

# **SERVICE MANUAL**

# **XP500A**



59C-28197-E1

EAS20040

XP500A SERVICE MANUAL ©2011 by Yamaha Motor Co., Ltd. First edition, November 2011 All rights reserved. Any reproduction or unauthorized use without the written permission of Yamaha Motor Co., Ltd. is expressly prohibited.

# EAS20071

This manual was produced by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha vehicles should have a basic understanding of mechanics and the techniques to repair these types of vehicles. Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

Yamaha Motor Company, Ltd. is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

#### TIP.

Designs and specifications are subject to change without notice.

#### EAS20081

## IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following notations.

	This is the safety alert symbol. It is used to alert you to potential per- sonal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
	A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
NOTICE	A NOTICE indicates special precautions that must be taken to avoid damage to the vehicle or other property.
TIP	A TIP provides key information to make procedures easier or clearer.

# HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

- The manual is divided into chapters and each chapter is divided into sections. The current section title "1" is shown at the top of each page.
- Sub-section titles "2" appear in smaller print than the section title.
- To help identify parts and clarify procedure steps, there are exploded diagrams "3" at the start of each removal and disassembly section.
- Numbers "4" are given in the order of the jobs in the exploded diagram. A number indicates a disassembly step.
- Symbols "5" indicate parts to be lubricated or replaced. Refer to "SYMBOLS".
- A job instruction chart "6" accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
- Jobs "7" requiring more information (such as special tools and technical data) are described sequentially.



## EAS20101 SYMBOLS

The following symbols are used in this manual for easier understanding.

TIP\_\_\_\_

The following symbols are not relevant to every vehicle.

SYMBOL	DEFINITION	SYMBOL	DEFINITION
Ø	Serviceable with engine mounted	G	Gear oil
· C	Filling fluid		Molybdenum disulfide oil
	Lubricant	BF	Brake fluid
A DECEMBER OF A	Special tool	B	Wheel bearing grease
	Tightening torque	2	Lithium-soap-based grease
<b>K</b>	Wear limit, clearance		Molybdenum disulfide grease
	Engine speed		Silicone grease
	Electrical data		Apply locking agent (LOCTITE®).
Ē	Engine oil	New	Replace the part with a new one.

# **TABLE OF CONTENTS**

EAS20110

GENERAL INFORMATION		
SPECIFICATIONS	2	
PERIODIC CHECKS AND ADJUSTMENTS	3	
CHASSIS	4	
ENGINE	5	
COOLING SYSTEM	6	
FUEL SYSTEM	7	
ELECTRICAL SYSTEM	8	
TROUBLESHOOTING	9	

# **GENERAL INFORMATION**

IDENTIFICATION	1-1
VEHICLE IDENTIFICATION NUMBER	1-1
MODEL LABEL	1-1
	1.0
	1-2
	1-2
	1-3
	1-4
OUTLINE OF THE ABS	1-10
ABS COMPONENT FUNCTIONS	1-16
ABS OPERATION	1-22
ABS SELF-DIAGNOSIS FUNCTION	1-25
ABS WARNING LIGHT AND OPERATION	1-28
IMPORTANT INFORMATION	1-20
	1_20
	1_20
	1-29
	1-29
LUCK WASHERS/PLATES AND CUTTER PINS	1-29
BEARINGS AND UIL SEALS	1-30
	1-30
RUBBER PARTS	1-30
BASIC SERVICE INFORMATION	1-31
QUICK FASTENERS	1-31
ELECTRICAL SYSTEM	
	······································
	4 07
SPECIAL IUULS	1-37

# EAS20130

#### EAS20140

# VEHICLE IDENTIFICATION NUMBER

The vehicle identification number "1" is stamped into the right side of the frame.



#### EAS20150 MODEL LABEL

The model label "1" is affixed to the storage box. This information will be needed to order spare parts.



#### EAS20170 FEATURES

#### EAS4B51038

## **OUTLINE OF FI SYSTEM**

The main function of a fuel supply system is to provide fuel to the combustion chamber at the optimum air-fuel ratio in accordance with the engine operating conditions. In a conventional carburetor system, the air-fuel ratio of the mixture that is supplied to the combustion chamber is created by the volume of the intake air and the fuel that is metered by the jet used in the respective chamber. Despite the same volume of intake air, the fuel volume requirement varies with the engine operating conditions, such as acceleration, deceleration, or operation under a heavy load. Carburetors that meter the fuel through the use of jets have been provided with various auxiliary devices, so that an optimum air-fuel ratio can be achieved to accommodate the constant changes in the operating conditions of the engine.

As the requirements for engines to deliver more performance and cleaner exhaust gases increase, it becomes necessary to control the air-fuel ratio in a more precise and finely tuned manner. To

accommodate this need, this model has adopted an electronically controlled fuel injection (FI) system in place of a conventional carburetor system. This system can achieve an optimum air-fuel ratio required by the engine at all times by using a microprocessor that regulates the fuel injection volume according to the engine operating conditions detected by various sensors.

Adoption of the FI system has resulted in a highly precise fuel supply, improved engine response, better fuel economy, and reduced exhaust emissions.



- 1. Fuel injector
- 2. Intake air temperature sensor
- 3. Lean angle sensor
- 4. ECU (engine control unit)
- 5. Engine trouble warning light
- 6. Battery
- 7. Intake air pressure sensor
- 8. Fuel hose
- 9. O<sub>2</sub> sensor
- 10.Fuel pump
- 11.Crankshaft position sensor
- 12.Fuel tank
- 13.Coolant temperature sensor

14.Throttle position sensor15.Spark plug16.Ignition coil17.Front wheel sensor

#### EAS4B51039 FI SYSTEM

The fuel pump delivers fuel to the fuel injector via the fuel filter. The pressure regulator (in the fuel pump) maintains the fuel pressure that is applied to the fuel injector at a certain level. Accordingly, when the energizing signal from the ECU (engine control unit) energizes the fuel injector, the fuel passage opens, causing the fuel to be injected into the intake manifold only during the time the passage remains open. Therefore, the longer the length of time the fuel injector is energized (injection duration), the greater the volume of fuel that is supplied. Conversely, the shorter the length of time the fuel injector is energized (injection duration), the greater the volume of fuel that is supplied. Conversely, the shorter the length of time the fuel injector is energized (injection duration), the lesser the volume of fuel that is supplied. The injection duration and the injection timing are controlled by the ECU (engine control unit). Signals that are input from the throttle position sensor, crankshaft position sensor, intake air pressure sensor, intake air temperature sensor, coolant temperature sensor, and O<sub>2</sub> sensor enable the ECU (engine control unit) to determine the injection duration. The injection timing is determined through the signals from the crankshaft position sensor. As a result, the volume of fuel that is required by the engine can be supplied at all times in accordance with the driving conditions.



11.Intake air temperature sensor

#### EAS52240 MULTI-FUNCTION DISPLAY EWA12312

## A WARNING

Be sure to stop the vehicle before making any setting changes to the multi-function display. Changing settings while riding can distract the operator and increase the risk of an accident.



- 1. Left set button
- 2. Fuel meter
- 3. Fuel level warning indicator "₽"
- 4. Odometer
- 5. Coolant temperature warning indicator " 🚛 "
- 6. Coolant temperature meter
- 7. Right set button



- 1. Tripmeter/fuel reserve tripmeter
- 2. Ambient temperature/average fuel consumption/instantaneous fuel consumption



1. Clock

The multi-function display is equipped with the following:

- A fuel meter
- A coolant temperature meter
- An odometer
- Two tripmeters (which show the distance traveled since they were last set to zero)
- A fuel reserve tripmeter (which shows the distance traveled when the remaining fuel in the fuel tank reaches approximately 3.0 L (0.79 US gal, 0.66 Imp.gal))
- A self-diagnosis device
- A clock
- · An ambient temperature display
- A fuel consumption display (average and instantaneous consumption functions)
- An oil change tripmeter (which shows the distance traveled since the last engine oil change)
- A V-belt replacement tripmeter (which shows the distance traveled since the last V-belt replacement)

#### TIP\_

- Be sure to turn the key to "ON" before using the left and right set buttons.
- When the key is turned to "ON", all of the display segments of the multi-function display will appear one after the other and then disappear, in order to test the electrical circuits.

#### Clock



1. Clock

To set the clock:

- 1. Push the left set button and right set button together for at least two seconds.
- 2. When the hour digits start flashing, push the right set button to set the hours.
- 3. Push the left set button, and the minute digits will start flashing.
- 4. Push the right set button to set the minutes.

5. Push the left set button and then release it to start the clock.

#### Odometer and tripmeter modes



1. Odometer/tripmeters/fuel reserve tripmeter



1. Oil change tripmeter



1. V-belt replacement tripmeter

Pushing the left set button switches the display between the odometer mode and the tripmeter modes in the following order:

 $\begin{array}{l} \mathsf{Odo} \to \mathsf{Trip} \ 1 \to \mathsf{Trip} \ 2 \to \mathsf{V}\text{-}\mathsf{Belt} \ \mathsf{Trip} \to \mathsf{Oil} \ \mathsf{Trip} \\ \to \mathsf{Odo} \end{array}$ 

When approximately 3.0 L (0.79 US gal, 0.66 Imp.gal) of fuel remains in the fuel tank, the display will automatically change to the fuel reserve tripmeter mode "Trip F" and start counting the distance traveled from that point. In that case, pushing the left set button switches the display between the various tripmeter and odometer modes in the following order:

 $\begin{array}{l} \mathsf{Odo} \to \mathsf{Trip} \ 1 \to \mathsf{Trip} \ 2 \to \mathsf{Trip} \ \mathsf{F} \to \mathsf{V}\text{-}\mathsf{Belt} \ \mathsf{Trip} \\ \to \mathsf{Oil} \ \mathsf{Trip} \to \mathsf{Odo} \end{array}$ 



1. Fuel reserve tripmeter

To reset a tripmeter, select it by pushing the left set button until "Trip F", "Trip 1" or "Trip 2" is displayed. While "Trip F", "Trip 1" or "Trip 2" is displayed, push the left set button for at least one second. If you do not reset the fuel reserve tripmeter manually, it will reset itself automatically and the display will return to the prior mode after refueling and traveling 5 km (3 mi).

#### **Fuel meter**

With the key in the "ON" position, the fuel meter indicates the amount of fuel in the fuel tank. The display segments of the fuel meter disappear towards "E" (Empty) as the fuel level decreases. When the fuel level reaches the bottom segment near "E", the fuel level warning indicator, "F", "E", and the bottom segment will flash. Refuel as soon as possible.



#### **Coolant temperature meter**

With the key in the "ON" position, the coolant temperature meter indicates the temperature of the coolant. The coolant temperature varies with changes in the weather and engine load. If the top segment, "H", "C", and coolant temperature warning indicator flash, stop the vehicle and let the engine cool.



ECA10021

Do not continue to operate the engine if it is overheating.

#### Oil change indicator "Oil"



1. Oil change indicator "Oil"

This indicator flashes at the initial 1000 km (600 mi), then at 5000 km (3000 mi) and every 5000 km (3000 mi) thereafter to indicate that the engine oil should be changed. After changing the engine oil, reset the oil change indicator. To reset the oil change indicator, select it by pushing the left set button until "Oil Trip" is displayed, and then push the left set button at least one second. When pushing the left set button, "Oil Trip" starts flashing. While "Oil Trip" is flashing, push the left set button for at least three seconds. If the engine oil is changed before the oil change indicator "Oil" flashes (i.e. before the periodic oil change interval has been reached), the indicator "Oil" must be reset after the oil change for the next periodic oil change to be indicated at the correct time.

The electrical circuit of the indicator can be checked according to the following procedure.

- 1. Set the engine stop switch to "⊖" and turn the key to "ON".
- 2. Check that the oil change indicator comes on for a few seconds and then goes off.

 If the oil change indicator does not come on, check the electrical circuit. (Refer to "SIGNALING SYSTEM" on page 8-19)

## V-belt replacement indicator "V-Belt"



1. V-belt replacement indicator "V-Belt"

This indicator flashes every 20000 km (12500 mi) when the V-belt needs to be replaced. After changing the V-belt, reset the V-belt replacement indicator. To reset the V-belt replacement indicator, select it by pushing the left set button until "V-Belt Trip" is displayed, and then push the left set button at least one second. When pushing the left set button, "V-Belt Trip" starts flashing. While "V-Belt Trip" is flashing, push the left set button for at least three seconds.

If the V-belt is changed before the V-belt replacement indicator "V-Belt" flashes (i.e. before the periodic V-belt change interval has been reached), the indicator "V-Belt" must be reset after the V-belt change for the next periodic V-belt change to be indicated at the correct time.

The electrical circuit of the indicator can be checked according to the following procedure.

- 1. Turn the key to "ON" and make sure that the engine stop switch is set to "⊖".
- 2. Check that the V-belt replacement indicator comes on for a few seconds and then goes off.
- If the V-belt replacement indicator does not come on, check the electrical circuit. (Refer to "SIGNALING SYSTEM" on page 8-19)

Ambient temperature display, average fuel consumption and instantaneous fuel consumption modes



1. Ambient temperature/average fuel consumption/instantaneous fuel consumption

Push the right set button to switch the display between the ambient temperature display "Air", the average fuel consumption mode "AVE\_\_.\_ km/L" or "AVE\_\_.\_ L/100 km", and the instantaneous fuel consumption mode "km/L" or "L/ 100 km" in the following order:

Air  $\rightarrow$  AVE\_ \_.\_ km/L or AVE\_ \_.\_ L/100 km  $\rightarrow$  km/L or L/100 km  $\rightarrow$  Air

For the UK only:

Push the right set button to switch the display between the ambient temperature display "Air", the average fuel consumption mode "AVE\_\_\_\_ MPG", and the instantaneous fuel consumption mode "MPG" in the following order:

 $\mathsf{Air} \to \mathsf{AVE}\_\_.\_\mathsf{MPG} \to \mathsf{MPG} \to \mathsf{Air}$ 

Ambient temperature display



1. Ambient temperature display

This display shows the ambient temperature from -9 °C to 40 °C in 1 °C increments.

For the UK only:

15 °F to 104 °F in 1 °F increments. The temperature displayed may vary from the ambient temperature. Pushing the right set button switches the ambient temperature display to the average fuel consumption and instantaneous fuel consumption modes.

Average fuel consumption mode



1. Average fuel consumption display

The average fuel consumption display can be set to either "AVE\_\_.\_ km/L" or "AVE\_\_.\_ L/ 100 km" (except for the UK).

For the UK only:

The average fuel consumption is displayed "AVE\_\_\_\_ MPG".

This display shows the average fuel consumption since it was last reset.

- When the display is set to "AVE\_ \_.\_ km/L", the average distance that can be traveled on 1.0 L of fuel is shown.
- When the display is set to "AVE\_\_.\_L/100 km", the average amount of fuel necessary to travel 100 km is shown.
- For the UK only: When the display is set to "AVE\_\_.\_ MPG", the average distance that can be traveled on 1.0 Imp.gal of fuel is shown.

To switch between the instantaneous fuel consumption displays, push the right set button for one second when one of the displays is shown (except for the UK).

To reset the average fuel consumption display, select it by pushing the right set button, and then push the right set button for at least one second.

#### TIP\_

After resetting an average fuel consumption display, "\_\_\_." is shown for that display until the vehicle has traveled 1 km (0.6 mi).

Instantaneous fuel consumption mode



1. Instantaneous fuel consumption display

The instantaneous fuel consumption display can be set to either "km/L" or "L/100 km" (except for the UK).

For the UK only:

The instantaneous fuel consumption is displayed "MPG".

- When the display is set to "km/L", the distance that can be traveled on 1.0 L of fuel under the current riding conditions is shown.
- When the display is set to "L/100 km", the amount of fuel necessary to travel 100 km under the current riding conditions is shown.
- For the UK only: The distance that can be traveled on 1.0 Imp.gal of fuel under the current riding conditions is shown.

#### TIP\_

If traveling at speeds under 10 km/h (6.0 mi/h), "\_ \_.\_" is displayed.

#### Self-diagnosis device



1. Error code display

This model is equipped with a self-diagnosis device for various electrical circuits. If a problem is detected in any of those circuits, the engine trouble warning light comes on and the display indicates an error code. If the display indicates any error codes, note the code number, and check the fuel injection system (Refer to "FUEL INJECTION SYSTEM" on page 8-29).

The self-diagnosis device also detects problems in the immobilizer system circuits. If a problem is detected in any of the immobilizer system circuits, the immobilizer system indicator light flashes and the display indicates an error code.

#### TIP.

If the display indicates error code 52, this could be caused by transponder interference. If this error code appears, try the following.

1. Use the code re-registering key to start the engine.

#### TIP\_

Make sure there are no other immobilizer keys close to the main switch, and do not keep more than one immobilizer key on the same key ring! Immobilizer system keys may cause signal interference, which may prevent the engine from starting.

- 2. If the engine starts, turn it off and try starting the engine with the standard keys.
- 3. If one or both of the standard keys do not start the engine, check the immobilizer system (Refer to "IMMOBILIZER SYSTEM" on page 8-75).

ECA11590 NOTICE

If the display indicates an error code, the vehicle should be checked as soon as possible in order to avoid engine damage.

#### EAS59C2101 OUTLINE OF THE ABS

- 1. The Yamaha ABS (anti-lock brake system) features an electronic control system, which acts on the front and rear brakes independently.
- 2. The ABS features a compact and lightweight design to help maintain the basic maneuverability of the vehicle.

#### **ABS** layout



- 1. Hydraulic unit assembly (ABS ECU)
- 2. Fuse box (right)
- 3. Fuse box (left)
- 4. ABS warning light
- 5. ABS test coupler

- 6. Rear wheel sensor rotor
- 7. Rear wheel sensor
- 8. Front wheel sensor
- 9. Front wheel sensor rotor

## ABS

The operation of the Yamaha ABS brakes is the same as conventional brakes on other vehicles, with a front brake lever for operating the front brake and a rear brake lever for operating the rear brake. When wheel lock is detected during emergency braking, hydraulic control is performed by the hydraulic system on the front and rear brakes independently.

# Useful terms

• Wheel speed:

The rotation speed of the front and rear wheels.

- Chassis speed:
  - The speed of the chassis.

When the brakes are applied, wheel speed and chassis speed are reduced. However, the chassis travels forward by its inertia even though the wheel speed is reduced.

- Brake force:
  - The force applied by braking to reduce the wheel speed.
- Wheel lock:

A condition that occurs when the rotation of one or both of the wheels has stopped, but the vehicle continues to travel.

• Side force:

The force on the tires which supports the vehicle when cornering.

• Slip ratio:

When the brakes are applied, slipping occurs between the tires and the road surface. This causes a difference between the wheel speed and the chassis speed.

Slip ratio is the value that shows the rate of wheel slippage and is defined by the following formula.



0%: There is no slipping between the wheel and the road surface. The chassis speed is equal to the wheel speed.

100%: The wheel speed is "0", but the chassis is moving (i.e., wheel lock).

#### Brake force and vehicle stability

When the brake pressure is increased, wheel speed is reduced. Slipping occurs between the tire and the road surface and brake force is generated. The limit of this brake force is determined by the friction force between the tire and the road surface and is closely related to wheel slippage. Wheel slippage is represented by the slip ratio.

Side force is also closely related to wheel slippage. See figure "A". If the brakes are applied while keeping the proper slip ratio, it is possible to obtain the maximum brake force without losing much side force.

ABS allows full use of the tires' capabilities even on slippery road surfaces or less slippery road surfaces. See figure "B".



- a. Friction force between the tire and road surface
- b. Brake force
- c. Side force
- d. Slip ratio (%)
- e. Less slippery road surface
- f. Controlling zone
- g. Slippery road surface

#### Wheel slip and hydraulic control

The ABS ECU calculates the wheel speed of each wheel according to the rotation signal received from the front and rear wheel sensors. In addition, the ABS ECU calculates the vehicle chassis speed and the rate of speed reduction based on the wheel speed values.

The difference between the chassis speed and the wheel speed calculated in the slip ratio formula is equal to the wheel slip. When the wheel speed is suddenly reduced, the wheel has a tendency to lock. When the wheel slip and the wheel speed reduction rate exceed the preset values, the ABS ECU determines that the wheel has a tendency to lock.

If the slip is large and the wheel has a tendency to lock (point A in the following figure), the ABS ECU reduces the brake fluid pressure in the brake caliper. Once the ABS ECU determines that the tendency of the wheel to lock has diminished after the brake fluid pressure is reduced, it increases the hydraulic pressure (point B in the following figure). The hydraulic pressure is initially increased quickly, and then it is increased gradually.



- a. Chassis speed
- b. Wheel speed
- c. Brake force
- d. Depressurizing phase
- e. Pressurizing phase

#### ABS operation and vehicle control

If the ABS starts operating, there is a tendency of the wheel to lock, and the vehicle is approaching the limit of control. To make the rider aware of this condition, the ABS has been designed to generate a reaction-force pulsating action in the front brake lever and rear brake lever independently.

TIP.

When the ABS is activated, a pulsating action may be felt at the front brake lever or rear brake lever, but this does not indicate a malfunction.

The higher the side force on a tire, the less traction there is available for braking. This is true whether the vehicle is equipped with ABS or not. Therefore, sudden braking while cornering is not recommended. Excessive side force, which ABS cannot prevent, could cause the tire to slip sideways.

#### EWA59C2101

#### A WARNING

The braking of the vehicle, even in the worst case, is principally executed when the vehicle is advancing straight ahead. During a turn, sudden braking is liable to cause a loss of traction of the tires. Even in vehicles equipped with ABS, overturning of the vehicle cannot be prevented if it is braked suddenly.

The ABS functions to prevent the tendency of the wheel to lock by controlling the brake fluid pressure. However, if there is a tendency of the wheel to lock on a slippery road surface, due to engine braking, the ABS may not be able to prevent the wheel from locking.

## 

The ABS controls only the tendency of the wheel to lock caused by applying the brakes. The ABS cannot prevent wheel lock on slippery surfaces, such as ice, when it is caused by engine braking, even if the ABS is operating.



- a. Friction force between the tire and road surface
- b. Brake force
- c. Side force
- d. Slip ratio (%)

#### **Electronic ABS features**

The Yamaha ABS (anti-lock brake system) has been developed with the most advanced electronic technology.

The ABS control is processed with good response under various vehicle travel conditions.

The ABS also includes a highly developed self-diagnosis function. The ABS detects any problem condition and allows normal braking even if the ABS is not operating properly.

When this occurs, the ABS warning light on the meter assembly comes on.

The ABS stores the fault codes in the memory of the ABS ECU for easy problem identification and troubleshooting.

#### ABS block diagram



- 1. Rear brake master cylinder
- 2. Hydraulic unit assembly
- 3. Front brake master cylinder
- 4. Inlet solenoid valve
- 5. ABS motor
- 6. Hydraulic pump
- 7. Outlet solenoid valve
- 8. ABS ECU
- 9. Buffer chamber
- 10.Rear brake caliper
- 11.Rear wheel sensor
- 12.ABS warning light
- 13. Front brake caliper
- 14. Front wheel sensor

#### EAS59C2102 ABS COMPONENT FUNCTIONS

#### Wheel sensors and wheel sensor rotors

Wheel sensors "1" detect the wheel rotation speed and transmit the wheel rotation signal to the ABS ECU.

Each wheel sensor contains a Hall IC. The wheel sensors are installed in the sensor housing for each wheel.

Sensor rotors "2" are installed on the inner side of the front and rear wheel hubs and rotate with the wheels.

The front sensor rotor has 80 magnetic poles (40 pairs) and the rear sensor rotor has 92 magnetic poles (46 pairs). They are installed close to the wheel sensors. As the sensor rotor rotates, the Hall element in the Hall IC installed in the wheel sensor generates pulses. The pulse frequency, which is proportional to the magnetic flux density, is converted into a wave in the Hall IC so that it can be output.

The ABS ECU calculates the wheel rotation speed by detecting the pulse frequency.





- 3. At low speed
- 4. At high speed
- 5. Wheel sensor
- 6. Wheel sensor rotor
- 7. Voltage
- 8. Time

#### ABS warning light

The ABS warning light "1" comes on to warn the rider if a malfunction in the ABS occurs. When the main switch is set to "ON", the ABS warning light comes on to check the electrical circuit and the system function (ABS self-diagnosis), and goes off when the vehicle is operated (the function check is properly completed at a speed of about 6 to 10 km/h [3.8 to 6.3 mi/h]).

- TIP\_
- The ABS warning light may go off later than usual when the vehicle is operated while the brakes are applied (the brake switch turned to "ON").
- The ABS warning light goes off when walking or operating the vehicle at a speed of faster than 7 km/h (4.4 mi/h) after correcting malfunctions that have occurred in the past with all the necessary checks and services completed.

The ABS warning light comes on to check the electrical circuit while the start switch is being pushed.

ECA59C2101

#### NOTICE

If the rear wheel is raced with the vehicle on a centerstand, the system may determine that a malfunction has been detected, and the ABS warning light may flash or come on. If this occurs, set the main switch to "OFF", then back to "ON". The system is normal if the ABS warning light goes off after starting off. If the fault codes have not been deleted, the fault codes remain in the memory and the ABS warning light goes off when the vehicle is operated at a speed of about 30 km/h (18.8 mi/h).



#### Hydraulic unit assembly

The hydraulic unit assembly "1" is composed of hydraulic control valves (each with a outlet solenoid valve and inlet solenoid valve), buffer chambers, hydraulic pumps, an ABS motor, and ABS ECU. The hydraulic unit adjusts the front and rear wheel brake fluid pressure to control the wheel speed according to signals transmitted from the ABS ECU.



#### Hydraulic control valve

The hydraulic control valve is composed of a inlet solenoid valve and outlet solenoid valve. The electromagnetic force generated in the inlet solenoid valve varies proportionally with the duty cycle control voltage that is supplied to it. Since this voltage is continuously variable, the solenoid valve moves smoothly and the hydraulic pressure is adjusted linearly.

1. When the brakes are operated normally, the inlet solenoid valve "1" is open and the outlet solenoid valve "2" is closed. The brake line between the brake master cylinder and brake caliper is open.



2. When the ABS is activated, the inlet solenoid valve "1" closes and the outlet solenoid valve "2" opens using the power supplied from the ABS ECU signals. This reduces the hydraulic pressure.



3. When the ABS ECU sends a signal to stop reducing the hydraulic pressure, the outlet solenoid valve "2" closes and the brake fluid is pressurized again. The inlet solenoid valve "1" controls the hydraulic pressure difference between the brake fluid in the upper brake lines (brake master cylinder side) and the brake fluid in the lower brake lines (brake caliper side).



## • Buffer chamber

The buffer chamber accumulates the brake fluid that is depressurized while the ABS is operating.



- 1. Buffer chamber (pressurizing phase)
- 2. Buffer chamber (depressurizing phase)
- 3. Raised piston

# ABS ECU

The ABS ECU is integrated with the hydraulic unit to achieve a compact and lightweight design. As shown in the following block diagram, the ABS ECU receives wheel sensor signals from the front and rear wheels and also receives signals from other monitor circuits.



- 1. Battery
- 2. AC magneto
- 3. Rectifier/regulator
- 4. Main fuse
- 5. Main switch
- 6. ABS ECU fuse
- 7. ABS motor fuse
- 8. ABS solenoid fuse
- 9. Front brake light switch
- 10.Rear brake light switch
- 11.Tail/brake light
- 12.Hydraulic unit assembly
- 13.ABS ECU
- 14.Solenoid relay
- 15.ABS motor relay
- 16. Front brake inlet solenoid

17.Front brake outlet solenoid 18.Rear brake inlet solenoid 19.Rear brake outlet solenoid 20.ABS motor 21.ECU (engine control unit) 22.Meter assembly 23.ABS warning light 24.Speedometer 25.ABS test coupler 26.Rear wheel sensor 27.Front wheel sensor 28.Start switch 29.Starting circuit cut-off relay 2 30.Starting circuit cut-off relay 1 31.Starter motor 32.Starter relay

The necessary actions are confirmed using the monitor circuit and control signals are transmitted to the hydraulic unit assembly.

#### ABS control operation

The ABS control operation performed in the ABS ECU is divided into the following two parts.

- Hydraulic control
- Self-diagnosis

When a malfunction is detected in the ABS, a fault code is stored in the memory of the ABS ECU for easy problem identification and troubleshooting.

- TIP\_
- Some types of malfunctions are not recorded in the memory of the ABS ECU (e.g., a blown ABS ECU fuse).
- The ABS performs a self-diagnosis test for a few seconds each time the vehicle starts up for the first time after the main switch was set to "ON". During this test, a "clicking" noise can be heard from front side of the vehicle, and if the front brake lever or rear brake lever are even slightly applied, a vibration can be felt at the levers, but these do not indicate a malfunction.



- 1. Software operation flow
- 2. Main switch "ON"
- 3. Initialize
- 4. Self-diagnosis (when static)
- 5. Self-diagnosis (when riding)
- 6. Receive signals
- 7. Control operation
- 8. Depressurize/pressurize

#### EAS59C2103 ABS OPERATION

The ABS hydraulic circuit consists of two systems: the front wheel, and rear wheel. The following describes the system for the front wheel only.

#### Normal braking (ABS not activated)

When the ABS is not activated, the inlet solenoid valve is open and the outlet solenoid valve is closed because a control signal has not been transmitted from the ABS ECU. Therefore, when the brake lever is squeezed, the hydraulic pressure in the brake master cylinder increases and the brake fluid is sent to the brake caliper.

At this time, the inlet and outlet check valves of the hydraulic pump are closed. As a result of eliminating the orifice, the brake master cylinder directly pressurizes the brake caliper during normal braking. When the brake lever is released, the brake fluid in the brake caliper returns to the brake master cylinder.



#### **Emergency braking (ABS activated)**

1. Depressurizing phase

When the front wheel is about to lock, the outlet solenoid valve is opened by the "depressurization" signal transmitted from the ABS ECU. When this occurs, the inlet solenoid valve compresses the spring and closes the brake line from the brake master cylinder. Because the outlet solenoid valve is open, the brake fluid is sent to the buffer chamber. As a result, the hydraulic pressure in the brake caliper is reduced.

The brake fluid stored in the buffer chamber is pumped back to the brake master cylinder by the hydraulic pump linked to the ABS motor.



- 1. Brake master cylinder
- 2. Brake light switch
- 3. ABS motor
- 4. Hydraulic pump
- 5. Buffer chamber
- 6. Outlet solenoid valve
- 7. Inlet solenoid valve
- 8. Brake caliper
- 9. Wheel sensor
- 10.ABS ECU
- 11.ABS warning light
- 12.Brake fluid pressure
- 13.Time

#### 2. Pressurizing phase

The outlet solenoid valve is closed by the "pressurization" signal transmitted from the ABS ECU. At this time, the ABS ECU controls the opening of the inlet solenoid valve. As the inlet solenoid valve opens, the brake line from the brake master cylinder opens, allowing the brake fluid to be sent to the brake caliper.



- 1. Brake master cylinder
- 2. Brake light switch
- 3. ABS motor
- 4. Hydraulic pump
- 5. Buffer chamber
- 6. Outlet solenoid valve
- 7. Inlet solenoid valve
- 8. Brake caliper
- 9. Wheel sensor
- 10.ABS ECU
- 11.ABS warning light
- 12.Brake fluid pressure
- 13.Time

#### EAS59C2104 ABS SELF-DIAGNOSIS FUNCTION

#### **ABS warning light**

The ABS warning light "1" comes on when a malfunction is detected by the ABS self-diagnosis. It is located in the meter assembly.



#### Instances when the ABS warning light comes on

1. The ABS warning light comes on when the main switch is set to "ON".

The ABS warning light comes on while the ABS is performing a self-diagnosis, then goes off if there are no malfunctions.

The self-diagnosis begins when the main switch is set to "ON", and is completed when the vehicle is operated at a speed of about 10 km/h (6.3 mi/h). (Refer to "ABS warning light" on page 1-17.)



- a. ABS warning light
- b. Main switch "OFF"
- c. Main switch "ON"
- d. Goes off
- e. Comes on
- f. The ABS self-diagnosis is completed (at a speed of about 10 km/h [6.3 mi/h]: refer to "ABS warning light" on page 1-17.)

2. The ABS warning light comes on while the start switch is being pushed.



- a. ABS warning light
- b. Main switch "OFF"
- c. Main switch "ON"
- d. Start switch "ON"
- e. Start switch "OFF"
- f. Goes off

- g. Comes on
- h. The ABS self-diagnosis is completed (walking the vehicle at a speed of faster than 7 km/h [4.4 mi/h].)
- i. Comes on while the start switch is being pushed
- The ABS warning light comes on while riding. If the ABS warning light comes on while riding, a malfunction has been detected in the ABS. The ABS hydraulic control will not be performed. The ABS will have recourse to manual braking if this occurs.



a. ABS warning light

b. Comes on

 The ABS warning light flashes while riding. If the ABS warning light flashes while riding, there is no problem with the function of the ABS. However, the ABS ECU input has unstable factors. (For details, refer to "ABS TROUBLE-SHOOTING OUTLINE" on page 8-91.)

#### TIP\_

The ABS warning light comes on or flashes if the vehicle is ridden with the test coupler adapter connected to the ABS test coupler.



a. ABS warning light

b. Comes on

c. Goes offd. Unstable ABS ECU input

5. The ABS warning light "1" flashes and a fault code "2" is indicated on the multi-function display when the test coupler adapter "3" is connected to the ABS test coupler "4" for troubleshooting the ABS.

When the test coupler adapter is connected to the ABS test coupler, the ABS warning light starts flashing and the multi-function display indicates all the fault codes recorded in the ABS ECU.



Test coupler adapter 90890-03149

TIP\_

The ABS warning light comes on or flashes if the vehicle is ridden with the test coupler adapter connected to the ABS test coupler.




# FEATURES



EAS59C2105 ABS WARNING LIGHT AND OPERATION

ABS function EWA59C2103

- When hydraulic control is performed by the ABS, the brake system alerts the rider that the
  wheels have a tendency to lock by generating a reaction-force pulsating action in the front
  brake lever or rear brake lever. When the ABS is activated, the grip between the road surface and tires is close to the limit. The ABS cannot prevent wheel lock\* on slippery surfaces, such as ice, when it is caused by engine braking, even if the ABS is activated.
  Use extreme care when operating the vehicle under these conditions.
- The ABS is not designed to shorten the braking distance or improve the cornering performance.
- Depending on the road conditions, the braking distance may be longer compared to that of vehicles not equipped with ABS. Therefore, ride at a safe speed and keep a safe distance between yourself and other vehicles.
- The braking of the vehicle, even in the worst case, is principally executed when the vehicle is advancing straight ahead. During a turn, sudden braking is liable to cause a loss of traction of the tires. Even vehicles equipped with ABS cannot be prevented from falling over if braked suddenly.
- The ABS does not work when the main switch is set to "OFF". The conventional braking function can be used.

\* Wheel lock: A condition that occurs when the rotation of one or both of the wheels has stopped, but the vehicle continues to travel.

# IMPORTANT INFORMATION

### EAS20190

### PREPARATION FOR REMOVAL AND DISAS-SEMBLY

1. Before removal and disassembly, remove all dirt, mud, dust and foreign material.



- 2. Use only the proper tools and cleaning equipment.
  - Refer to "SPECIAL TOOLS" on page 1-37.
- 3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.



- 4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
- 5. Keep all parts away from any source of fire.

### EAS20200

## **REPLACEMENT PARTS**

Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.



#### EAS20210 GASKETS, OIL SEALS AND O-RINGS

- 1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
- 2. During reassembly, properly oil all mating parts and bearings and lubricate the oil seal lips with grease.



- 1. Oil
- 2. Lip
- 3. Spring
- 4. Grease

#### EAS20220 LOCK WASHERS/PLATES AND COTTER PINS

After removal, replace all lock washers/plates "1" and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.



### EAS20231

# BEARINGS AND OIL SEALS

Install bearings "1" and oil seals "2" so that the manufacturer marks or numbers are visible. When installing oil seals, lubricate the oil seal lips with a light coat of lithium-soap-based grease. Oil bearings liberally when installing, if appropriate.

# ECA13300

Do not spin the bearing with compressed air because this will damage the bearing surfaces.





# EAS20240

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip "1", make sure the sharp-edged corner "2" is positioned opposite the thrust "3" that the circlip receives.



#### EAS59C1101 RUBBER PARTS

Check rubber parts for deterioration during inspection. Some of the rubber parts are sensitive to gasoline, flammable oil, grease, etc. Do not allow any items other than the specified one to contact the parts.

# **BASIC SERVICE INFORMATION**

# BASIC SERVICE INFORMATION

#### EAS30390 QUICK FASTENERS

### **Rivet type**

- 1. Remove:
  - Quick fastener

### TIP\_

To remove the quick fastener, push its pin with a screwdriver, then pull the fastener out.









## Screw type

- 1. Remove:
  - Quick fastener

#### TIP\_

To remove the quick fastener, loosen the screw with a screwdriver, then pull the fastener out.







- 2. Install:
  - Quick fastener

### TIP\_

To install the quick fastener, insert the fastener into the part to be secured and tighten the screw.



Quick fastener

### TIP\_

To install the quick fastener, push its pin so that it protrudes from the fastener head, then insert the fastener into the part to be secured and push the pin in with a screwdriver. Make sure that the pin is flush with the fastener's head.



# **BASIC SERVICE INFORMATION**





# EAS30402

Electrical parts handling

### NOTICE

Never disconnect a battery lead while the engine is running; otherwise, the electrical components could be damaged.



### ECA16751

#### NOTICE

When disconnecting the battery leads from the battery, be sure to disconnect the negative battery lead first, then the positive battery lead. If the positive battery lead is disconnected first and a tool or similar item contacts the vehicle, a spark could be generated, which is extremely dangerous.



### TIP.

If a battery lead is difficult to disconnect due to rust on the battery terminal, remove the rust using hot water.



#### ECA16760 **NOTICE**

Be sure to connect the battery leads to the correct battery terminals. Reversing the battery lead connections could damage the electrical components.



#### ECA16771 **NOTICE**

When connecting the battery leads to the battery, be sure to connect the positive battery lead first, then the negative battery lead. If the negative battery lead is connected first and a tool or similar item contacts the vehicle while the positive battery lead is being connected, a spark could be generated, which is extremely dangerous.



# NOTICE

Set the main switch to "OFF" before disconnecting or connecting an electrical component.



#### ECA16620

#### NOTICE

Handle electrical components with special care, and do not subject them to strong shocks.



# ECA16630

Electrical components are very sensitive to and can be damaged by static electricity. Therefore, never touch the terminals and be sure to keep the contacts clean.



### TIP\_

When resetting the ECU by turning the main switch to "OFF", be sure to wait approximately 5 seconds before turning the main switch back to "ON".



## Checking the electrical system

### TIP.

Before checking the electrical system, make sure that the battery voltage is at least 12 V.



#### ECA14371 **NOTICE**

Never insert the tester probes into the coupler terminal slots. Always insert the probes from the opposite end "a" of the coupler, taking care not to loosen or damage the leads.



# ECA16640

For waterproof couplers, never insert the tester probes directly into the coupler. When performing any checks using a waterproof coupler, use the specified test harness or a suitable commercially available test harness.



## Checking the connections

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

- 1. Disconnect:
  - Lead
  - Coupler
  - Connector

ECA16780

NOTICE

- When disconnecting a coupler, release the coupler lock, hold both sections of the coupler securely, and then disconnect the coupler.
- There are many types of coupler locks; therefore, be sure to check the type of coupler lock before disconnecting the coupler.



# ECA16790

When disconnecting a connector, do not pull the leads. Hold both sections of the connector securely, and then disconnect the connector.



- 2. Check:
  - Lead
  - Coupler
  - Connector

Moisture  $\rightarrow$  Dry with an air blower. Rust/stains  $\rightarrow$  Connect and disconnect several times.



- 3. Check:
  - All connections
    - Loose connection  $\rightarrow$  Connect properly.

TIP\_

• If the pin "1" on the terminal is flattened, bend it up.

# **BASIC SERVICE INFORMATION**

• After disassembling and assembling a coupler, pull on the leads to make sure that they are installed securely.





- 4. Connect:
  - Lead
  - Coupler
  - Connector

### TIP \_\_\_\_

- When connecting a coupler or connector, push both sections of the coupler or connector together until they are connected securely.
- Make sure all connections are tight.





- 5. Check:
  - Continuity (with the pocket tester)

Pocket tester 90890-03112 Analog pocket tester YU-03112-C

### TIP\_

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.





- 6. Check:
  - Resistance



Pocket tester 90890-03112 Analog pocket tester YU-03112-C TIP\_\_\_

The resistance values shown were obtained at the standard measuring temperature of 20 °C (68 °F). If the measuring temperature is not 20 °C (68 °F), the specified measuring conditions will be shown.



Intake air temperature sensor resistance 5.4–6.6 k $\Omega$  at 0 °C (32 °F) 290–390  $\Omega$  at 80 °C (176 °F)



The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools as this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools, part numbers or both may differ depending on the country.

When placing an order, refer to the list provided below to avoid any mistakes.

- TIP.
- For U.S.A. and Canada, use part numbers starting with "YM-", "YU-", or "ACC-".
- For others, use part numbers starting with "90890-".

Tool name/Tool No.	Illustration	Reference pages
Pocket tester 90890-03112 Analog pocket tester YU-03112-C		1-35, 8-125, 8- 126, 8-127, 8- 131, 8-133, 8- 134, 8-135, 8- 136, 8-137, 8- 138, 8-139, 8- 141
Valve lapper 90890-04101 Valve lapping tool YM-A8998	014	3-6
Vacuum gauge 90890-03094 Vacuummate YU-44456	90890-03094	3-9
	YU-44456	
Digital tachometer 90890-06760 YU-39951-B	Cost of the second seco	3-8, 3-9
Carburetor angle driver 2 90890-03173		3-10

Tool name/Tool No.	Illustration	Reference pages
Compression gauge 90890-03081 Engine compression tester YU-33223		5-1
Oil filter wrench 90890-01469 YM-01469	66.8	3-26, 6-6
Oil pressure gauge set 90890-03120	Contraction of the second seco	3-28
Oil pressure adapter B 90890-03124	M20×P1.5	3-28
Test coupler adapter 90890-03149		1-27, 4-73, 4-74
Pressure gauge 90890-03153 YU-03153	Contraction of the second seco	3-28, 7-4
Steering nut wrench 90890-01403 Exhaust flange nut wrench YU-A9472	R20	3-24, 4-90
Damper rod holder 90890-01460	021.2	4-84, 4-85

Tool name/Tool No.	Illustration	Reference pages
T-handle 90890-01326 T-handle 3/8" drive 60 cm long YM-01326	er	4-84, 4-85
Fork seal driver weight 90890-01367 Replacement hammer YM-A9409-7	90890-01367 90890-01367 YM-A9409-7/YM-A5142-4	4-86
Fork seal driver attachment (ø43) 90890-01374 Replacement 43 mm YM-A5142-3	043	4-86
Yamaha bond No. 1215 90890-85505 (Three Bond No.1215®)	Contraction of the second seco	5-17, 5-48, 5- 55, 5-72
Valve spring compressor 90890-04019 YM-04019	0000 0001 0000 M6×P1.0	5-22, 5-28
Valve spring compressor attachment 90890-04114 Valve spring compressor adapter 19.5 mm YM-04114	90890-04114 ø19	5-22, 5-28
	YM-04114 ø19.5	

Tool name/Tool No.	Illustration	Reference pages
Valve guide remover (ø4) 90890-04111 Valve guide remover (4.0 mm) YM-04111	04	5-24
Valve guide installer (ø4) 90890-04112 Valve guide installer (4.0 mm) YM-04112	ø7.3 ø9.1	5-24
Valve guide reamer (ø4) 90890-04113 Valve guide reamer (4.0 mm) YM-04113	4mm	5-24
Piston pin puller set 90890-01304 Piston pin puller YU-01304	90890-01304	5-30
Sheave holder 90890-01481	OD OD OC	5-44, 5-47, 5- 48, 5-49
Locknut wrench 90890-01348 YM-01348	90890-01348 46 * YM-01348	5-44, 5-45, 5-47

Tool name/Tool No.	Illustration	Reference pages
Sheave spring compressor 90890-04134 YM-04134	90890-04134	5-45, 5-47
	YM-04134	
Sheave fixed block 90890-04135 Sheave fixed bracket YM-04135	90890-04135	5-45, 5-47
	YM-04135	
Sheave holder 90890-01701 Primary clutch holder YS-01880-A	Contraction of the second seco	5-53, 5-55
Flywheel puller 90890-01362 Heavy duty puller YU-33270-B		5-53
Rotor holding tool 90890-01235 Universal magneto & rotor holder YU-01235	and the second sec	5-60, 5-64
Clutch spring compressor 90890-01482		5-60, 5-63

Tool name/Tool No.	Illustration	Reference pages
Universal clutch holder 90890-04086 YM-91042	90890-04086 <u>M8×P1.25</u> 30 <sup>1119</sup> 156	5-60, 5-63
	YM-91042	
Plane bearing installer 90890-04139		5-76, 5-80
Radiator cap tester 90890-01325 Mityvac cooling system tester kit YU-24460-A	90890-01325 Ø38	6-3
	YU-24460-A	
Radiator cap tester adapter 90890-01352 Pressure tester adapter YU-33984	90890-01352 041 028	6-3
	YU-33984	
Mechanical seal installer 90890-04132 Water pump seal installer YM-33221-A	ø27.5 014	6-12

Tool name/Tool No.	Illustration	Reference pages
Middle driven shaft bearing driver 90890-04058 Middle drive bearing installer 40 & 50mm YM-04058	040 0 e28	6-12
Fuel pressure adapter 90890-03181 YM-03181		7-4
Ignition checker 90890-06754 Oppama pet-4000 spark checker YM-34487		8-135
Thickness gauge 90890-03180 Feeler gauge set YU-26900-9		5-19, 5-61
Tension gauge 90890-03226 YM-03226		3-21
Test harness S- pressure sensor (3P) 90890-03207 YU-03207		8-140
Test harness- lean angle sensor (6P) 90890-03209 YU-03209		8-136

Tool name/Tool No.	Illustration	Reference pages
Digital circuit tester 90890-03189 Model 88 Multimeter with tachometer YU-A1927		5-37, 8-115, 8- 116, 8-137, 8- 140
Yamaha diagnostic tool 90890-03215	UNAMAA UNAMAA UNAMAA UNAMAA UNAMAA	8-35

# SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
ENGINE SPECIFICATIONS	2-2
CHASSIS SPECIFICATIONS	2-9
ELECTRICAL SPECIFICATIONS	2-12
TIGHTENING TORQUES GENERAL TIGHTENING TORQUE SPECIFICATIONS ENGINE TIGHTENING TORQUES CHASSIS TIGHTENING TORQUES	2-14 2-14 2-15 2-18
LUBRICATION POINTS AND LUBRICANT TYPES ENGINE CHASSIS	2-21 2-21 2-23
LUBRICATION SYSTEM CHART AND DIAGRAMS ENGINE OIL LUBRICATION CHART LUBRICATION DIAGRAMS	2-25 2-25 2-27
COOLING SYSTEM DIAGRAMS	2-35
CABLE ROUTING	2-39

# GENERAL SPECIFICATIONS

Model	
Model	59C2
Dimensions	
Overall length	2200 mm (86.6 in)
Overall width	775 mm (30.5 in)
Overall height	1420/1475 mm (55.9/58.1 in)
Seat height	800 mm (31.5 in)
Wheelbase	1580 mm (62.2 in)
Ground clearance	125 mm (4.92 in)
Minimum turning radius	2800 mm (110.2 in)
Weight	
Curb weight	221 kg (487 lb)

Curb weight Maximum load 221 kg (487 lb) 194 kg (428 lb)

## EAS20290 ENGINE SPECIFICATIONS

Engine	
Engine type	Liquid cooled 4-stroke, DOHC
Displacement	530 cm <sup>3</sup>
Cvlinder arrangement	Inline 2-cvlinder
Bore × stroke	68.0 × 73.0 mm (2.68 × 2.87 in)
Compression ratio	10.90 : 1
Standard compression pressure (at sea level)	1950 kPa/470 r/min (19.5 kgf/cm <sup>2</sup> /470 r/min.
	282.8 psi/470 r/min)
Minimum-maximum	1700–2180 kPa/470 r/min (17.0–21.8 kgf/cm <sup>2</sup> / 470 r/min, 246.1–316.8 psi/470 r/min)
Starting system	Electric starter
Fuel	
Recommended fuel	Premium unleaded gasoline only
Fuel tank capacity	15.0 L (3.96 US gal, 3.30 Imp.gal)
Fuel reserve amount	3.0 L (0.79 US gal, 0.66 Imp.gal)
Engine oil	
Lubrication system	Dry sump
Becommended brand	
	SAE 10W-30 or SAE 10W-40
Becommended engine oil grade	API service SG type or higher IASO standard
riccommended engine on grade	MA
Engine oil quantity	
Total amount	3.50 L (3.70 US gt, 3.08 Imp.gt)
Without oil filter cartridge replacement	2.70 L (2.85 US at, 2.38 Imp.at)
With oil filter cartridge replacement	2.90 L (3.07 US at. 2.55 Imp.at)
Oil pressure (hot)	120.0 kPa/1200 r/min (1.20 kgf/cm <sup>2</sup> /1200 r/
	min, 17.4 psi/1200 r/min)
Oil filter	
Oil filter type	Cartridge
Qil pump	
Oil nump type	Trochoid
Oil pressure	120 kPa/1200 r/min (1 20 kof/cm <sup>2</sup> /1200 r/min
	17.4 psi/1200 r/min) at 70.0 °C (158.0 °F)
Bypass valve opening pressure	78.0–118.0 kPa (0.78–1.18 kgf/cm <sup>2</sup> , 11.3–17.1 psi)
Relief valve operating pressure	450.0–550.0 kPa (4.50–5.50 kgf/cm <sup>2</sup> , 65.3– 79.8 psi)
Pressure check location	MAIN GALLERY
Cooling system	
Badiator capacity (including all routes)	1 50 L (1 59 US at 1.32 lmp at)
Coolant reservoir canacity (up to the maximum	1.00 E (1.00 00 qt, 1.02 mp.qt)
level mark)	0.27 L (0.29 US at. 0.24 Imp.at)
Radiator cap opening pressure	107.9–137.3 kPa (1.08–1.37 kgf/cm <sup>2</sup> , 15.7– 19.9 psi)
Thermostat	. /
Valve opening temperature	69.0–73.0 °C (156.20–163.40 °F)
Valve full open temperature	85.0 °C (185.00 °F)
Valve lift (full open)	8.0 mm (0.31 in)
<b>v i</b> <i>i</i>	х <i>г</i>

Radiator core Width Height Depth Water pump Water pump type Reduction ratio Impeller shaft tilt limit

### Spark plug(s)

Manufacturer/model Spark plug gap

### Cylinder head

Combustion chamber volume Warpage limit



### Camshaft

Limit

Drive system Camshaft cap inside diameter Camshaft journal diameter Camshaft-journal-to-camshaft-cap clearance Limit Camshaft lobe dimensions Intake A Limit Intake B Limit Exhaust A Limit Exhaust B 329.0 mm (12.95 in) 149.8 mm (5.90 in) 24.0 mm (0.94 in)

Single suction centrifugal pump 23/19 (1.210) 0.15 mm (0.0059 in)

NGK/CR7E 0.7-0.8 mm (0.028-0.031 in)

16.93–17.73 cm<sup>3</sup> (1.03–1.08 cu.in) 0.03 mm (0.0012 in)

Chain drive (left) 23.000–23.021 mm (0.9055–0.9063 in) 22.959–22.972 mm (0.9039–0.9044 in) 0.028–0.062 mm (0.0011–0.0024 in) 0.08 mm (0.0031 in)

32.490–32.590 mm (1.2791–1.2831 in) 32.390 mm (1.2752 in) 24.950–25.050 mm (0.9823–0.9862 in) 24.850 mm (0.9783 in) 32.690–32.790 mm (1.2870–1.2909 in) 32.590 mm (1.2831 in) 24.950–25.050 mm (0.9823–0.9862 in) 24.850 mm (0.9783 in)



Camshaft runout limit



0.030 mm (0.0012 in)

Timing chain Tensioning system

Automatic

# **ENGINE SPECIFICATIONS**

Valve, valve seat, valve guide

Valve clearance (cold) Intake Exhaust Valve dimensions Valve head diameter (intake) Valve head diameter (exhaust)



Valve face width (intake) Valve face width (exhaust)



Valve seat width (intake) Limit Valve seat width (exhaust) Limit

Valve margin thickness (intake) Valve margin thickness (exhaust)



Valve stem diameter (intake) Limit Valve stem diameter (exhaust) Limit Valve guide inside diameter (intake) Limit Valve guide inside diameter (exhaust) Limit Valve-stem-to-valve-guide clearance (intake) Limit Valve-stem-to-valve-guide clearance (exhaust) Limit

Valve stem runout



Valve spring Free length (intake) Limit 0.15–0.22 mm (0.0059–0.0087 in) 0.25–0.32 mm (0.0098–0.0126 in)

25.9–26.1 mm (1.0197–1.0276 in) 21.9–22.1 mm (0.8622–0.8701 in)

1.202–2.475 mm (0.0473–0.0974 in) 1.202–2.475 mm (0.0473–0.0974 in)

0.90–1.10 mm (0.0354–0.0433 in) 1.6 mm (0.06 in) 0.90–1.10 mm (0.0354–0.0433 in) 1.6 mm (0.06 in)

0.50–0.90 mm (0.0197–0.0354 in) 0.50–0.90 mm (0.0197–0.0354 in)

3.975–3.990 mm (0.1565–0.1571 in) 3.945 mm (0.1553 in) 3.960–3.975 mm (0.1559–0.1565 in) 3.930 mm (0.1547 in) 4.000–4.012 mm (0.1575–0.1580 in) 4.050 mm (0.1594 in) 4.050 mm (0.1594 in) 0.010–0.037 mm (0.0004–0.0015 in) 0.080 mm (0.0032 in) 0.025–0.052 mm (0.0010–0.0020 in) 0.100 mm (0.0039 in) 0.040 mm (0.0016 in)

36.73 mm (1.45 in) 34.89 mm (1.37 in) Free length (exhaust) Limit Installed compression spring force (intake)

Installed compression spring force (exhaust)

Installed length (intake) Installed length (exhaust) Spring rate K1 (intake) Spring rate K2 (intake) Spring rate K1 (exhaust) Spring rate K2 (exhaust) Spring tilt (intake) Spring tilt (exhaust)

Winding direction (intake) Winding direction (exhaust)

### Valve lifter

Valve lifter outside diameter (intake) Limit Valve lifter outside diameter (exhaust) Limit

### Cylinder

Bore Wear limit Taper limit Out of round limit

### Piston

Piston-to-cylinder clearance Limit Diameter D Height H



Offset Offset direction Piston pin bore inside diameter Limit Piston pin outside diameter Limit Piston-pin-to-piston-pin-bore clearance 36.73 mm (1.45 in) 34.89 mm (1.37 in) 96.6–111.2 N (9.85–11.34 kgf, 21.72–25.00 lbf) 96.6–111.2 N (9.85–11.34 kgf, 21.72–25.00 lbf) 30.60 mm (1.20 in) 30.60 mm (1.20 in) 16.95 N/mm (1.73 kgf/mm, 96.78 lb/in) 23.19 N/mm (2.36 kgf/mm, 132.41 lb/in) 16.95 N/mm (1.73 kgf/mm, 96.78 lb/in) 23.19 N/mm (2.36 kgf/mm, 132.41 lb/in) 16.95 N/mm (2.36 kgf/mm, 132.41 lb/in) 1.6 mm (0.06 in)

1.6 mm (0.06 in)

Clockwise

Clockwise 24.482–24.488 mm (0.9639–0.9641 in)

24.462–24.466 mm (0.9639–0.9641 m) 24.457 mm (0.9629 in) 24.482–24.488 mm (0.9639–0.9641 in) 24.457 mm (0.9629 in)

68.000–68.010 mm (2.6772–2.6776 in) 68.100 mm (2.6811 in) 0.050 mm (0.0020 in) 0.050 mm (0.0020 in)

0.010–0.035 mm (0.0004–0.0014 in) 0.15 mm (0.0059 in) 67.975–67.990 mm (2.6762–2.6768 in) 9.0 mm (0.35 in)

0.25 mm (0.0098 in) Intake side 16.002–16.013 mm (0.6300–0.6304 in) 16.043 mm (0.6316 in) 15.991–16.000 mm (0.6296–0.6299 in) 15.971 mm (0.6288 in) 0.002–0.022 mm (0.0001–0.0009 in)





Journal oil clearance Bearing color code Journal diameter 0.040–0.082 mm (0.0016–0.0032 in) 1.Blue 2.Black 3.Brown 4.Green 54.984–55.000 mm (2.1647–2.1654 in)

Balancer	
Balancer drive method	Piston
Connecting rod oil clearance	0.036–0.060 mm (0.0014–0.0024 in)
	Wat multiple disc sutematic
Clutch type	Automatic
Frietion plate thicknoon	Automatic $2.02 + 2.08 \text{ mm} (0.115 + 0.121 \text{ in})$
Moor limit	2.92 - 3.00 [[[[[] (0.115 - 0.121 [[])
Vear minit	2.02 IIIIII (0.1110 III)
Plate quantity	0 pcs
Diate questity	1.30–1.50 MM (0.051–0.059 M)
Marpage limit	$5 \mu cs$ 0.10 mm (0.0020 in)
Viai page IIIIII. Clutab plata 2 thicknoop	(0.0039  mm)
Ploto quantity	1.00-2.00 mm ( $0.071-0.079$ m)
Marpage limit	$2 \mu cs$ 0.20 mm (0.0070 in)
Clutch spring free length	(0.20  mm (0.0079  m))
Limit	24.80  mm (0.08  in)
Spring quantity	6 pcc
Clutch damper spring beight	3 50 mm (0 14 in)
Minimum beight	3.30  mm (0.14  m)
Spring quantity	7 pcs
Clutch spring plate beight	4.70  mm (0.19  in)
Minimum beight	4.70  mm (0.13  m)
Spring quantity	1 ncs
V-belt	
V-belt width	32.9 mm (1.30 in)
Limit	31.4 mm (1.24 in)
Transmission	
Iransmission type	
Primary reduction ratio	
Secondary reduction fatio	$0.034 (32/32 \times 30/22 \times 39/20)$
Coor ratio	
Gear fallo Drimony choove weight outside dismotor	$2.041 - 0.750 \cdot 1$
Limit	24.9 - 25.1 11111 (0.90 - 0.99 11) 24.4 mm (0.96 in)
Drive axle rupout limit	24.4 mm (0.90 m) 0.100 mm (0.0030 in)
Socondary shaft runout limit	0.120  mm (0.0039  m)
	0.12011111 (0.0047111)
Air filter	
Air filter element	Oil-coated paper element
Pump type	Electrical
Maximum consumption amperage	1./ A
Output pressure	250.0 kPa (2.50 kgf/cm <sup>2</sup> , 36.3 psi)
Fuel injector	
Model/quantity	0660/2
Resistance	12.0 Ω
Throttle body	
Type/quantity	ACW34-10/1
ID mark	59C1 00

Fuel injection sensor	
Coolant temperature sensor resistance	2.32–2.59 kΩ at 20 °C (68 °F) 310.0–326.0 Ω at 80 °C (176 °F)
Throttle position sensor maximum resistance	2.64–6.16 kΩ
Throttle position sensor resistance	0–6.16 kΩ
Intake air pressure output voltage	3.57–3.71 V at 101.32 kPa
Intake air temperature sensor resistance	5.4–6.6 kΩ at 0 °C (32 °F)
	290–390 Ω at 80 °C (176 °F)
Idling condition	
Engine idling speed	1100–1300 r/min
Intake vacuum	29.3–31.9 kPa (220–239 mmHg, 8.7–9.4 inHg)
Water temperature	85.0–105.0 °C (185.00–221.00 °F)
Oil temperature	60.0–80.0 °C (140.00–176.00 °F)
Throttle grip free play	3.0–5.0 mm (0.12–0.20 in)
Fuel line pressure (at idle)	220–300 kPa (2.20–3.00 kgf/cm <sup>2</sup> , 31.3–42.7 psi)

## EAS20300 CHASSIS SPECIFICATIONS

Chassis	
Frame type	Diamond
Caster angle	25.00°
Trail	92 mm (3.6 in)
Front wheel	
Wheel type	Cast wheel
Rim size	15M/C × MT3.50
Rim material	Aluminum
Wheel travel	120.0 mm (4.72 in)
Radial wheel runout limit	1.0 mm (0.04 in)
Lateral wheel runout limit	0.5 mm (0.02 in)
Wheel axle bending limit	0.25 mm (0.01 in)
Wheel sensor rotor deflection limit	0.15 mm (0.0059 in)
Rear wheel	
Wheel type	Cast wheel
Rim size	$15M/C \times MT5.00$
Rim material	Aluminum
Wheel travel	116.0 mm (4.57 in)
Radial wheel runout limit	1.0 mm (0.04 in)
Lateral wheel runout limit	0.5 mm (0.02 in)
Wheel axle bending limit	0.25 mm (0.01 in)
Wheel sensor rotor deflection limit	0.15 mm (0.0059 in)
Front tire	
Туре	Tubeless
Size	120/70R15 M/C 56H
Manufacturer/model	DUNLOP/GPR-100F
Manufacturer/model	BRIDGESTONE/BT011F
Wear limit (front)	1.6 mm (0.06 in)
Rear tire	
Туре	Tubeless
Size	160/60R15 M/C 67H
Manufacturer/model	DUNLOP/GPR-100L
Manufacturer/model	BRIDGESTONE/BT012R
vvear limit (rear)	1.6 mm (0.06 in)
Tire air pressure (measured on cold tires)	
Loading condition	U-90 kg (U-198 lb)
Front	$225 \text{ kPa} (2.25 \text{ kgf/cm}^2, 33 \text{ psi})$
Rear Leading anglitics	250 kPa (2.50 kgt/cm <sup>2</sup> , 36 psi)
Loading condition	90–194 Kg (198–428 lD) 205 kBa (2.05 kat/am², 22 pai)
FIOIL Roar	225 KPa (2.25 Kyi/cm <sup>2</sup> , 35 $\mu$ si) 280 kPa (2.80 kaf/cm <sup>2</sup> , 41 nsi)
	200 KFa (2.00 Kgi/chi+, 41 psi)
Front brake	Dual dias broks
iype Operation	Dual disc brake
Operation Front disc brake	Right hand operation
Diso outsido diamator y thickness	$267.0 \times 1.0 \text{ mm} (10.51 \times 0.16 \text{ m})$
Brake disc thickness limit	$207.0 \times 4.0$ IIIIII (10.31 × 0.10 III) 3.5 mm (0.11 in)
Brake disc deflection limit	0.5  mm (0.14  m) 0.15 mm (0.0059 in)

# **CHASSIS SPECIFICATIONS**

Brake pad lining thickness (inner) Limit Brake pad lining thickness (outer) Limit Master cylinder inside diameter Caliper cylinder inside diameter Specified brake fluid	4.0 mm (0.16 in) 0.5 mm (0.02 in) 4.0 mm (0.16 in) 0.5 mm (0.02 in) 15.00 mm (0.59 in) 30.23 mm (1.19 in) 27.00 mm (1.06 in) DOT 4
Rear brake	
Type Operation Rear disc brake Disc outside diameter × thickness Brake disc thickness limit Brake disc deflection limit Brake pad lining thickness (inner) Limit Brake pad lining thickness (outer) Limit Master cylinder inside diameter Caliper cylinder inside diameter Specified brake fluid	Single disc brake Left hand operation $282.0 \times 5.0 \text{ mm} (11.10 \times 0.20 \text{ in})$ 4.5  mm (0.18  in) 0.15  mm (0.0059  in) 8.0  mm (0.31  in) 0.8  mm (0.03  in) 8.0  mm (0.31  in) 0.8  mm (0.03  in) 14.0  mm (0.55  in) 38.10  mm (1.50  in) DOT 4
<b>Rear brake lock</b> Rear brake lock pad Brake pad lining thickness Limit Rear brake lock cable length	3.0 mm (0.12 in) 0.8 mm (0.03 in) 43–45 mm (1.69–1.77 in)
Steering	
Steering Steering bearing type Center to lock angle (left) Center to lock angle (right)	Angular bearing 38.5° 38.5°
Front suspension Type Spring/shock absorber type Front fork travel Fork spring free length Limit Collar length Fork spring installed length Spring rate K1 Spring stroke K1 Inner tube outer diameter Inner tube bending limit Optional spring available Recommended oil Quantity Level	Telescopic fork Coil spring/oil damper 120.0 mm (4.72 in) 303.9 mm (11.96 in) 297.8 mm (11.72 in) 195.0 mm (7.68 in) 284.9 mm (11.22 in) 16.28 N/mm (1.66 kgf/mm, 92.96 lb/in) 0.0-120.0 mm (0.00-4.72 in) 43.0 mm (1.69 in) 0.2 mm (0.01 in) No Fork oil 10W or equivalent 517.0 cm <sup>3</sup> (17.48 US oz, 18.23 Imp.oz) 87.0 mm (3.43 in)
Rear suspension	
Type Spring/shock absorber type Rear shock absorber assembly travel Spring free length	Swingarm Coil spring/gas-oil damper 43.0 mm (1.69 in) 191.2 mm (7.53 in)

**2-10** 

Spring installed length	180.0  mm (7.09  in)
Spring rate K1	225.60 N/mm (23.00 kgf/mm, 1288.18 lb/ln)
Spring rate K2	294.00 N/mm (29.98 kgf/mm, 1678.74 lb/in)
Spring stroke K1	0.0–28.8 mm (0.00–1.13 in)
Spring stroke K2	28.8–43.0 mm (1.13–1.69 in)
Optional spring available	No
Enclosed gas/air pressure (STD)	4900 kPa (49.0 kgf/cm², 696.9 psi)
Swingarm	
Swingarm end free play limit (radial)	1.0 mm (0.04 in)
Swingarm end free play limit (axial)	1.0 mm (0.04 in)
Drive belt	

Drive belt slack (scale position)

13.4

#### EAS20310 ELECTRICAL SPECIFICATIONS Voltage System voltage 12 V Ignition system Ignition system TCI Advancer type Digital Ignition timing (B.T.D.C.) 5.0°/1200 r/min TCI 248-372 Ω (Gy-B) Crankshaft position sensor resistance Ignition coil Minimum ignition spark gap 6.0 mm (0.24 in) Primary coil resistance 1.87-2.53 Ω Secondary coil resistance 12.00–18.00 kΩ Spark plug cap Material Resin Resistance 7.5–12.5 kΩ AC magneto 14.0 V, 25.0 A at 5000 r/min Standard output Standard output 14.0 V, 350 W at 5000 r/min Stator coil resistance 0.224-0.336 Ω (W-W) **Rectifier/regulator** Regulator type Semi conductor-short circuit Regulated voltage (DC) 14.1-14.9 V 22.0 A Rectifier capacity (DC) Battery Model YTZ12S Voltage, capacity 12 V, 11.0 Ah Specific gravity 1.310 Manufacturer **GS YUASA** Ten hour rate amperage 1.10 A Headlight Bulb type Halogen bulb Bulb voltage, wattage × quantity Headlight 12 V, 55 W × 2 Auxiliary light 12 V, 5.0 W $\times$ 1 Tail/brake light LED Front turn signal light 12 V, 21.0 W $\times$ 2 Rear turn signal light 12 V, 21.0 W × 2 License plate light 12 V, 5.0 W × 1 Meter lighting LED Indicator light Turn signal indicator light $LED \times 2$ High beam indicator light LED Engine trouble warning light LED ABS warning light LED Immobilizer system indicator light LED

Electric starting system System type	Constant mesh		
Starter motor			
Power output	0 70 kW		
Armature coil commutator resistance	0.0100-0.0200.0		
Armature coil insulation resistance	$\frac{1}{2}$		
Brush overall length	12.0  mm (0.47  in)		
Limit	650  mm (0.26  in)		
Brush spring force	6.02-6.51 N ( $614-664$ of $21.65-23.41$ oz)		
Mica undercut (denth)	$0.02 \ 0.01 \ R \ (0.04 \ 0.04 \ gl, 21.03 \ 20.41 \ 02)$		
Starter relay			
Amperage	180.0 A		
Coil resistance	4.18–4.62 Ω		
Horn			
Horn type	Plane		
Quantity	1 pcs		
Maximum amperage	3.0 A		
Coil resistance	1.06–1.11 Ω		
Turn signal/hazard relay			
Relay type	Full transistor		
Built-in, self-canceling device	No		
Fuel sender unit			
Sender unit resistance (full)	4 0-10 0 0		
Sender unit resistance (ruii)	4.0-10.0 S2 93 0-100 0 0		
	30.0-100.0 32		
Fuses			
Main fuse	40.0 A		
Headlight fuse	20.0 A		
Signaling system fuse	15.0 A		
Ignition fuse	7.5 A		
Radiator fan fuse	15.0 A		
Parking lighting fuse	10.0 A		
Fuel injection system fuse	7.5 A		
ABS motor fuse	30.0 A		
ABS control unit fuse	5.0 A		
ABS solenoid fuse	20.0 A		
Backup fuse	7.5 A		
Spare fuse	40.0 A		
Spare fuse	30.0 A		
Spare fuse	20.0 A		
Spare fuse	15.0 A		
Spare fuse	10.0 A		
Spare fuse	7.5 A		
Spare fuse	5.0 A		

#### EAS20320 TIGHTENING TORQUES

#### EAS20331

### GENERAL TIGHTENING TORQUE SPECIFI-CATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



- A. Distance between flats
- B. Outside thread diameter

A (nut)	B (bolt)	General tightening torques			
		Nm	m⋅kgf	ft∙lbf	
10 mm	6 mm	6	0.6	4.3	
12 mm	8 mm	15	1.5	11	
14 mm	10 mm	30	3.0	22	
17 mm	12 mm	55	5.5	40	
19 mm	14 mm	85	8.5	61	
22 mm	16 mm	130	13.0	94	

#### EAS20340 ENGINE TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Camshaft cap bolt	M6	12	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-C
Engine oil check bolt	M8	1	15 Nm (1.5 m·kgf, 11 ft·lbf)	
Exhaust pipe stud bolt	M8	4	15 Nm (1.5 m·kgf, 11 ft·lbf)	
Cylinder head nut	M9	6	See TIP.	-E
Cylinder head bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Cylinder bolt	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Spark plug	M10	2	13 Nm (1.3 m·kgf, 9.4 ft·lbf)	
Cylinder head cover bolt	M6	10	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Timing chain tensioner rod accessing plug	M20	1	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	
Cylinder stud bolt	M9	6	13 Nm (1.3 m·kgf, 9.4 ft·lbf)	See TIP.
Connecting rod nut	M7	4	See TIP.	ļ
Balancer connecting rod nut	M9	2	60 Nm (6.0 m·kgf, 43 ft·lbf)	<u>I</u>
Balancer cylinder bolt	M10	4	58 Nm (5.8 m·kgf, 42 ft·lbf)	-6
Generator rotor nut	M18	1	See TIP.	-C
Timing chain tensioner bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Timing chain guide (intake side) bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-6
Water pump housing cover bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Water pump assembly bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Water pump inlet and outlet pipes bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Thermostat cover bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Coolant pipe bolt	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Coolant drain bolt	M12	1	1.6 Nm (0.16 m·kgf, 1.2 ft·lbf)	
Oil pump bolt	M6	3	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Oil strainer bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	¢
Oil filter cartridge union bolt	M20	1	63 Nm (6.3 m·kgf, 46 ft·lbf)	
Oil filter cartridge	M20	1	17 Nm (1.7 m·kgf, 12 ft·lbf)	
Oil delivery pipe bolt	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-0
Intake manifold bolt	M6	4	14 Nm (1.4 m·kgf, 10 ft·lbf)	
Intake manifold joint clamp	M5	2	3.0 Nm (0.30 m·kgf, 2.2 ft·lbf)	
Throttle body joint clamp	M5	2	3.0 Nm (0.30 m·kgf, 2.2 ft·lbf)	
Air filter case bolt	M6	2	9 Nm (0.9 m⋅kgf, 6.5 ft⋅lbf)	
Exhaust assembly nut (front)	M8	4	20 Nm (2.0 m·kgf, 14 ft·lbf)	
Exhaust assembly nut (rear)	M10	1	31 Nm (3.1 m·kgf, 22 ft·lbf)	
Crankcase bolt	M6	5	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	L = 35 mm (1.38 in)
Crankcase bolt	M6	8	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	L = 50 mm (1.97 in)
Crankcase bolt	M8	8	24 Nm (2.4 m·kgf, 17 ft·lbf)	

# **TIGHTENING TORQUES**

ltem	Thread size	Q'ty	Tightening torque	Remarks
Engine oil pressure check point plug	M20	1	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	
Engine oil check bolt	M8	1	20 Nm (2.0 m·kgf, 14 ft·lbf)	
Engine oil drain bolt	M14	1	43 Nm (4.3 m·kgf, 31 ft·lbf)	
Oil tank bolt	M6	7	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Stator coil base screw	M6	3	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	-6
Timing mark accessing plug	M16	1	8 Nm (0.8 m·kgf, 5.8 ft·lbf)	
Generator cover bolt	M6	19	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Outer V-belt case bolt	M6	4	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Outer V-belt case bolt	M8	6	24 Nm (2.4 m·kgf, 17 ft·lbf)	
Inner V-belt case plate bolt	M6	3	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Inner V-belt case bolt	M8	1	18 Nm (1.8 m·kgf, 13 ft·lbf)	L = 25 mm (0.98 in)
Inner V-belt case bolt	M8	1	24 Nm (2.4 m·kgf, 17 ft·lbf)	
Outer V-belt case nut	M6	1	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Crankshaft end access cover screw	M6	3	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
V-belt case air filter case screw	M6	3	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Generator cover protector screw	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
V-belt case air filter case cover screw	M6	2	7 Nm (0.7 m⋅kgf, 5.1 ft⋅lbf)	
Generator cover protector cover screw	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
V-belt case air filter element (left) bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
V-belt case air duct joint clamp	M4	1	3.0 Nm (0.30 m⋅kgf, 2.2 ft⋅lbf)	
V-belt case air filter element joint clamp	M4	1	3.0 Nm (0.30 m·kgf, 2.2 ft·lbf)	
Starter clutch bolt	M8	3	30 Nm (3.0 m·kgf, 22 ft·lbf)	-6
Clutch assembly nut	M16	1	65 Nm (6.5 m·kgf, 47 ft·lbf)	
Clutch boss nut	M48	1	130 Nm (13 m·kgf, 94 ft·lbf)	
Bearing housing bolt	M8	3	30 Nm (3.0 m·kgf, 22 ft·lbf)	
Primary sheave nut	M20	1	160 Nm (16 m·kgf, 116 ft·lbf)	Shell Sun- light Grease 3®
Secondary sheave nut	M18	1	90 Nm (9.0 m·kgf, 65 ft·lbf)	YAMAHA GREASE "H" or Polyurea Grease®
Secondary sheave spring seat nut	M36	1	90 Nm (9.0 m·kgf, 65 ft·lbf)	
Crankshaft right end bearing retainer screw	M6	1	11 Nm (1.1 m·kgf, 8.0 ft·lbf)	-6

# **TIGHTENING TORQUES**

Item	Thread size	Q'ty	Tightening torque	Remarks
Secondary shaft bearing retainer bolt	M6	2	12 Nm (1.2 m·kgf, 8.7 ft·lbf)	-0
Stator coil bolt	M6	3	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-15
Crankshaft position sensor bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	-6
Starter motor bolt	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
O <sub>2</sub> sensor	M18	1	45 Nm (4.5 m⋅kgf, 33 ft⋅lbf)	
Coolant temperature sensor	M12	1	18 Nm (1.8 m·kgf, 13 ft·lbf)	

### TIP\_

### Cylinder head nut

- 1. Tighten the nuts to 10 Nm (1.0 m·kgf, 7.2 ft·lbf).
- 2. Tighten the nuts to 20 Nm (2.0 m·kgf, 14 ft·lbf).
- 3. Tighten the nuts further to reach the specified angle 120°.

#### TIP\_

### Cylinder head stud bolt

• The tightening torque is for reference only. Install the cylinder head stud bolt so that it protrudes 150.2–152.2 mm (5.91–5.99 in) from the crankcase.

#### TIP.

### Connecting rod nut

• Tighten the connecting rod nuts to 16 Nm (1.6 m·kgf, 12 ft·lbf), and then tighten them further to reach the specified angle 90°.

### TIP\_

### Generator rotor nut

• Tighten the generator rotor nuts to 65 Nm (6.5 m·kgf, 47 ft·lbf), and then tighten them further to reach the specified angle 120°.

### Cylinder head tightening sequence:


#### EAS20350 CHASSIS TIGHTENING TORQUES

Item	Thread size	Q'ty	Tightening torque	Remarks
Engine mounting nut (front upper side)	M12	1	88 Nm (8.8 m·kgf, 64 ft·lbf)	
Engine mounting bolt (front lower side)	M10	4	45 Nm (4.5 m·kgf, 33 ft·lbf)	-6
Engine mounting nut (rear side)	M12	1	105 Nm (10.5 m·kgf, 76 ft·lbf)	
Rear frame bolt	M12	2	83 Nm (8.3 m·kgf, 60 ft·lbf)	-6
Front cowling stay bolt	M10	2	48 Nm (4.8m·kgf, 35 ft·lbf)	
Battery box bolt (lower)	M8	1	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Battery box bolt (upper and cen- ter)	M6	2	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Battery box bolt (air cleaner bracket)	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Footboard bracket bolt (front side)	M8	4	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Radiator bracket bolt	M8	4	30 Nm (3.0 m·kgf, 22 ft·lbf)	<u> </u>
Main switch/immobilizer unit screw	M8	2	23 Nm (2.3 m·kgf, 17 ft·lbf)	-5
Muffler stay nut	M10	1	32 Nm (3.2 m·kgf, 23 ft·lbf)	
Fuel tank bracket bolt	M6	4	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Pivot shaft	M22	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Pivot shaft nut	M22	1	100 Nm (10 m·kgf, 72 ft·lbf)	
Rear shock absorber assembly rear nut	M12	1	53 Nm (5.3 m·kgf, 38 ft·lbf)	
Rear shock absorber assembly front bolt	M16	1	68 Nm (6.8 m·kgf, 49 ft·lbf)	
Swingarm bolt	M10	3	40 Nm (4.0 m·kgf, 29 ft·lbf)	
Drive pulley assembly bolt	M10	5	48 Nm (4.8 m⋅kgf, 35 ft⋅lbf)	L = 25 mm (0.98 in), L = 90 mm (3.54 in)
Drive belt guard bolt	M6	4	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Swingarm cover bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Holder cover bolt	M6	3	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Upper bracket pinch bolt	M8	2	30 Nm (3.0 m·kgf, 22 ft·lbf)	
Lower bracket pinch bolt	M8	4	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Front fork cap bolt	M40	2	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Damper rod assembly bolt	M10	2	30 Nm (3.0 m·kgf, 22 ft·lbf)	-6
Steering stem nut	M28	1	115 Nm (11.5 m·kgf, 83 ft·lbf)	
Lower ring nut	M30	1	See TIP.	
Upper handlebar holder bolt	M8	4	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Lower handlebar holder nut	M10	2	34 Nm (3.4 m·kgf, 25 ft·lbf)	
Brake hose union bolt (master cylinder side)	M10	2	30 Nm (3.0 m⋅kgf, 22 ft⋅lbf)	
Brake master cylinder holder bolt	M6	4	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	

Item	Thread size	Q'ty	Tightening torque	Remarks
Brake master cylinder cap screw	M4	4	1.5 Nm (0.15 m·kgf, 1.1 ft·lbf)	
Grip end	M16	2	26 Nm (2.6 m·kgf, 19 ft·lbf)	
Throttle cable bolt	M5	2	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Throttle cable adjusting locknut	M8	1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Brake hose union bolt (Brake joint side)	M10	2	30 Nm (3.0 m·kgf, 22 ft·lbf)	
Fuel tank bolt	M6	2	9 Nm (0.9 m·kgf, 6.5 ft·lbf)	
Fuel tank nut	M6	2	9 Nm (0.9 m·kgf, 6.5 ft·lbf)	
Fuel pump bolt	M5	6	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Fuel rail screw	M5	2	2 3.5 Nm (0.35 m·kgf, 2.5 ft·lbf)	
Storage box bolt	M6	10	) 10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Seat lock bolt	M6	4	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Grab bar bolt	M8	4	16 Nm (1.6 m·kgf, 12 ft·lbf)	
Side cover bolt (front side)	M6	4	1.5 Nm (0.15 m·kgf, 1.1 ft·lbf)	
Front cowling bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Head light bolt	M6	4	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Footboard bolt	M6	6	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Footboard bolt (rear upper of right side)	M6	1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	-6
Headlight bolt (center)	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front turn signal light bolt	M6	2	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Windshield screw	M5	4	0.5 Nm (0.05 m·kgf, 0.36 ft·lbf)	
Windshield stay bolt	M6	4	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Side cover bolt (rear side)	M6	2	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Storage compartment bolt	M6	1	4.0 Nm (0.40 m·kgf, 2.9 ft·lbf)	
Recovery tank bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front fender bolt (hexagon socket bolt)	M6	4	10 Nm (1.0 m·kgf, 7.2 ft·lbf)	
Front fender bolt (flange bolt)	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front wheel axle	M18	1	72 Nm (7.2 m·kgf, 52 ft·lbf)	
Rear wheel axle nut	M24	1	160 Nm (16 m·kgf, 116 ft·lbf)	
Lower bracket pinch bolt	M8	4	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Front wheel axle pinch bolt	M8	1	20 Nm (2.0 m·kgf, 14 ft·lbf)	
Drive belt adjusting locknut	M8	2	16 Nm (1.6 m·kgf, 12 ft·lbf)	
Front brake caliper bolt	M10	4	40 Nm (4.0 m·kgf, 29 ft·lbf)	
Rear brake caliper bolt	M10	2	27 Nm (2.7 m·kgf, 20 ft·lbf)	
Front brake disc bolt	M8	10	23 Nm (2.3 m·kgf, 17 ft·lbf)	-0
Rear brake disc bolt	M8	5	30 Nm (3.0 m·kgf, 22 ft·lbf)	-6
Front brake hose union bolt (cali- per side)	M10	2	30 Nm (3.0 m·kgf, 22 ft·lbf)	
Rear brake hose union bolt (cali- per side)	M10	1	30 Nm (3.0 m·kgf, 22 ft·lbf)	
Front brake caliper bleed screw	M8	2	5 Nm (0.5 m·kgf, 3.6 ft·lbf)	
Rear brake caliper bleed screw	M7	1	6 Nm (0.6 m kgf, 4.3 ft lbf)	

Item	Thread size	Q'ty	Tightening torque	Remarks
Front wheel sensor bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Rear wheel sensor bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Rear brake lock caliper bolt	M8	2	23 Nm (2.3 m·kgf, 17 ft·lbf)	
Rear brake lock caliper slide pin bolt	M8	1	17 Nm (1.7 m·kgf, 12 ft·lbf)	
Rear brake lock caliper bracket bolt	M8	1	22 Nm (2.2 m·kgf, 16 ft·lbf)	
Rear brake lock caliper piston locknut	M16	1	22 Nm (2.2 m·kgf, 16 ft·lbf)	Left-hand thread.
Rear brake lock adjusting nut	M8	1	15 Nm (1.5 m·kgf, 11 ft·lbf)	
Front brake hose joint nut	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front brake hose holder bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Rear brake hose guide bolt	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Rear brake hose holder bolt	M6	4	10 Nm (1.0 m⋅kgf, 7.2 ft⋅lbf)	
Rear brake lock cable holder bolt	M6	1	10 Nm (1.0 m⋅kgf, 7.2 ft⋅lbf)	
Rear brake hose holder bolt (rear left footrest)	M6	1	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Front wheel sensor rotor bolt	M5	3	8 Nm (0.8 m·kgf, 5.8 ft·lbf)	-6
Rear wheel sensor rotor bolt	M5	5	8 Nm (0.8 m·kgf, 5.8 ft·lbf)	-5
Centerstand bracket nut	M10	4	55 Nm (5.5 m·kgf, 40 ft·lbf)	
Centerstand nut	M10	2	55 Nm (5.5 m·kgf, 40 ft·lbf)	
Sidestand nut	M10	1	65 Nm (6.5 m·kgf, 47 ft·lbf)	
Rear footrest bracket bolt	M8	4	30 Nm (3.0 m·kgf, 22 ft·lbf)	
Lean angle sensor bolt	M4	2	1.5 Nm (0.15 m·kgf, 1.1 ft·lbf)	
Starter relay lead bolt	M6	2	3.6 Nm (0.36 m·kgf, 2.6 ft·lbf)	
Sidestand switch nut	M5	2	3.8 Nm (0.38 m⋅kgf, 2.8 ft⋅lbf)	
Intake air pressure sensor bolt	M5	1	3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)	
Ambient temperature sensor bolt	M5	1	3.8 Nm (0.38 m⋅kgf, 2.8 ft⋅lbf)	
Throttle position sensor screw	M5	2	3.5 Nm (0.35 m⋅kgf, 2.5 ft⋅lbf)	
ECU (engine control unit) nut	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Hydraulic unit assembly bracket bolt	M8	2	16 Nm (1.6 m·kgf, 12 ft·lbf)	
Hydraulic unit assembly and hydraulic unit assembly bracket bolt	M6	3	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Brake hose flare nut	M10	4	16 Nm (1.6 m·kgf, 12 ft·lbf)	
Damper mount bolt nut	M8	3	16 Nm (1.6 m·kgf, 12 ft·lbf)	
Brake joint assembly bolt	M6	2	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	
Damper cap bolt	M6	3	7 Nm (0.7 m·kgf, 5.1 ft·lbf)	

# TIP\_\_\_\_\_

### Lower ring nut

1. First, tighten the lower ring nut approximately 52 Nm (5.2 m·kgf, 38 ft·lbf) by using the ring nut wrench and turn the steering right and left a few times, then loosen the lower ring nut completely.

2. Retighten the lower ring nut 14 Nm (1.4 m·kgf, 10 ft·lbf).

# LUBRICATION POINTS AND LUBRICANT TYPES

#### EAS20370 ENGINE

Lubrication point	Lubricant
Oil seal lips	
O-rings	
Coolant hose insertion part	Water or silicone fluid
Bearings and bushings	- <b>E</b>
Cylinder head nut seats and washers	- <b>E</b>
Camshaft cap bolt seats	<b>_</b>
Crankshaft big ends	
Piston surfaces	- <b>E</b>
Piston pins	- <b>E</b>
Crankshaft journals	<b>—E</b>
Balancer piston surface	<b>–</b> E
Balancer piston pin	<b>—E</b>
Generator rotor nut	<b>—E</b>
Camshaft lobes and journals (intake and exhaust)	
Valve stem seals (intake and exhaust)	Silicone fluid
Valve stems and stem ends (intake and exhaust)	
Valve lifter outer surface (intake and exhaust)	
Water pump impeller shaft	
O-ring (coolant pipe)	-€s> or silicone fluid
Oil pump shaft and rotors (inner and outer)	<b>—</b> (E)
Oil pump gaskets	
V-belt case air filter case screw bushing	Water
V-belt case air filter case cover screw bushing	Water
Crankshaft end access cover screw bushing	Water or silicone fluid
Generator cover protector cover screw bushing	Water or silicone fluid
Generator cover protector screw bushing	Water or silicone fluid
Starter clutch idle gear inner surface	
Starter clutch idle gear shaft	
Starter clutch and starter clutch gear	
Primary driven gear spline and main axle spline	
1st pinion gear spline and main axle spline	
1st wheel gear spline and drive axle spline	
Primary sheave spacer and o-ring	Shell Sunlight grease 3®
Primary sheave nut	Shell Sunlight grease 3®
Secondary sheave nut	YAMAHA GREASE "H" or Polyurea Grease®

# LUBRICATION POINTS AND LUBRICANT TYPES

Lubrication point	Lubricant
Secondary shaft right end bearing	
Pivot shaft taper roller bearing	
Crankcase mating surface	Yamaha bond No.1215 (Three bond No.1215®)
Inner V-belt case seal mating surface	Yamaha bond No.1215 (Three bond No.1215®)
Crankshaft position sensor/stator lead grommet	Yamaha bond No.1215 (Three bond No.1215®)

#### EAS20380 CHASSIS

Lubrication point	Lubricant
Steering bearings (upper and lower)	
Upper bearing cover seal lip and lower bearing dust seal lip	
Tube guide (throttle grip) inner surface and throttle cables	
Rear brake lock cable end (lever end)	YAMAHA GREASE "F"
Brake lever pivoting point and metal-to-metal moving parts	
Drive axle spline	YAMAHA GREASE "H" or Polyurea Grease®
Drive pulley assembly pivoting point	YAMAHA GREASE "H" or Polyurea Grease®
Rear shock absorber assembly bearing inner surface	
Rear shock absorber assembly spacer and collar	
Pivot shaft oil seal and collar	
Rear shock absorber assembly front bolt seats	
Seat lock metal-to-metal moving parts	
Seat hinge metal-to-metal moving parts	
Seat lock cable	
Passenger footrest pivoting point	
Centerstand pivoting point and metal-to-metal moving parts	
Centerstand hook and spring contact point	
Sidestand pivoting point and metal-to-metal moving parts	
Sidestand hook and spring contact point	
Front wheel oil seal lip	
Rear wheel oil seal lip	
Fuel lid pivoting point	

# LUBRICATION SYSTEM CHART AND DIAGRAMS

EAS20400 ENGINE OIL LUBRICATION CHART



- 1. Intake camshaft
- 2. Exhaust camshaft
- 3. Timing chain tensioner
- 4. Connecting rod
- 5. To piston
- 6. Starter clutch gear
- 7. Crankshaft
- 8. Balancer connecting rod
- 9. To balancer piston
- 10.Oil pipe
- 11.Check valve
- 12.Relief valve
- 13.Oil filter
- 14.Oil cooler
- 15.Oil tank
- 16.Oil strainer
- 17.Feed pump
- 18.Delivery pipe
- 19.Scavenge pump
- 20.Oil strainer
- 21.To starter idle gear
- 22.Clutch
- 23.Secondary shaft
- 24. To transmission

#### EAS20410 LUBRICATION DIAGRAMS



- 1. Exhaust camshaft
- 2. Intake camshaft
- 3. Delivery pipe
- 4. Oil pump assembly
- 5. Scavenge pump
- 6. Feed pump
- 7. Oil pipe
- 8. Oil cooler
- 9. Oil filter
- 10.Relief valve
- 11.Check valve



- 1. Crankshaft
- 2. Secondary shaft
- 3. Drive axle
- 4. Clutch
- 5. Generator cover



- 1. Oil strainer
- 2. Intake camshaft
- 3. Exhaust camshaft





- 1. Generator cover
- 2. Oil strainer
- 3. Main gallery
- 4. Right crankcase
- A. Forward







- 1. Radiator cap
- 2. Radiator filler hose
- 3. Radiator inlet hose
- 4. Cooling system air bleed hose
- 5. Coolant pipe
- 6. Thermostat outlet hose
- 7. Oil cooler outlet hose
- 8. Thermostat
- 9. Oil cooler
- 10.Coolant hose
- 11.Water pump inlet pipe
- 12.Water pump outlet pipe
- 13.Oil cooler inlet hose
- 14.Radiator outlet hose
- 15.Coolant reservoir hose
- 16.Fast idle plunger outlet coolant hose
- 17.Coolant reservoir
- 18. Coolant reservoir breather hose
- 19.Radiator
- 20.Water pump



- 1. Thermostat
- 2. Thermostat outlet hose
- 3. Cooling system air bleed hose
- 4. Radiator cap
- 5. Radiator filler pipe
- 6. Radiator filler hose
- 7. Coolant reservoir hose
- 8. Radiator
- 9. Radiator inlet hose
- 10.Coolant pipe
- 11.Oil cooler
- 12.Oil cooler outlet hose

### EAS20430 CABLE ROUTING Handlebar (top side view)



- 1. Front brake hose (hydraulic unit to front brake hose joint)
- 2. Lead holder
- 3. Cap bolt cover
- 4. Front brake master cylinder
- 5. Right handlebar switch
- 6. Front brake hose (front brake master cylinder to hydraulic unit)
- 7. Right handlebar switch lead
- 8. Left handlebar switch lead
- 9. Left handlebar switch
- 10.Rear brake master cylinder
- 11.Rear brake hose (rear brake master cylinder to hydraulic unit)
- 12.Throttle cable
- 13.Throttle body
- 14.Horn lead
- 15.Brake hose bracket
- A. Route the brake hose so that the opening faces outside of the vehicle.
- B. Adjust the free play of the accelerator grip so that the free play is 3 to 5 mm (0.12 to 0.20 in) when measured at the outer circumference of the rim.
- C. Tighten the union bolt, pushing the brake pipe against the guide wire.
- D. Apply grease to the cable end and tube guide when installing the throttle cable. Apply a pea-sized amount (approx. 0.2 g (0.007 oz)) of grease to the cable end.
- E. Adjust the free play of the throttle grip. After tightening the nuts, make sure to cover with rubber cover.
- F. When installing the throttle cable to the vehicle, route the cables on the pull side and return side carefully, so that the cables do not get twisted or return by itself.
- G. Face the opening of the lead holder to the bottom of the vehicle.

# Handlebar (front side and left side view)



- 1. Right handlebar switch
- 2. Front brake master cylinder
- 3. Right handlebar switch lead
- 4. Front brake hose (front brake master cylinder to hydraulic unit)
- 5. Rear brake hose (rear brake master cylinder to hydraulic unit)
- 6. Left handlebar switch lead
- 7. Rear brake master cylinder
- 8. Left handlebar switch
- 9. Rear brake lock cable
- 10. Front brake pipe/joint assembly
- 11.Horn lead
- 12.Lead holder
- 13.Cap bolt cover
- 14. Front brake hose (hydraulic unit to front brake hose joint)
- 15.Throttle cables
- 16.Handlebar
- A. Route the right handlebar switch lead in front of the throttle cables and through the upper bracket forward.
- B. Route the left handlebar switch lead in front of the rear brake lock cable and through the upper bracket forward.
- C. Pass the brake pipe between the projections.
- D. Install the rear brake hose so that the yellow paint mark on the pipe faces to the front of the vehicle.
- E. Route the rear brake lock cable behind the handlebar switch leads and throttle cables.
- F. Pass the brake hoses through the guide wire.
- G. Route the throttle cables behind the handlebar switch leads and front of the rear brake lock cable.
- H. Install the front brake hose so that the white paint mark on the pipe faces to the front of the vehicle.
- I. Connect the wire harness of the front and rear brake switch connectors from inside the vehicle.
- J. Install the brake pipe against the projection.
- K. Install the rear brake lock cable after rotating the rear brake lock lever to the position shown in the illustration.
- L. Apply YAMAHA GREASE "F" to the end of the rear brake lock cable and install it.



Front brake (front side and left side view)

2-43

- 1. Holder
- 2. Brake hose
- 3. Lower bracket cover
- 4. Horn
- 5. Horn lead
- 6. Grommet
- 7. Front fork
- 8. Front wheel sensor lead
- 9. Front brake hose holder
- 10.Cable guide
- 11.Front brake caliper
- 12.Front wheel sensor
- A. Fasten at a position 0 to 5 mm (0 to 0.20 in) from the protector end of the brake hose.
- B. Route the horn lead along the brake hose. Make sure that there is no slack in the lead.
- C. Fasten at a position 0 to 5 mm (0 to 0.20 in) from the bending part of the brake hose.
- D. Route the front wheel sensor lead in front of the brake hose and horn lead.
- E. Pass the front wheel sensor lead through the hole in the lower bracket cover.
- F. 10–20 mm (0.39–0.79 in)
- G. Fasten the front wheel sensor lead at the end of the plastic tape.
- H. Insert the brake hose joint into the stopper claw of the horn bracket.
- I. Insert the horn lead coupler. Install the black lead to the bracket side (bottom).
- Install the horn bracket, aligning the projection of the horn bracket with the groove of the horn.
- K. 0–5 mm (0–0.20 in)
- L. Face the holder opening to the rear of the vehicle.
- M. Bring the both ends of the white tape on the horn lead into position between brake hose grommet flanges.
- N. White tape
- O. Between brake hose grommet flanges
- P. Face the holder opening to the front of the vehicle.
- Q. Front of the vehicle
- R. Route the horn lead between the holders under the brake hose. Both routes shown in the illustration are acceptable.
- S. 70–80 mm (2.76–3.15 in)
- T. Only the left side, fasten the grommet part of the front wheel sensor.
- U. Route the front wheel sensor lead inside of the brake hose.
- V. Tighten the union bolts, pushing the brake pipe against the projection of the brake caliper.
- W. Pass the front wheel sensor lead through the cable guide.

X. Route the front wheel sensor lead between the front brake caliper and the outer tube.

# Frame (front side view)



- 1. Meter lead
- 2. Ambient temperature sensor lead
- 3. ABS ECU coupler
- 4. Fuse box (left)
- 5. Fuse box lead
- 6. Lean angle sensor lead
- 7. ECU (engine control unit) lead
- 8. Hydraulic unit assembly
- 9. Wire harness
- 10.Handlebar switch lead
- A. Install the fuse box (right) securely to the plastic stay.
- B. Insert the wire harness holder into stay 1.
- C. Connect the front wheel sensor lead to the connector attached to the wire harness.
- D. Fasten the starter relay lead to the plastic stay. Route and insert the handlebar switch lead inside the vehicle.
- E. Fasten the right and left handlebar switch couplers to the plastic stay.
- F. Insert the wire harness holder (with white tape) into stay 1.
- G. Route the horn lead and front wheel sensor lead as shown in the illustration.
- H. Fasten the right and left handlebar switch leads and insert them into stay 1. The ratchet may be faced to any direction.
- I. Route the right and left handlebar switch leads between stay 1.
- J. Pass the handlebar switch leads through the holder. The opening can be oriented in any direction.
- K. Install the holder between the wire harness holder and meter lead. The opening can be oriented in any direction.
- L. The left and right handlebar switch leads can be positioned in either way.
- M. Detailed illustration of the steering head pipe front side routing
- N. Inside of stay 1.
- O. Connect to the coupler fastened to the wire harness.
- P. Insert the wire harness holder into stay 1 from the inside of the vehicle.
- Q. Route the front wheel sensor lead further to the left of the vehicle than the right and left handlebar switch leads.
- R. Insert the wire harness holder into stay 1.
- S. Right side
- T. Insert the front wheel sensor lead holder into stay 1.
- U. Insert the front wheel sensor lead holder into stay 1. Face the opening to the top of the vehicle.
- V. Left side

Frame (left side view)



- 1. Battery
- 2. Sidestand switch coupler
- 3. Battery negative lead coupler
- 4. Battery negative lead
- 5. Starter motor lead
- 6. AC magneto lead
- 7. Sidestand switch lead
- 8. Frame
- 9. Ignition coil
- 10.Rectifier/regulator
- 11.AC magneto coupler
- 12.Fuel injection system relay
- 13.Rear brake hose
- 14.Battery positive lead
- A. Insert the lead of the sidestand switch coupler into the battery box rib.
- B. Insert the leads of the battery negative lead coupler into the battery box rib.
- C. Pass the AC magneto lead, starter motor lead, and battery negative lead through the plastic guide. The leads may be placed anywhere in the guide.
- D. Fasten the sidestand switch lead and rear brake hose to the brake hose holder.
- E. To the starter motor and AC magneto
- F. Fasten with the sidestand switch lead positioning tape.
- G. Fasten the spark plug leads with the holder.
- H. Fasten spark plug #1 lead to the holder. Face the opening to the bottom of the vehicle.
- I. Install the AC magneto coupler to the battery box.
- J. With the rectifier/regulator disconnected, install the battery negative lead, starter motor lead, and wire harness. Insert them into the battery box rib. The harness may be placed anywhere in the rib.
- K. Route the starter motor lead outside the AC magneto lead.
- L. Pass the battery negative lead through the hole of the battery box.
- M. Starting circuit cut-off relay 1 and 2 can be installed to the both holders.
- N. Pass the battery negative lead through the battery box rib.
- O. Insert the plastic band of the battery positive lead so that the cutting end of the band faces to the bottom of the vehicle.
- P. Fasten the leads to the wire harness holder. This wire harness holder is secured at two points. The order of leads does not need to be controlled.
- Q. Face the wire harness holder block to the bottom of the vehicle. Face the end of the holder downward along the frame.







- 1. ECU (engine control unit) lead
- 2. Turn signal/hazard relay
- 3. Couplers
- 4. Headlight relay
- 5. Radiator fan motor relay
- 6. Throttle position sensor sub-wire harness
- 7. Fuel pump lead
- 8. Bracket 1
- 9. Immobilizer lead
- 10.Main switch leads
- 11.Turn signal light lead coupler
- 12.Headlight coupler
- 13.Headlight sub-wire harness
- A. Insert the headlight sub-wire harness coupler into the plastic stay.
- B. Route the headlight sub-wire harness further outside of the vehicle than the fuse box.
- C. Insert the wire harness holder into bracket 1.
- D. Insert the wire harness holder into the frame.
- E. Install the seat lock cable to bracket 1.
- F. Route the rear brake lock cable further inside of the vehicle than bracket 1.
- G. Route the immobilizer lead over the main switch coupler.
- H. Pass the wire harness side of the immobilizer lead, and the main switch side of the main switch leads through the rib of bracket 1.
- I. After installing the headlight, connect to the wire harness side.
- J. Insert the wire harness holder into the headlight body.
- K. Pass securely through the headlight body rib. (3 points)



Rear frame (top side and right side view)

- 1. Fuel pump coupler
- 2. Fuel injector #1
- 3. Fuel tank fitting bracket
- 4. Intake air pressure sensor
- 5. Air filter case
- 6. Intake air temperature sensor
- 7. Fuel injector #2
- 8. Fuel tank breather hose
- 9. Rear brake lock cable
- 10.O<sub>2</sub> sensor lead
- 11.Rear wheel sensor lead
- 12.Rear turn signal light lead
- 13.ABS test coupler
- 14.Tail/brake light lead
- 15.License plate light lead coupler
- 16.Tail/brake light lead coupler
- 17.Taillight lead cover
- 18.Storage box light switch lead
- A. Route the wire harness under the fuel tank fitting bracket and then through the hole of the storage box.
- B. Fasten the main switch lead and immobilizer lead. The cable holder may be fastened to any direction.
- C. Insert the cable holder into the fuel tank fitting bracket. Fasten the seat lock cable and rear brake lock cable.
- D. Route the rear brake lock cable between bracket 10 and the frame.
- E. Install the seat lock cable to bracket 10.
- F. Insert the wire harness holder into the fuel tank fitting bracket. Route the wire harness under the seat lock cable and rear brake lock cable.
- G. Insert the wire harness holder into the frame.
- H. Insert the wire harness holder into the bottom side of the fuel tank fitting bracket.
- I. Insert the wire harness holder into the rear frame. (2 points)
- J. Fit it to the rib part of the side cover.
- K. Secure the O<sub>2</sub> sensor coupler to the wire harness.
- L. Route the fuel tank breather hose between the storage box and fuel tank.
- M. Fasten the seat lock cable to the cable holder attached to the fuel tank.
- N. Route the coolant temperature sensor lead under the rear brake lock cable.
- O. Fasten the radiator fan motor lead to the plastic band. Face the end of the band to the outside of the vehicle.
- P. Secure the wire sub-lead coupler to the wire harness.
- Q. Insert the wire harness holder into the bracket.

- R. When inserting the rear wheel sensor lead into the holder, soapy water or silicone fluid may be applied.
- S. Install it so that the lead passes under the insert part of the side cover cavity.
- T. Tail light routing diagram
- U. Routing of the tail light lead.
- V. Fasten the ABS test coupler lead to the holder which is applied to the storage box.
- W. Insert it all the way into the storage box light.
- X. Pass the leads through the rib part of the taillight lead cover. Route the turn signal light lead and storage box light switch lead to the right of the vehicle. Route the turn signal light lead and tail light lead to the left of the vehicle. Route the leads further inside of the vehicle than the turn signal light installation part.

Rear brake (top side and left side view)






- 1. Rear brake hose
- 2. Fuel tank fitting bracket
- 3. Footboard
- 4. Rear frame
- 5. Left rear cowling
- 6. Rear brake hose holder (left)
- 7. Swingarm
- 8. Drive pulley cover
- 9. Passenger footrest
- 10.Rear brake lock cable holder bracket
- 11.Crankcase
- 12.Frame
- 13.Sidestand switch lead
- 14.Stay
- 15.Brake hose holder
- 16.Side cover (left)
- 17.Seat lock cable
- 18.Rear brake lock cable
- 19. Rear brake lock cable holder (crankcase)
- 20.Rear brake lock adjusting nut
- 21.Rear brake hose bracket
- 22.Rear brake hose holder (right)
- 23.Rear wheel sensor lead
- 24.Rear brake lock caliper
- 25.Rear brake lock cable holder (swingarm)
- 26.Rear brake caliper
- 27.Rear wheel sensor holder
- 28.Rear wheel sensor
- A. Install the brake hose holder, aligning the stopper of the brake hose holder with the hole of the passenger footrest. To prevent kinks, install the rear brake hose holder (left) first and then brake hose holder.
- B. Face the opening of the brake hose holder upward.
- C. Route the brake hose along the concave face of the left rear cowling.
- D. Install the cap, pushing it against the nut and washer.
- E. Route the rear brake lock cable under the brake hose.
- F. Face the opening of the cable holder to the inside of the vehicle.
- G. Install the rear brake lock cable holder (crankcase), inserting the projection of the cable guide into the hole of the rear brake lock cable holder bracket.
- H. Install the rear brake hose holder (left), inserting the projection of the rear brake hose holder (left) into the hole of the rear brake hose bracket.
- I. Install the rear brake hose holder (right), inserting the projection of the rear brake hose holder (right) into the hole of the rear brake hose bracket.

- J. Install the holder, pushing it against the rear wheel sensor protector end.
- K. 60-70 mm (2.36-2.76 in)
- L. Tighten the union bolt, pushing the brake pipe against the projection of the brake caliper.

### Throttle body (left side view)



- 1. Fast idle plunger inlet coolant hose
- 2. Intake manifold
- 3. Radiator
- 4. Fast idle plunger outlet coolant hose
- 5. Throttle body assembly
- 6. Air filter case
- 7. Intake air pressure sensor
- A. Insert the throttle body into the intake manifold until it does not move any further. Engine oil may be applied.
- B. Insert the coolant hose until it does not move any further. Face the pink paint mark to the rear of the vehicle.
- C. Position the clip at least 1 mm (0.04 in) away from the end of the hose, making sure that it does not run on the spool. Face the clip to the rear of the vehicle.
- D. Position the clip at least 1 mm (0.04 in) away from the end of the hose, making sure that it does not run on the spool. Face the clip to the left of the vehicle.
- E. Insert the fast idle plunger inlet coolant hose until the bending part of the pipe.
- F. Insert the fast idle plunger outlet coolant hose until the bending part of the pipe. Face the white paint mark to the left of the vehicle.
- G. Insert the fast idle plunger outlet coolant hose until the bending part of the pipe. Face the yellow paint mark to the top the vehicle.
- H. Position the clip at least 1 mm (0.04 in) away from the end of the hose, making sure that it does not run on the spool. Turn the clip, so that it does not interfere with the spark plug leads and radiator (should be turned downwards slightly to the front).
- I. Insert the air filter case until it touches the throttle body. Engine oil may be applied.
- J. 8°
- K. 3°
- L. 30°
- M. 65°
- N. Insert the intake air pressure sensor hose until it does not move any further.
- O. Position the clip 1 to 4 mm (0.04 to 0.16 in) away from the end of the cylinder head breather hose. Face the clip to the left of the vehicle.
- P. Insert the cylinder head breather hose until it does not move any further. Face the white paint mark to the top of the vehicle.
- Q. To the cylinder head cover
- R. To the throttle body assembly
- S. Insert the fast idle plunger intake hose until it does not move any further. Face the blue paint mark to the right of the vehicle.

- T. Position the clip 1 to 4 mm (0.04 to 0.16 in) away from the end of the fast idle plunger intake hose. Face the clip to the right of the vehicle.
- U. Fasten the cylinder head breather hose to the air filter case.
- V. Insert the cylinder head breather hose until it does not move any further. Face the yellow paint mark to the right of the vehicle.
- W. Position the clip 1 to 4 mm (0.04 to 0.16 in) away from the end of the cylinder head breather hose. The clip may be rotated to any direction.
- X. Position the clip at least 1 mm (0.04 in) away from the end of the hose, making sure that it does not run on the spool. Face the clip to the bottom of the vehicle.
- Y. Insert the fast idle plunger intake hose until it does not move any further. Face the yellow paint mark to the front of the vehicle.



Fuel tank (top side, left side and right side view)

- 1. Fuel hose
- 2. Fuel tank breather hose
- 3. Air filter case
- 4. Intake air pressure sensor
- 5. Fuel tank
- 6. Bottom center cowling
- 7. Radiator outlet hose
- 8. Fuel tank overflow hose
- 9. White paint mark
- 10.Filler cover
- 11.Fuel tank cap
- 12.Bracket 2
- 13.Rollover valve
- 14.Fuel rail
- 15.Fuel tank protector
- 16.Fuel tank fitting bracket
- A. Face the clip knob to any direction but to the top of the vehicle.
- B. When inserting the fuel tank breather hose into the fuel tank, 2-stroke engine oil may be applied.
- C. Push the grommet securely into the fuel tank. When inserting the fuel tank breather hose into the grommet, soapy water or silicone fluid may be applied.
- D. Push the grommet securely into the fuel tank. Soapy water or silicone fluid may be applied.
- E. Make sure that the clip does run on the spool.
- F. Insert the fuel tank breather hose until it touches the end of the fuel tank protector.
- G. Insert the fuel tank protector until the separator spool of the fuel tank.
- H. Insert the end of the fuel tank breather hose according to the area shown in the illustration.
- I. Inside of the vehicle
- J. Outside of the vehicle
- K. End of the fuel tank breather hose
- L. Route the end of the fuel tank overflow hose so that it comes out under the bottom center cowling.
- M. Route the fuel tank overflow hose between the radiator outlet hose and frame.
- N. Route the fuel tank overflow hose inside of the frame.
- O. 7 to 10 mm (0.28 to 0.39 in) (From the lower end of the paint mark to the upper end of grommet)
- P. Install the fuel tank overflow hose and filler cover, pressing them against the connector boss.
- Q. Apply the holder, aligning it with the upper end of the damper. Face the holder opening upward or downwards. Make sure that the end of the holder does not run on the bending part of the tank.

- R. Insert the intake pressure sensor hose until it touches the pipe of the intake air pressure sensor.
- S. 0 to 3 mm (0 to 0.12 in)
- T. Route the fuel tank breather hose inside of the frame.
- U. Install the fuel tank breather hose, holding the positioning protector behind the holder.
- V. Push the fuel tank breather hose into the storage box hook.
- W. Route the fuel tank breather hose to the concave of the storage box.
- X. Install the rollover valve stay, pushing it against the projection of the storage box.
- Y. Push the fuel tank breather hose against the rollover valve.
- Z. Face the clip knob to the outside of the vehicle.
- AA.Face the clip knob to the rear of the vehicle.
- AB.After installing the fuel hose, check that the claw is inserted firmly to the end.
- AC.Make sure to remove/install the fuel hose manually without using tools.
- AD.Fuel hose connector assembly drawing
- AE.Assembly drawing from the fuel rail to the fuel hose
- AF.Insert the connector until the click sound is heard and check that the connector does not come off. Make sure that no foreign matter is caught in the sealing section. (It is prohibited to wear the cotton work gloves or equivalent coverings.)
- AG. This part works as a dropout stopper.
- AH.After "AF" work is finished, slide the fuel hose connector cover attached to the fuel hose connector as shown in the illustration. Make sure that it is attached completely tight.
- Al. Fuel hose connector cover

F

G

Н

#### (1) 2 (0)) 3 7 0 $\cap$ н 4 O) 5 Α 0 6 汨病 $\mathcal{T}$ В 8 Ш Ċ D 9 (0)0 $\bigcirc \bigcirc$ $\bigcirc$ U (10) 1 Ε 0 Ó P H 0 (5) $\bigcirc$ $\bigcirc$ $\bigcirc$ 0) 13 6 (16) (12) 0 $\overline{\mathbb{O}}$ 14 0 C 13 1 S) (16)

### Hydraulic unit (top side and front side view)

(15)

13

(2)

3

17

- 1. Front brake hose (hydraulic unit to front brake hose joint)
- 2. Front brake hose (front brake master cylinder to hydraulic unit)
- 3. Rear brake hose (rear brake master cylinder to hydraulic unit)
- 4. Rear brake pipe/joint assembly (hydraulic unit to rear brake hose)
- 5. Hydraulic unit assembly
- 6. Rear brake hose (rear brake pipe/joint assembly to rear brake caliper)
- 7. Battery box 2
- 8. Grommet
- 9. Relay stay
- 10.Stay 1
- 11.Mold
- 12.Battery box 1
- 13.Brake hose holder
- 14.Battery positive lead
- 15.Stay
- 16.Brake hose holder 1
- 17. Hydraulic unit assembly bracket
- A. Tighten the union bolt, pushing the brake pipe against the hydraulic unit assembly bracket.
- B. Pass the rear brake hose between the battery box 2 and stay 1.
- C. Install the grommet, fitting it into the hole of the stay 1 at the space between the pipe of the stay 1 and the battery box 2.
- D. Pass the brake hoses through the hole of the relay stay.
- E. Install the end of the mold until the area shown in the illustration.
- F. Insert the mold all the way into the stay 1, aligning the end of the mold with the rounded end of the stay 1.
- G. Install the mold aligning with the end of the stay 1.
- H. Face the opening of the holder to the bottom of the vehicle.
- I. Fasten the rear brake hose grommets to the brake hose holders.

### PERIODIC CHECKS AND ADJUSTMENTS

PERIODIC MAINTENANCE	3-1
INTRODUCTION	3-1
PERIODIC MAINTENANCE CHART FOR THE EMISSION	
CONTROL SYSTEM	3-1
GENERAL MAINTENANCE AND LUBRICATION CHART	3-2
CHECKING THE FUEL LINE	3-4
CHECKING THE SPARK PLUGS	3-4
ADJUSTING THE VALVE CLEARANCE	3-5
ADJUSTING THE ENGINE IDLING SPEED	3-8
SYNCHRONIZING THE THROTTLE BODY	3-9
CHECKING THE THROTTLE BODY JOINTS	3-10
CHECKING THE CYLINDER HEAD BREATHER HOSE	3-10
ADJUSTING THE EXHAUST GAS VOLUME	3-11
CHECKING THE EXHAUST SYSTEM	3-11
REPLACING THE AIR FILTER ELEMENT	3-12
CLEANING THE V-BELT CASE AIR FILTER ELEMENT	3-12
CHECKING THE BRAKE OPERATION	3-13
CHECKING THE BRAKE FLUID LEVEL	3-14
ADJUSTING THE FRONT DISC BRAKE	3-14
CHECKING THE FRONT BRAKE PADS	3-15
ADJUSTING THE REAR DISC BRAKE	3-15
CHECKING THE REAR BRAKE PADS	3-15
BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)	3-16
CHECKING THE FRONT BRAKE HOSES	3-17
CHECKING THE REAR BRAKE HOSE	3-17
ADJUSTING THE REAR BRAKE LOCK CABLE	3-17
CHECKING THE REAR BRAKE LOCK	3-18
CHECKING THE REAR BRAKE LOCK PADS	3-19
CHECKING THE WHEELS	3-19
CHECKING THE TIRES	3-19
CHECKING THE WHEEL BEARINGS	3-20
CHECKING THE SWINGARM	3-20
CHECKING THE DRIVE BELT	3-20
ADJUSTING THE DRIVE BELT SLACK	3-21
LUBRICATING THE DRIVE PULLEY AND DRIVE AXLE	3-22
CHECKING AND ADJUSTING THE STEERING HEAD	3-23
CHECKING THE CHASSIS FASTENERS	3-24
LUBRICATING THE LEVERS	3-24
CHECKING THE SIDESTAND	3-24
LUBRICATING THE SIDESTAND	3-25
CHECKING THE CENTERSTAND	3-25
LUBRICATING THE CENTERSTAND	3-25
CHECKING THE SIDESTAND SWITCH	3-25
CHECKING THE FRONT FORK	3-25
CHECKING THE REAR SHOCK ABSORBER ASSEMBLY	3-25
CHECKING THE ENGINE OIL LEVEL	3-25
	3-26
MEASURING THE ENGINE OIL PRESSURE	3-28
CHECKING THE COOLANT LEVEL	3-29
CHECKING THE COOLING SYSTEM	3-29

CHANGING THE COOLANT	3-30
REPLACING THE V-BELT	3-31
CHECKING THE BRAKE LIGHT SWITCHES	3-32
CHECKING AND LUBRICATING THE CABLES	3-32
LUBRICATING THE REAR SUSPENSION	3-32
CHECKING THE THROTTLE GRIP	3-32
CHECKING AND CHARGING THE BATTERY	3-33
CHECKING THE FUSES	3-33
REPLACING THE HEADLIGHT BULBS	3-33
ADJUSTING THE HEADLIGHT BEAMS	3-34

#### EAS20460

### INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. If followed, these preventive maintenance procedures will ensure more reliable vehicle operation, a longer service life and reduce the need for costly overhaul work. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

TIP

- The annual checks must be performed every year, except if a kilometer-based maintenance, or for the UK, a mileage-based maintenance, is performed instead.
- From 50000 km (30000 mi), repeat the maintenance intervals starting from 10000 km (6000 mi).
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

EAS59C1302

### PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL SYSTEM

				ODOMETER READING					
NO.		ITEM	JOB	1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	CHECK
1	*	Fuel line	<ul> <li>Check fuel hoses for cracks or damage.</li> </ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
2	*	Spark plugs	<ul><li>Check condition.</li><li>Clean and regap.</li></ul>		$\checkmark$		$\checkmark$		
			Replace.					$\checkmark$	
3	*	Valves	<ul><li>Check valve clearance.</li><li>Adjust.</li></ul>	Every 40000 km (24000 mi)					
4	*	Fuel injection	<ul> <li>Adjust engine idling speed and synchronization.</li> </ul>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$

### EAS59C1303 GENERAL MAINTENANCE AND LUBRICATION CHART

				ODOMETER READING					
N	NO. ITEM		JOB	1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	CHECK
1		Air filter element	Replace.					$\checkmark$	
2	*	V-belt case air fil-	Clean.						
2		ter elements	Replace.			$\checkmark$		$\checkmark$	
3	*	Front brake	Check operation, fluid level     and vehicle for fluid leakage.	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
			Replace brake pads.		١	Whenever wo	orn to the lim	it	
4	*	Rear brake	<ul> <li>Check operation, fluid level and vehicle for fluid leakage.</li> </ul>	$\checkmark$		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
			Replace brake pads.		. ۱	Whenever wo	orn to the lim	it	
5	*	Brake hoses	<ul> <li>Check for cracks or damage.</li> <li>Check for correct routing and clamping.</li> </ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
			Replace.			Every	4 years		
6		Rear brake lock	Check cable length.	$\checkmark$	4000 km	(2400 mi) af	ter the initial	1000 km (60	0 mi) and
		cable	Adjust if necessary.			every 5000	km (3000 m	i) thereafter	
7	*	Rear brake lock	<ul> <li>Check operation.</li> <li>Check rubber boots.</li> <li>Check wear indicator.</li> <li>Adjust if necessary.</li> </ul>	$\checkmark$	V	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
8	*	Wheels	<ul> <li>Check runout and for dam- age.</li> </ul>		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	
9	*	Tires	<ul> <li>Check tread depth and for damage.</li> <li>Replace if necessary.</li> <li>Check air pressure.</li> <li>Correct if necessary.</li> </ul>		V	V	V	V	$\checkmark$
10	*	Wheel bearings	<ul> <li>Check bearing for looseness or damage.</li> </ul>			$\checkmark$	$\checkmark$	$\checkmark$	
11	*	Drive belt	<ul> <li>Check belt condition.</li> <li>Replace if damaged.</li> <li>Check belt tension.</li> <li>Adjust if necessary.</li> </ul>	✓ Every 10000 km (6000 mi) until 40000 km (24000 mi), and every 5000 km (3000 mi) thereafter					
12	*	Drive pulley and drive axle	Lubricate.			$\checkmark$		$\checkmark$	
10	*	Steering bearings	Check bearing play and steer- ing for roughness.	$\checkmark$	V	$\checkmark$	$\checkmark$	$\checkmark$	
13			<ul> <li>Lubricate with lithium-soap- based grease.</li> </ul>		E	very 20000 l	km (12000 m	ni)	
14	*	Chassis fasteners	<ul> <li>Make sure that all nuts, bolts and screws are properly tight- ened.</li> </ul>			$\checkmark$	$\checkmark$	$\checkmark$	
15		Front brake lever pivot shaft	Lubricate with silicone grease.		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
16		Rear brake lever pivot shaft	Lubricate with silicone grease.		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
17		Sidestand, centerstand	<ul> <li>Check operation.</li> <li>Lubricate with lithium-soap- based grease.</li> </ul>		V	$\checkmark$	$\checkmark$		$\checkmark$
18	*	Sidestand switch	Check operation.						
19	*	Front fork	<ul> <li>Check operation and for oil leakage.</li> </ul>		V	$\checkmark$	$\checkmark$	$\checkmark$	
20	*	Shock absorber assembly	<ul> <li>Check operation and shock absorber for oil leakage.</li> </ul>						
			Change.			When the oil	change indi	cator flashes	
21		Engine oil	Check oil level and vehicle for oil leakage.	e for Every 5000 km (3000 mi)			$\checkmark$		
22		Engine oil filter cartridge	Replace.	$\checkmark$		$\checkmark$		$\checkmark$	

NO.				ODOMETER READING					
		. ITEM CHE	JOB	1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	CHECK
23	*	Cooling system	Check coolant level and vehi- cle for coolant leakage.		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
			<ul> <li>Change with ethylene glycol anti-freeze coolant.</li> </ul>			Every	3 years		
24	*	V-belt	Replace.	When the V-belt replacement indicator flashes [every 20000 km (12500 mi)]				km (12500	
25	*	Front and rear brake switches	Check operation.	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
26		Moving parts and cables	Lubricate.		$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
27	*	Throttle grip	<ul> <li>Check operation.</li> <li>Check throttle grip free play, and adjust if necessary.</li> <li>Lubricate cable and grip housing.</li> </ul>		$\checkmark$	$\checkmark$	$\checkmark$	V	V
28	*	Lights, signals and switches	<ul><li>Check operation.</li><li>Adjust headlight beam.</li></ul>	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	

TIP\_

• Engine air filter and V-belt air filters

• This model's engine air filter is equipped with a disposable oil-coated paper element, which must not be cleaned with compressed air to avoid damaging it.

- The engine air filter element needs to be replaced and the V-belt air filter elements need to be serviced more frequently when riding in unusually wet or dusty areas.
- Hydraulic brake service
  - After disassembling the brake master cylinders and calipers, always change the fluid. Regularly check the brake fluid levels and fill the reservoirs as required.
  - Every two years replace the internal components of the brake master cylinders and calipers, and change the brake fluid.
  - Replace the brake hoses every four years and if cracked or damaged.

### EAS21030

### CHECKING THE FUEL LINE

The following procedure applies to all of the fuel and breather hoses.

- 1. Remove:
  - Center cover Refer to "GENERAL CHASSIS" on page 4-1.
  - Side covers Refer to "GENERAL CHASSIS" on page 4-1.
  - Footboards Refer to "GENERAL CHASSIS" on page 4-1.
  - Storage box Refer to "GENERAL CHASSIS" on page 4-1.
- 2. Check:
  - Fuel hose "1"
  - Fuel tank breather hose "2" Cracks/damage  $\rightarrow$  Replace.

Loose connection  $\rightarrow$  Connect properly.

#### ECA14940 **NOTICE**

# Make sure the fuel tank breather hose is routed correctly.



- 3. Install:
  - Storage box Refer to "GENERAL CHASSIS" on page 4-1.
  - Footboards Refer to "GENERAL CHASSIS" on page 4-1.
  - Side covers Refer to "GENERAL CHASSIS" on page 4-1.
  - Center cover Refer to "GENERAL CHASSIS" on page 4-1.

#### EAS20680 CHECKING THE SPARK PLUGS

The following procedure applies to all of the spark plugs.

- 1. Remove:
  - Radiator cover Refer to "GENERAL CHASSIS" on page 4-1.
- 2. Disconnect:
  - Spark plug cap
- 3. Remove:
  - Spark plug
- ECA13320

### NOTICE

### Before removing the spark plugs, blow away any dirt accumulated in the spark plug wells with compressed air to prevent it from falling into the cylinders.

- 4. Check:
  - Spark plug type Incorrect → Change.



- Manufacturer/model NGK/CR7E
- 5. Check:
  - Electrode "1"
     Damage/wear → Beplace the spat
  - Damage/wear → Replace the spark plug.
    Insulator "2" Abnormal color → Replace the spark

Abnormal color  $\rightarrow$  Replace the spark plug.

Normal color is medium-to-light tan.

- 6. Clean:
  - Spark plug (with a spark plug cleaner or wire brush)
- 7. Measure:
  - Spark plug gap "a" (with a wire thickness gauge) Out of specification → Regap.

Spark plug gap 0.7–0.8 mm (0.028–0.031 in)



- 8. Install:
  - Spark plug



#### Spark plug 13 Nm (1.3 m·kgf, 9.4 ft·lbf)

### TIP.

Before installing the spark plug, clean the spark plug and gasket surface.

### 9. Connect:

- Spark plug cap 10. Install:
  - Radiator cover Refer to "GENERAL CHASSIS" on page 4-1.

### EAS20490

### ADJUSTING THE VALVE CLEARANCE

The following procedure applies to all of the valves.

### TIP\_

- Valve clearance adjustment should be made on a cold engine, at room temperature.
- When the valve clearance is to be measured or adjusted, the piston must be at top dead center (TDC) on the compression stroke.
- 1. Remove:
  - Radiator cover Refer to "GENERAL CHASSIS" on page 4-1.
- 2. Remove:
  - Radiator bracket
    - Refer to "RADIATOR" on page 6-1.
- 3. Remove:
  - Storage box Refer to "GENERAL CHASSIS" on page 4-1.
- 4. Remove:
  - Fuel tank
    - Refer to "FUEL TANK" on page 7-1.
- 5. Remove:
  - Air filter case
  - Throttle body
  - Intake manifold Refer to "THROTTLE BODY" on page 7-5.
- 6. Remove:
  - Spark plugs
  - Cylinder head cover
  - Cylinder head cover gasket Refer to "CAMSHAFTS" on page 5-8.

- 7. Remove:
  - Timing mark accessing plug "1"
  - Crankshaft end access cover "2"





- 8. Measure:
  - Valve clearance Out of specification → Adjust.
- Valve clearance (cold) Intake 0.15–0.22 mm (0.0059–0.0087 in) Exhaust 0.25–0.32 mm (0.0098–0.0126 in)

### \*\*\*\*

a. Turn the crankshaft clockwise.



b. When piston #1 is at TDC on the compression stroke, align the "I" mark "a" on the generator rotor with the mark "b" on the generator cover.

### TIP\_

- TDC on the compression stroke can be found when the cylinder #1 camshaft lobes are turned away from each other.
- In order to be sure that the piston is at TDC, the alignment mark "c" on the intake camshaft sprocket and the alignment mark "d" on the exhaust camshaft sprocket must align with the cylinder head mating surface as shown in the illustration.





c. Measure the valve clearance with a thickness gauge "1".



### TIP\_

- If the valve clearance is incorrect, record the measured reading.
- Measure the valve clearance in the following sequence.

Valve clearance measuring sequence Cylinder #1  $\rightarrow$  #2



- A. Front
- d. To measure the valve clearances of the other cylinders, starting with cylinder #1 at TDC, turn the crankshaft clockwise as specified in the following table.



- A. Degrees that the crankshaft is turned clockwise
- B. Cylinder
- C. Combustion cycle

Cylinder #2

.....

360°

- 9. Remove:
  - Camshafts

TIP\_

- Refer to "CAMSHAFTS" on page 5-8.
- When removing the timing chain and camshafts, fasten the timing chain with a wire to retrieve it if it falls into the crankcase.
- 10. Adjust:
  - Valve clearance

\*\*\*\*\*

a. Remove the valve lifter "1" and the valve pad "2" with a valve lapper "3".



Valve lapper 90890-04101 Valve lapping tool YM-A8998

TIP \_\_\_\_

- Cover the timing chain opening with a rag to prevent the valve pad from falling into the crankcase.
- Make a note of the position of each valve lifter "1" and valve pad "2" so that they can be installed in the correct place.





b. Calculate the difference between the specified valve clearance and the measured valve clearance.

Example:

Specified valve clearance = 0.15-0.22 mm (0.0059-0.0087 in)

Measured valve clearance = 0.25 mm(0.0098 in)

0.25 mm (0.0098 in) - 0.22 mm (0.0087 in) = 0.03 mm (0.001 in)

c. Check the thickness of the current valve pad.

### TIP\_

The thickness "a" of each valve pad is marked in hundredths of millimeters on the side that touches the valve lifter.

### Example:

If the valve pad is marked "155", the pad thickness is 1.55 mm (0.061 in).



 Calculate the sum of the values obtained in steps (b) and (c) to determine the required valve pad thickness and the valve pad number.

Example:

1.55 mm (0.061 in) + 0.03 mm (0.001 in) = 1.58 mm (0.062 in)

The valve pad number is 158.

e. Round off the valve pad number according to the following table, and then select the suitable valve pad.

Last digit	Rounded value
0, 1, 2	0
3, 4, 5, 6	5
7, 8, 9	10

TIP\_\_\_

Refer to the following table for the available valve pads.

Valve pad range	Nos. 120–240
Valve pad thickness	1.20–2.40 mm (0.047–0.094 in)
Available valve pads	25 thicknesses in 0.05 mm (0.002 in) increments

Example:

Valve pad number = 158 Rounded value = 160

New valve pad number = 160

f. Install the new valve pad "1" and the valve lifter "2".

TIP\_

- Lubricate the valve pad with molybdenum disulfide oil.
- Lubricate the valve lifter (Top side) with molybdenum disulfide oil.
- Lubricate the valve lifter (Outer side) with engine oil.

- The valve lifter must turn smoothly when rotated by hand.
- Install the valve lifter and the valve pad in the correct place.



g. Install the exhaust and intake camshafts, timing chain and camshaft caps.



### TIP

- Refer to "CAMSHAFTS" on page 5-8.
- Lubricate the camshaft lobes and camshaft journals with molybdenum disulfide oil.
- First, install the exhaust camshaft.
- Turn the crankshaft clockwise several full turns to seat the parts.
- h. Measure the valve clearance again.
- i. If the valve clearance is still out of specification, repeat all of the valve clearance adjustment steps until the specified clearance is obtained.

### 11. Install:

All removed parts

### TIP.

For installation, reverse the removal procedure.

### 12. Adjust:

• Throttle grip free play Refer to "CHECKING THE THROTTLE GRIP" on page 3-32.

EAS20610

# ADJUSTING THE ENGINE IDLING SPEED

Prior to adjusting the engine idling speed, the throttle body synchronization should be adjusted properly, the air filter element should be clean, and the engine should have adequate compression.

- 1. Start the engine and let it warm up for several minutes.
- 2. Remove:
  - Radiator cover Refer to "GENERAL CHASSIS" on page 4-1.
  - Side cover (right) Refer to "GENERAL CHASSIS" on page 4-1.
- 3. Install:
  - Digital tachometer (onto the spark plug lead of cylinder #1)



Digital tachometer 90890-06760 YU-39951-B

- 4. Check:
  - Engine idling speed Out of specification → Adjust.

5. Adjust:

3-8

- Engine idling speed
- \*\*\*\*\*
- a. Turn the idling speed adjusting screw "1" in direction "a" or "b" until the specified engine idling speed is obtained.

Direction "a" Engine idling speed is increased. Direction "b" Engine idling speed is decreased.



### 6. Install:

- Side cover (right)
- Refer to "GENERAL CHASSIS" on page 4-1.
- Radiator cover Refer to "GENERAL CHASSIS" on page 4-1.

### EAS20571

# SYNCHRONIZING THE THROTTLE BODY

Prior to synchronizing the throttle body, the valve clearance and the engine idling speed should be properly adjusted and the ignition timing should be checked.

1. Stand the vehicle on a level surface.

### TIP\_

Place the vehicle on a centerstand.

- 2. Remove:
  - Radiator cover Refer to "GENERAL CHASSIS" on page 4-1.
  - Center cover Refer to "GENERAL CHASSIS" on page 4-1.
  - Side covers Refer to "GENERAL CHASSIS" on page 4-1.
  - Footboards Refer to "GENERAL CHASSIS" on page 4-1.
- 3. Remove:
  - Intake air pressure sensor hose for cylinder #1 "1"
  - Synchronizing pipe cap for cylinder #2 "2"





- 4. Install:
  - Hose "1" (Parts No.: 5JW-24311-00)
  - 3-Way joint "2" (Parts No.: 68V-24376-00)
  - Cylinder #1 intake air pressure sensor hose "3"
  - Vacuum gauge hose for cylinder #1 "4"
  - Vacuum gauge hose for cylinder #2 "5"
  - Vacuum gauge
  - Digital tachometer (onto the spark plug lead of cylinder #1)



Vacuum gauge 90890-03094 Vacuummate YU-44456 Digital tachometer 90890-06760 YU-39951-B





- 5. Start the engine and let it warm up for several minutes.
- 6. Check:
  - Engine idling speed Out of specification → Adjust. Refer to "ADJUSTING THE ENGINE IDLING SPEED" on page 3-8.
- (~)

### Engine idling speed 1100–1300 r/min

### 7. Adjust:

• Throttle body synchronization

### \*\*\*\*

a. Turn the cylinder #1 air screw "1" and cylinder #2 air screw "2" using the carburetor angle driver 2 "3".



TIP

- After each step, rev the engine two or three times, each time for less than a second, and check the synchronization again.
- If the air screw is removed, turn the screw is fully, and then turn it out 3/4 turn. Then, synchronize the throttle body.



Carburetor angle driver 2 90890-03173

Intake vacuum 29.3–31.9 kPa (220–239 mmHg, 8.7–9.4 inHg)

### TIP.

The difference in vacuum pressure between two cylinders should not exceed 1.33 kPa (10 mm Hg).

### \*\*\*\*

- 8. Measure:
  - Engine idling speed Out of specification → Adjust. Make sure that the vacuum pressure is within specification.
- 9. Stop the engine and remove the measuring equipment.
- 10. Adjust:
  - Throttle grip free play Refer to "CHECKING THE THROTTLE GRIP" on page 3-32.



Throttle grip free play 3.0–5.0 mm (0.12–0.20 in)

11. Install:

• All removed parts

EAS21010

### CHECKING THE THROTTLE BODY JOINTS 1. Remove:

Center cover

Refer to "GENERAL CHASSIS" on page 4-1.

- 2. Check:
  - Throttle body joints "1" Cracks/damage → Replace.



- 3. Install:
  - Center cover Refer to "GENERAL CHASSIS" on page 4-1.

### CHECKING THE CYLINDER HEAD BREATHER HOSE

- 1. Remove:
  - Center cover Refer to "GENERAL CHASSIS" on page 4-1.
  - Side cover (right) Refer to "GENERAL CHASSIS" on page 4-1.

- Footboard (right) Refer to "GENERAL CHASSIS" on page 4-1.
- 2. Check:
  - Cylinder head breather hose "1" Cracks/damage → Replace.
     Loose connection → Connect properly.

#### ECA14920 **NOTICE**

# Make sure the cylinder head breather hose is routed correctly.



### 3. Install:

· All removed parts

# ADJUSTING THE EXHAUST GAS VOLUME

Be sure to set the CO density level to standard, and then adjust the exhaust gas volume.

- 1. Set the main switch to "OFF" and set the engine stop switch to "⊖".
- 2. Simultaneously press and hold the left set "1" and right set "2" buttons, set the main switch to "ON", and continue to press the buttons for 8 seconds or more.



### TIP\_

"dIAG" appears on the odometer LCD.



3. Press the left set button to select the CO adjustment mode "Co" or the diagnostic monitoring mode "dIAG".



- 4. After selecting "Co", simultaneously press the left set and right set buttons for 2 seconds or more to execute the selection.
- 5. Press the left set and right set buttons to select a cylinder.

### TIP

The selected cylinder number appears on the clock LCD.

- To decrease the selected cylinder number, press the right set button.
- To increase the selected cylinder number, press the left set button.
- 6. After selecting the cylinder, simultaneously press the left set and right set buttons for 2 seconds or more to execute the selection.
- 7. Change the CO adjustment volume by pressing the left set and right set buttons.

### TIP\_

The CO adjustment volume appears on the odometer LCD.

- To decrease the CO adjustment volume, press the right set button.
- To increase the CO adjustment volume, press the left set button.
- 8. Release the switch to execute the selection.
- 9. Simultaneously press the left set and right set buttons to return to the cylinder selection (step 5).
- 10. Set the main switch to "OFF" to cancel the mode.

#### EAS21081 CHECKING THE EXHAUST SYSTEM

The following procedure applies to all of the exhaust pipes and gaskets.

- 1. Remove:
  - Side cover (right) Refer to "GENERAL CHASSIS" on page 4-1.

- 2. Check:
  - Exhaust assembly "1" Cracks/damage  $\rightarrow$  Replace.
  - Gasket "2"
  - Exhaust gas leaks  $\rightarrow$  Replace.
- 3. Check:
  - Tightening torque
  - Exhaust assembly nut (front) "3"
  - Exhaust assembly nut (rear) "4"
  - O<sub>2</sub> sensor "5"

Exhaust assembly nut (front)

20 Nm (2.0 m·kgf, 14 ft·lbf) Exhaust assembly nut (rear) 31 Nm (3.1 m·kgf, 22 ft·lbf) O<sub>2</sub> sensor 45 Nm (4.5 m·kgf, 33 ft·lbf)



- 4. Install:
  - Side cover (right) Refer to "GENERAL CHASSIS" on page 4-1.

### EAS20961

### **REPLACING THE AIR FILTER ELEMENT**

1. Remove:

 Center cover Refer to "GENERAL CHASSIS" on page 4-1

- 2. Remove:
  - Air filter case cover "1"



- 3. Check:
  - Air filter element "1" Damage  $\rightarrow$  Replace.

### TIP

- Replace the air filter element every 20000 km (12000 mi) of operation.
- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.



- 4. Install:
- Air filter case cover ECA4B51003

### NOTICE

Never operate the engine without the air filter element installed. Unfiltered air will cause rapid wear of engine parts and may damage the engine. Operating the engine without the air filter element will also affect throttle body synchronization, leading to poor engine performance and possible overheating.

### TIP\_

When installing the air filter element into the air filter case cover, make sure that the sealing surfaces are aligned to prevent any air leaks.

- 5. Install:
  - Center cover Refer to "GENERAL CHASSIS" on page 4-1

#### EAS20980 **CLEANING THE V-BELT CASE AIR FILTER** ELEMENT

- 1. Remove:
  - Center cover Refer to "GENERAL CHASSIS" on page 4-1
  - Footboards Refer to "GENERAL CHASSIS" on page 4-1.

### 2. Remove:

• V-belt case air filter element (left) "1"



### 3. Remove:

- V-belt case air filter case cover "1"
- V-belt case air filter case "2"
- V-belt case air filter element (right) "3"





- 4. Clean:
  - V-belt case air filter elements Blow the compressed air to the outer surface of the V-belt case air filter element.





- 5. Check:
  - V-belt case air filter elements Damage → Replace.

#### ECA13440 **NOTICE**

Since the V-belt case air filter element is a dry type, do not let grease or water contact it.

- 6. Install:
  - V-belt case air filter element (right)
  - V-belt case air filter case
  - V-belt case air filter case cover



- 7. Install:
  - V-belt case air filter element (left)



V-belt case air filter element (left) bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

- 8. Install:
  - Footboards Refer to "GENERAL CHASSIS" on page 4-1.
  - Center cover Refer to "GENERAL CHASSIS" on page 4-1.

### EAS30921

### CHECKING THE BRAKE OPERATION

- 1. Check:
  - Brake operation Brake not working properly → Check the brake system. Refer to "FRONT BRAKE" on page 4-37 and "REAR BRAKE" on page 4-50.

### TIP\_\_\_

Drive on the road, operate the front and rear brakes separately and check to see if the brakes are operating properly.

### EAS21240

### CHECKING THE BRAKE FLUID LEVEL

1. Stand the vehicle on a level surface.

### TIP

- · Place the vehicle on the centerstand.
- Make sure the vehicle is upright.
- 2. Check:
  - Brake fluid level Below the minimum level mark "a"  $\rightarrow$  Add the recommended brake fluid to the proper level.







- A. Front brake
- B. Rear brake

#### EWA13090

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- · Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical

reaction, leading to poor brake performance.

• When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

### ECA13540

### NOTICE

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

### TIP\_

In order to ensure a correct reading of the brake fluid level, make sure the top of the brake master cylinder reservoir is horizontal.

### EAS21160

### ADJUSTING THE FRONT DISC BRAKE 1. Adjust:

 Brake lever position (distance "a" from the throttle grip to the brake lever)

### TIP

- While pushing the brake lever forward, turn the adjusting dial "1" until the brake lever is in the desired position.
- Be sure to align the setting on the adjusting dial with the arrow mark "2" on the brake lever.

Position #1 Distance "a" is the largest. Position #5 Distance "a" is the smallest.



### EWA13060

### WARNING

 After adjusting the brake lever position, make sure the pin on the brake lever holder is firmly inserted in the hole in the adjusting dial.

 A soft or spongy feeling in the brake lever can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce in loss of control and possibly an accident. Therefore, check and if necessary, bleed the brake system.

### ECA13490

### NOTICE

After adjusting the brake lever position, make sure there is no brake drag.

#### EAS21250

### CHECKING THE FRONT BRAKE PADS

The following procedure applies to all of the brake pads.

- 1. Operate the brake.
- 2. Check:
  - Front brake pad Wear indicators "1" almost touch the brake disc → Replace the brake pads as a set.

Refer to "FRONT BRAKE" on page 4-37.



### EAS21210

### ADJUSTING THE REAR DISC BRAKE

1. Adjust:

 Brake lever position (distance "a" from the left side grip to the brake lever)

TIP\_

- While pushing the brake lever forward, turn the adjusting dial "1" until the brake lever is in the desired position.
- Be sure to align the setting on the adjusting dial with the arrow mark "2" on the brake lever holder.

#### Position #1 Distance "a" is the largest. Position #5 Distance "a" is the smallest.



### EWA13060

- After adjusting the brake lever position, make sure the pin on the brake lever holder is firmly inserted in the hole in the adjusting dial.
- A soft or spongy feeling in the brake lever can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce in loss of control and possibly an accident. Therefore, check and if necessary, bleed the brake system.

ECA13490

### NOTICE

After adjusting the brake lever position, make sure there is no brake drag.

#### EAS21260 CHECKING THE REAR BRAKE PADS

The following procedure applies to all of the brake pads.

- 1. Operate the brake.
- 2. Check:
  - Rear brake pad Wear indicators "1" almost touch the brake disc → Replace the brake pads as a set.

Refer to "REAR BRAKE" on page 4-50.



#### EAS30770 BLEEDING THE HYDRAULIC BRAKE SYS-TEM (ABS)

#### EWA14000

### 

Always bleed the brake system when the brake related parts are removed.

### ECA17050

- Bleed the brake system in the following order.
- 1st step: Front brake calipers
- 2rd step: Rear brake caliper

### EWA15740

### **WARNING**

### Bleed the ABS whenever:

- the system is disassembled.
- a brake hose is loosened, disconnected or replaced.
- the brake fluid level is very low.
- brake operation is faulty.

### TIP\_

- Be careful not to spill any brake fluid or allow the brake master cylinder reservoir to overflow.
- When bleeding the ABS, make sure that there is always enough brake fluid before applying the brake. Ignoring this precaution could allow air to enter the ABS, considerably lengthening the bleeding procedure.
- If bleeding is difficult, it may be necessary to let the brake fluid settle for a few hours.
   Repeat the bleeding procedure when the tiny bubbles in the hose have disappeared.

### 1. Bleed:

• ABS

### \*\*\*\*

- Fill the brake master cylinder reservoir to the proper level with the specified brake fluid.
- b. Install the brake master cylinder reservoir diaphragm.
- c. Connect a clear plastic hose "1" tightly to the bleed screw "2".





- A. Front brake caliper
- B. Rear brake caliper
- d. Place the other end of the hose into a container.
- e. Slowly apply the brake several times.
- f. Fully squeeze the brake lever and hold it in position.
- g. Loosen the bleed screw.

### TIP\_

Loosening the bleed screw will release the pressure and cause the brake lever to contact the throttle grip or handlebar grip.

- h. Tighten the bleed screw and then release the brake lever.
- i. Repeat steps (e) to (h) until all of the air bubbles have disappeared from the brake fluid in the plastic hose.
- j. Check the operation of the hydraulic unit. Refer to "HYDRAULIC UNIT OPERATION TESTS" on page 4-72.

### ECA17060

### Make sure that the main switch is set to "OFF" before checking the operation of the hydraulic unit.

 After operating the ABS, repeat steps (e) to (i), and then fill the brake master cylinder reservoir to the proper level with the specified brake fluid.

### I. Tighten the bleed screw to specification.



Front brake caliper bleed screw 5 Nm (0.5 m·kgf, 3.6 ft·lbf) Rear brake caliper bleed screw 6 Nm (0.6 m·kgf, 4.3 ft·lbf)

m. Fill the brake master cylinder reservoir to the proper level with the specified brake fluid.

Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-14.

#### EWA13110 WARNING

After bleeding the hydraulic brake system, check the brake operation.

### EAS21280

### **CHECKING THE FRONT BRAKE HOSES**

The following procedure applies to all of the brake hoses and brake hose holders.

- 1. Check:
  - Brake hose "1"

Cracks/damage/wear  $\rightarrow$  Replace.



- 2. Check:
  - Brake hose holder
    - Loose  $\rightarrow$  Tighten the holder bolt.
- 3. Hold the vehicle upright and apply the front brake several times.
- 4. Check:
  - Brake hose

Brake fluid leakage  $\rightarrow$  Replace the damaged hose.

Refer to "FRONT BRAKE" on page 4-37.

### EAS21290

### CHECKING THE REAR BRAKE HOSE

- 1. Check:
  - Brake hose "1" Cracks/damage/wear → Replace.



- 2. Check:
  - Brake hose holders Loose connection → Tighten the holder bolt.
- 3. Hold the vehicle upright and apply the rear brake several times.
- 4. Check:
  - Brake hose Brake fluid leakage → Replace the damaged hose.
    - Refer to "REAR BRAKE" on page 4-50.

EAS21320

# ADJUSTING THE REAR BRAKE LOCK CABLE

EWA59C1301

### 

Do not use the rear brake lock lever while driving.

### TIP.

Place the vehicle on the centerstand.

- 1. Measure:
  - Rear brake lock cable length "a" Out of specification → Adjust.

### TIP\_

Measure while the rear brake lock lever is released.



Rear brake lock cable length 43–45 mm (1.69–1.77 in)

- 2. Adjust:
  - Rear brake lock cable length

### \*\*\*\*

a. Turn the rear brake lock cable adjusting nut "1" in direction "b" or "c" until the specified rear brake lock cable free play is obtained.

### Direction "b"

Rear brake lock cable length increased. Direction "c"

Rear brake lock cable length decreased.



### \*\*\*\*\*

- 3. Adjust:
  - Clearance between the brake pad and brake disc.
- \*\*\*\*\*
- a. Remove the cap of the rear brake lock adjusting nut.
- b. Loosen the rear brake lock adjusting nut "1" slightly.
- c. Adjust the piston adjusting bolt "2" so that the wear indicator "3" is placed within the width of the wear indicator groove "4" when the rear brake lock is activated. Recommended procedure:

Tighten the piston adjusting bolt to 3.0 Nm (0.30 m·kgf, 2.2 ft·lbf) and then loosen the bolt 1-1/2 turn.

d. Tighten the rear brake lock adjusting nut while holding the piston adjusting bolt so as not to turn the bolt.



### Rear brake lock adjusting nut 15 Nm (1.5 m·kgf, 11 ft·lbf)

- e. Make sure that the tire can be turned by hand when the rear brake lock is deactivated.
- f. Make sure that the wear indicator is placed within the width of the wear indicator groove when the rear brake lock is activated.



g. Install the cap of the rear brake lock adjusting nut.

\*\*\*\*\*

#### EAS59C1305

### CHECKING THE REAR BRAKE LOCK

- 1. Check:
  - Rear brake lock operation Apply the rear brake lock, and then pushing the vehicle for properly locks the rear brake lock.

Rear brake lock not working properly  $\rightarrow$  Check the rear brake lock cable and rear brake lock pads.

Refer to "ADJUSTING THE REAR BRAKE LOCK CABLE" on page 3-17 and "CHECKING THE REAR BRAKE LOCK PADS" on page 3-19.

- 2. Check:
  - Rear brake lock cable length Out of specification → Adjust. Refer to "ADJUSTING THE REAR BRAKE LOCK CABLE" on page 3-17.
- 3. Check:
  - Wear indicator "1" Check the position of the indicator while applying the rear brake lock lever.
     Passed the wear indicator groove "2" → Adjust the rear brake lock cable length.
     Refer to "ADJUSTING THE REAR BRAKE LOCK CABLE" on page 3-17.



### 4. Check:

 Rear brake lock caliper boots Cracks/damage → Replace. Refer to "REAR BRAKE" on page 4-50.

### EAS59C1301

### CHECKING THE REAR BRAKE LOCK PADS

The following procedure applies to all of the brake pads.

- 1. Operate the rear brake lock.
- 2. Check:
  - Rear brake lock pad Wear indicators "1" almost touch the brake disc → Replace the brake pads as a set.

Refer to "REPLACING THE REAR BRAKE LOCK PADS" on page 4-64.



### EAS21670

### CHECKING THE WHEELS

The following procedure applies to both of the wheels.

- 1. Check:
  - Wheel
- Damage/out-of-round  $\rightarrow$  Replace.

### 

Never attempt to make any repairs to the wheel.

### TIP\_

After a tire or wheel has been changed or replaced, always balance the wheel.

### EAS21650

CHECKING THE TIRES

The following procedure applies to both of the tires.

- 1. Check:
  - Tire pressure

Out of specification  $\rightarrow$  Regulate.



### WARNING

- The tire pressure should only be checked and regulated when the tire temperature equals the ambient air temperature.
- The tire pressure and the suspension must be adjusted according to the total weight (including cargo, rider, passenger and accessories) and the anticipated riding speed.
- Operation of an overloaded vehicle could cause tire damage, an accident or an injury.

NEVER OVERLOAD THE VEHICLE.

<u>/</u> ~	Tire air pressure (measured on
	cold tires)
0	Loading condition
	0–90 kg (0–198 lb)
	Front
	225 kPa (2.25 kgf/cm², 33 psi)
	Rear
	250 kPa (2.50 kgf/cm², 36 psi)
	Loading condition
	90–194 kg (198–428 lb)
	Front
	225 kPa (2.25 kgf/cm², 33 psi)
	Rear
	280 kPa (2.80 kgf/cm², 41 psi)
	Maximum load
	194 kg (428 lb)
* Total and a	weight of rider, passenger, cargo accessories

### EWA13190

It is dangerous to ride with a worn-out tire. When the tire tread reaches the wear limit, replace the tire immediately.

### 2. Check:

• Tire surfaces

Damage/wear  $\rightarrow$  Replace the tire.



- 1. Tire tread depth
- 2. Side wall
- 3. Wear indicator

Wear limit (front) 1.6 mm (0.06 in) Wear limit (rear) 1.6 mm (0.06 in)

### EWA14090

After extensive tests, the tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. The front and rear tires should always be by the same manufacturer and of the same design. No guarantee concerning handling characteristics can be given if a tire combination other than one approved by Yamaha is used on this vehicle.

# X

Front tire

Size 120/70R15 M/C 56H Manufacturer/model DUNLOP/GPR-100F Manufacturer/model BRIDGESTONE/BT011F

### Rear tire Size

160/60R15 M/C 67H Manufacturer/model DUNLOP/GPR-100L Manufacturer/model BRIDGESTONE/BT012R

### EWA13210

New tires have a relatively low grip on the road surface until they have been slightly worn. Therefore, approximately 100 km should be traveled at normal speed before any high-speed riding is done.

### TIP\_

For tires with a direction of rotation mark "1":

- Install the tire with the mark pointing in the direction of wheel rotation.
- Align the mark "2" with the valve installation point.



### EAS30780

### CHECKING THE WHEEL BEARINGS

The following procedure applies to all of the wheel bearings.

- 1. Check:
  - Wheel bearings Refer to "CHECKING THE FRONT WHEEL" on page 4-20 and "CHECKING THE REAR WHEEL" on page 4-32.

### EAS30790

### CHECKING THE SWINGARM

1. Check:

- Swingarm operation Swingarm not working properly → Check the swingarm. Refer to "REMOVING THE SWINGARM" on page 4-99.
- 2. Check:
  - Swingarm excessive play Refer to "REMOVING THE SWINGARM" on page 4-99.

### EAS59C1307

### CHECKING THE DRIVE BELT

- 1. Remove:
  - Drive belt upper guard and lower guard Refer to "REAR WHEEL" on page 4-27.

### 2. Check:

 Drive belt External tooth cracks "A"  $\rightarrow$  Replace. Missing teeth "B"  $\rightarrow$  Replace. Hook wear "C"  $\rightarrow$  Replace. Stone damage "D"  $\rightarrow$  Replace if damage is on the edge. Internal tooth cracks (hairline) "E"  $\rightarrow$  OK to run, but monitor condition. Chipping (not serious) "F"  $\rightarrow$  OK to run, but monitor condition. Fuzzy edge cord "G"  $\rightarrow$  OK to run, but monitor condition Bevel wear (outboard edge only) "H"  $\rightarrow$ OK to run, but monitor condition. Refer to "BELT DRIVE" on page 4-92.

В

D

Α









Е





G





- 3. Install:
  - Drive belt upper guard and lower guard Refer to "REAR WHEEL" on page 4-27.

#### FAS21430 **ADJUSTING THE DRIVE BELT SLACK** ECA59C1301

NOTICE

A drive belt that is too tight will cause loud noises, and one that is too loose can skip and damage the swingarm or cause an accident. Therefore, keep the drive belt slack within the specified limits.

### TIP\_

Measure the drive belt slack when the drive belt is at room temperature, and when the drive belt is dry.

1. Stand the vehicle on a level surface. EWA59C1302

### **WARNING**

### Securely support the vehicle so that there is no danger of it falling over.

### TIP.

Place the vehicle on the centerstand.

- 2. Remove the drive belt upper guard or lower quard.
- 3. Align the rear wheel pulley bolt and center line of the swingarm as shown in the illustration.



4. Set the tension gauge "1" to upside or downside of the drive belt.

### TIP.

To set correctly between protruding portion "2" of the tension gauge and teeth "3" of cog when scaling drive belt slack.

- 5. Measure:
  - Drive belt slack (The scale position "a" on the tension gauge.) Out of specification  $\rightarrow$  Adjust.



3-21

### TIP\_

Measure the drive belt slack after setting the tension gauge at 13.4 position on the scale.





### \*\*\*\*

- a. Turn the handle of the tension gauge until indicator "1" and edge "2" of handle to lap over.
- Read the scale at over lap point, which is current drive belt slack scale.
   Example: 15.1



### \*\*\*\*

- 6. Adjust:
  - Drive belt slack

### \*\*\*\*\*

- a. Loosen the wheel axle nut and both left and right locknuts "1".
- b. Turn both adjusting bolts "2" in direction "a" or "b" until the specified drive belt slack is obtained.

### Direction "a" Drive belt is tightened. Direction "b" Drive belt is loosened.

### TIP\_

- Push the rear wheel forward to make sure that there is no clearance between the adjusting block and the ends of the swingarm.
- After adjusting the drive belt slack to 13.4, measure the distance "c" on the left side and then adjust the distance on the right side to the same value as measured on the left side. The difference in the distance "c" between the left and right sides should be 0.5 mm (0.02 in) or less.



c. Tighten the wheel axle nut to specification.



d. Tighten the locknuts to specification.



#### EAS59C1304 LUBRICATING THE DRIVE PULLEY AND DRIVE AXLE

- 1. Remove:
  - Drive belt upper guard and lower guard Refer to "REAR WHEEL" on page 4-27.
- 2. Remove:
  - Drive belt

Refer to "BELT DRIVE" on page 4-92.

- 3. Remove:
  - Drive pulley cover
  - Refer to "BELT DRIVE" on page 4-92.
    Dust cover Refer to "BELT DRIVE" on page 4-92.
  - Drive pulley assembly Refer to "BELT DRIVE" on page 4-92.
- 4. Clean:
  - Drive axle "1"
  - Drive pulley assembly inner part "2"

- 5. Lubricate:
  - Drive axle "1"



Recommended lubricant YAMAHA GREASE "H" or Polyurea Grease®

- 6. Lubricate:
  - Drive pulley assembly inner part "2"







- 7. Install:
  - All removed parts
- 8. Adjust:
  - Drive belt slack Refer to "ADJUSTING THE DRIVE BELT SLACK" on page 3-21.

### EAS21500

### CHECKING AND ADJUSTING THE STEER-ING HEAD

1. Stand the vehicle on a level surface. EWA13120

### 

# Securely support the vehicle so that there is no danger of it falling over.

### TIP\_

Place the vehicle on a suitable stand so that the front wheel is elevated.

- 2. Check:
  - Steering head Grasp the bottom of the front fork legs and gently rock the front fork. Binding/looseness → Adjust the steering head.
- 3. Remove:
  - Upper bracket Refer to "STEERING HEAD" on page 4-89.
- 4. Adjust:
  - Steering head

### \*\*\*\*

a. Remove the lock washer "1", the upper ring nut "2", and the rubber washer "3".



b. Loosen the lower ring nut "4" and then tighten it to specification with a steering nut wrench "5".

### TIP\_

- Set a torque wrench at a right angle to the steering nut wrench.
- Move the steering to the left and right a couple of time to check that it moves smoothly.



Steering nut wrench 90890-01403 Exhaust flange nut wrench YU-A9472



Lower ring nut (initial tightening torque) 52 Nm (5.2 m·kgf, 38 ft·lbf)

c. Loosen the lower ring nut completely, then tighten it to specification.

### EWA13140

Do not overtighten the lower ring nut.



Lower ring nut (final tightening torque) 14 Nm (1.4 m·kgf, 10 ft·lbf)

d. Check the steering head for looseness or binding by turning the front fork all the way in both directions. If any binding is felt, remove the lower bracket and check the upper and lower bearings. Refer to "STEERING HEAD" on page 4-89.

- e. Install the rubber washer "3".
- f. Install the upper ring nut "2".
- g. Finger tighten the upper ring nut "2", then align the slots of both ring nuts. If necessary, hold the lower ring nut and tighten the upper ring nut until their slots are aligned.
- h. Install the lock washer "1".

### TIP.

Make sure the lock washer tabs "a" sit correctly in the ring nut slots "b".



### \*\*\*\*

5. Install:

• Upper bracket Refer to "STEERING HEAD" on page 4-89.

#### EAS30840 CHECKING THE CHASSIS FASTENERS

Make sure that all nuts, bolts, and screws are properly tightened.

Refer to "CHASSIS TIGHTENING TORQUES" on page 2-18.

EAS21700

### LUBRICATING THE LEVERS

Lubricate the pivoting point and metal-to-metal moving parts of the levers.



Recommended lubricant Silicone grease

#### EAS30850 CHECKING THE SIDESTAND

- 1. Check:
  - Sidestand operation Check that the sidestand moves smoothly.
     Rough movement → Repair or replace.

### EAS21720

### LUBRICATING THE SIDESTAND

Lubricate the pivoting point, metal-to-metal moving parts and spring contact point of the sidestand.



#### Recommended lubricant Lithium-soap-based grease

### Lithium-soap-based grea

EAS30860

### CHECKING THE CENTERSTAND

- 1. Check:
  - Centerstand operation Check that the centerstand moves smoothly.

Rough movement  $\rightarrow$  Repair or replace.

### EAS21730

### LUBRICATING THE CENTERSTAND

Lubricate the pivoting point, metal-to-metal moving parts and spring contact point of the centerstand.



#### Recommended lubricant Lithium-soap-based grease

### EAS30870

**CHECKING THE SIDESTAND SWITCH** Refer to "CHECKING THE SWITCHES" on page 8-123.

### EAS21531

### CHECKING THE FRONT FORK

1. Stand the vehicle on a level surface.

### 

Securely support the vehicle so that there is no danger of it falling over.

- 2. Check:
  - Inner tube
    - Damage/scratches  $\rightarrow$  Replace.
  - Front fork leg
     Oil leaks between inner tube and outer
     tube → Replace the oil seal.
- 3. Hold the vehicle upright and apply the front brake.
- 4. Check:
  - Front fork operation

Push down hard on the handlebar several times and check if the front fork rebounds smoothly.

Rough movement  $\rightarrow$  Repair. Refer to "FRONT FORK" on page 4-81.



### EAS59C1306

### CHECKING THE REAR SHOCK ABSORBER ASSEMBLY

- 1. Check:
  - Rear shock absorber assembly operation Push down hard on the seat several times and check if the rear shock absorber rebound smoothly.
     Rough movement → Replace.
     Refer to "REAR SHOCK ABSORBER ASSEMBLY" on page 4-94.
- 2. Check:
  - Rear shock absorber assembly Gas leaks/oil leaks → Replace.
     Refer to "REAR SHOCK ABSORBER ASSEMBLY" on page 4-94.

### EAS20731

### CHECKING THE ENGINE OIL LEVEL

- 1. Stand the vehicle on a level surface.
- TIP\_
- Place the vehicle on the centerstand.
- Make sure the vehicle is upright.
- 2. Start the engine, warm it up for several minutes, and then turn it off.
- 3. Check:
  - Engine oil level

The engine oil level should be between the minimum level mark "a" and maximum level mark "b".

Below the minimum level mark  $\rightarrow$  Add the recommended engine oil to the proper level.


Type SAE 10W-30 or SAE 10W-40 Recommended engine oil grade API service SG type or higher, JASO standard MA



ECA13361 **NOTICE** 

- Engine oil also lubricates the clutch and the wrong oil types or additives could cause clutch slippage. Therefore, do not add any chemical additives or use engine oils with a grade of "CD" or higher and do not use oils labeled "ENERGY CONSERV-ING II".
- Do not allow foreign materials to enter the crankcase.

#### TIP\_

Before checking the engine oil level, wait a few minutes until the oil has settled.

- 4. Start the engine, warm it up for several minutes, and then turn it off.
- 5. Check the engine oil level again.

#### TIP\_

Before checking the engine oil level, wait a few minutes until the oil has settled.

#### EAS20791 CHANGING THE ENGINE OIL

- 1. Start the engine, warm it up for several minutes, and then turn it off.
- 2. Place a container under the engine oil drain bolt.
- 3. Remove:
  - Engine oil filler cap "1" (along with the O-ring)
  - Engine oil drain bolt "2" (along with the gasket)





- 4. Drain:
  - Engine oil (completely from the crankcase)
- 5. If the oil filter cartridge is also to be replaced, perform the following procedure.
- \*\*\*\*\*
- a. Remove the oil filter cartridge "1" with an oil filter wrench "2".



Oil filter wrench 90890-01469 YM-01469



 Lubricate the O-ring "3" of the new oil filter cartridge with a thin coat of lithium-soapbased grease.

#### NOTICE

Make sure the O-ring "3" is positioned correctly in the groove of the oil filter cartridge.



c. Tighten the new oil filter cartridge to specification with an oil filter wrench.

> Oil filter cartridge 17 Nm (1.7 m·kgf, 12 ft·lbf)

- 6. Install:
  - Engine oil drain bolt

(along with the gasket New)

#### TIP.

Lubricate the O-ring of the engine oil drain bolt with a thin coat of lithium-soap-based grease.

# Engine oil drain bolt 43 Nm (4.3 m·kgf, 31 ft·lbf)

- 7. Fill:
  - Crankcase

(with the specified amount of the recommended engine oil)

### Engine oil quantity Total amount 3.50 L (3.70 US qt, 3.08 Imp.qt) Without oil filter cartridge replacement 2.70 L (2.85 US qt, 2.38 Imp.qt) With oil filter cartridge replacement 2.90 L (3.07 US qt, 2.55 Imp.qt)

- 8. Install:
  - Engine oil filler cap

(along with the O-ring New)

- 9. Start the engine, warm it up for several minutes, and then turn it off.
- 10. Check:
  - Engine
    - (for engine oil leaks)
- 11. Check:
  - Engine oil level Refer to "CHECKING THE ENGINE OIL LEVEL" on page 3-25.
- 12. Check:
  - Engine oil pressure
- \*\*\*\*
- Remove the bottom side cowling and bottom center cowling.
   Refer to "GENERAL CHASSIS" on page 4-1.
- b. Slightly loosen the oil check bolt "1".



- c. Start the engine and keep it idling until engine oil starts to seep from the oil check bolt. If no engine oil comes out after one minute, turn the engine off so that it will not seize.
- check the engine oil passages, the oil filter cartridge and the oil pump for damage or leakage.
   Refer to "OIL PUMP" on page 5-65.
- e. Start the engine after solving the problem(s) and check the engine oil pressure again.

f. Tighten the oil check bolt to specification.



#### Engine oil check bolt 20 Nm (2.0 m·kgf, 14 ft·lbf)

g. Install the bottom side cowling and bottom center cowling.

Refer to "GENERAL CHASSIS" on page 4-1.

\*\*\*\*\*

#### EAS20820

#### MEASURING THE ENGINE OIL PRESSURE 1. Check:

- Engine oil level Below the minimum level mark → Add the recommended engine oil to the proper level.
- 2. Start the engine, warm it up for several minutes, and then turn it off.

# ECA13410

NOTICE

When the engine is cold, the engine oil will have a higher viscosity, causing the engine oil pressure to increase. Therefore, be sure to measure the engine oil pressure after warming up the engine.

- 3. Remove:
  - Engine oil pressure check point plug "1" (Bottom of the crankcase)

# EWA12980

# The engine, muffler and engine oil are extremely hot.



- 4. Install:
  - Oil pressure gauge "1"
  - Adapter "2"



# Oil pressure gauge set 90890-03120

or Oil pressure adapter B 90890-03124 Pressure gauge 90890-03153 YU-03153



- 5. Measure:
  - Engine oil pressure (at the following conditions)



Out of specification $\rightarrow$	<ul> <li>Adjust</li> </ul>
------------------------------------	----------------------------

Engine oil pressure	Possible causes
Below specification	<ul> <li>Faulty oil pump</li> <li>Clogged oil filter</li> <li>Leaking oil passage</li> <li>Broken or damaged oil seal</li> </ul>
Above specification	<ul> <li>Leaking oil passage</li> <li>Faulty oil filter</li> <li>Oil viscosity too high</li> </ul>

### 6. Install:

• Engine oil pressure check point plug

TIP\_

Lubricate the O-ring of the engine oil pressure check point plug with a thin coat of lithiumsoap-based grease.



# Engine oil pressure check point plug

12 Nm (1.2 m·kgf, 8.7 ft·lbf)

#### EAS21110 CHECKING THE COOLANT LEVEL

- 1. Stand the vehicle on a level surface.
- TIP\_
- Place the vehicle on the centerstand.
- Make sure the vehicle is upright.

#### 2. Check:

Coolant level

The coolant level should be between the maximum level mark "a" and minimum level mark "b".

Below the minimum level mark  $\rightarrow$ Remove the left footboard mat, coolant reservoir cap access panel "1", and coolant reservoir cap, and then add the recommended coolant to the proper level.





# ECA13470

- NOTICE
- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available, soft water may be used.

- 3. Start the engine, warm it up for several minutes, and then turn it off.
- 4. Check:
  - Coolant level

### TIP.

Before checking the coolant level, wait a few minutes until it settles.

### EAS21120

#### CHECKING THE COOLING SYSTEM 1. Remove:

- Center cover Refer to "GENERAL CHASSIS" on page 4-1.
- Side covers Refer to "GENERAL CHASSIS" on page 4-1.
- Footboards Refer to "GENERAL CHASSIS" on page 4-1.
- 2. Check:
  - Radiator "1"
    - Radiator inlet hose "2"
    - Radiator outlet hose "3"
    - Oil cooler inlet hose "4"
    - Oil cooler outlet hose "5"
    - Oil cooler "6"
    - Thermostat outlet hose "7"
    - Water pump "8"
    - Water pump inlet pipe "9"
    - Water pump outlet pipe "10"
    - Radiator filler pipe "11"
    - Radiator filler hose "12"
    - Coolant pipe "13" Cracks/damage → Replace. Refer to "RADIATOR" on page 6-1, "THERMOSTAT" on page 6-7 and "WATER PUMP" on page 6-9.



3-29

## 3. Install:

- Footboards Refer to "GENERAL CHASSIS" on page 4-1.
- Side covers Refer to "GENERAL CHASSIS" on page 4-1.
- Center cover Refer to "GENERAL CHASSIS" on page 4-1.

#### EAS21131

# CHANGING THE COOLANT

- 1. Remove:
  - Center cover Refer to "GENERAL CHASSIS" on page 4-1.
  - Side cover (left) Refer to "GENERAL CHASSIS" on page 4-1.
  - Footboard (left) Refer to "GENERAL CHASSIS" on page 4-1.
- 2. Disconnect:
  - Coolant reservoir hose "1"



- 3. Drain:
  - Coolant

(from the coolant reservoir)

- 4. Remove:
  - Radiator cap "1"

# EWA13030

A hot radiator is under pressure. Therefore, do not remove the radiator cap when the engine is hot. Scalding hot fluid and steam may be blown out, which could cause serious injury. When the engine has cooled, open the radiator cap as follows: Place a thick rag or a towel over the radiator cap and slowly turn the radiator cap counterclockwise toward the detent to allow any residual pressure to escape. When the hissing sound has stopped,

# press down on the radiator cap and turn it counterclockwise to remove.

#### TIP.

When removing the radiator cap, hold the radiator filler pipe "2".



5. Remove:
Coolant drain bolt "1" (along with the O-ring)



- 6. Drain:
  - Coolant
    - (from the engine and radiator)
- 7. Install:
  - Coolant drain bolt
    - (along with the O-ring New)



- 8. Connect:
  - Coolant reservoir hose
- 9. Fill:
  - Cooling system (with the specified amount of the recommended coolant)

### Recommended antifreeze High-quality ethylene glycol antifreeze containing corrosion inhibitors for aluminum engines Mixing ratio 1:1 (antifreeze:water) Radiator capacity (including all routes) 1.50 L (1.59 US qt, 1.32 Imp.qt) Coolant reservoir capacity (up to the maximum level mark) 0.27 L (0.29 US qt, 0.24 Imp.qt)

Handling notes for coolant

Coolant is potentially harmful and should be handled with special care.

# EWA13040

- If coolant splashes in your eyes, thoroughly wash them with water and consult a doctor.
- If coolant splashes on your clothes, quickly wash it away with water and then with soap and water.
- If coolant is swallowed, induce vomiting and get immediate medical attention.

#### ECA13480 **NOTICE**

- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available, soft water may be used.
- If coolant comes into contact with painted surfaces, immediately wash them with water.

## • Do not mix different types of antifreeze.

- 10. Install:
  - Radiator cap
- 11. Fill:
  - Coolant reservoir
    - (with the recommended coolant to the maximum level mark "a")



## 12. Install:

- Coolant reservoir cap
- 13. Start the engine, warm it up for several minutes, and then stop it.
- 14. Check:
  - Coolant level Refer to "CHECKING THE COOLANT LEVEL" on page 3-29.

#### TIP\_

Before checking the coolant level, wait a few minutes until the coolant has settled.

15. Install:

- Footboard (left) Refer to "GENERAL CHASSIS" on page 4-1.
- Side cover (left) Refer to "GENERAL CHASSIS" on page 4-1.
- Center cover Refer to "GENERAL CHASSIS" on page 4-1.

#### EAS4B51007 REPLACING THE V-BELT

- 1. Remove:
  - Center cover Refer to "GENERAL CHASSIS" on page 4-1.
  - Side cover (right) Refer to "GENERAL CHASSIS" on page 4-1.
  - Footboard (right) Refer to "GENERAL CHASSIS" on page 4-1.
  - Outer V-belt case Refer to "V-BELT AUTOMATIC TRANS-MISSION" on page 5-39.

## 2. Check:

V-belt

Cranks/damage/wear  $\rightarrow$  Replace. Grease/oil  $\rightarrow$  Clean the primary and secondary pulleys. Refer to "V-BELT AUTOMATIC TRANS-MISSION" on page 5-39.

#### TIP.

Replace the V-belt every 20000 km (12500 mi) of operation.

## 3. Install:

- Outer V-belt case Refer to "V-BELT AUTOMATIC TRANS-MISSION" on page 5-39.
- Footboard (right) Refer to "GENERAL CHASSIS" on page 4-1.
- Side cover (right) Refer to "GENERAL CHASSIS" on page 4-1.
- Center cover Refer to "GENERAL CHASSIS" on page 4-1.

## EAS30960

## CHECKING THE BRAKE LIGHT SWITCHES

- 1. Check:
  - Front brake light switch operation
  - Rear brake light switch operation When operating the brake lever, confirm that the brake light comes on.
     Faulty → Refer to "CHECKING THE SWITCHES" on page 8-123.

#### EAS21690

# CHECKING AND LUBRICATING THE CABLES

The following procedure applies to all of the inner and outer cables.

# WARNING

Damaged outer cable may cause the cable to corrode and interfere with its movement. Replace damaged outer cable and inner cables as soon as possible.

- 1. Check:
  - Outer cable
    - $\mathsf{Damage} \to \mathsf{Replace}.$
- 2. Check:
  - Cable operation

Rough movement  $\rightarrow$  Lubricate.



Recommended lubricant Engine oil or a suitable cable lubricant

### TIP.

Hold the cable end upright and pour a few drops of lubricant into the cable sheath or use a suitable lubricating device.

### EAS21740

## LUBRICATING THE REAR SUSPENSION

Lubricate the pivoting point and metal-to-metal moving parts of the rear suspension.



Recommended lubricant Lithium-soap-based grease

#### EAS30890 CHECKING THE THROTTLE GRIP

- 1. Check:
  - Throttle cables Damage/deterioration  $\rightarrow$  Replace.
  - Throttle cable installation Incorrect → Reinstall the throttle cables. Refer to "HANDLEBAR" on page 4-76.
- 2. Check:
  - Throttle grip movement Rough movement → Lubricate or replace the defective part(s).



Recommended lubricant Suitable cable lubricant

With the engine stopped, turn the throttle grip slowly and release it. Make sure that the throttle grip turns smoothly and returns properly when released.

Repeat this check with the handlebar turned all the way to the left and right.

- 3. Check:
  - Throttle grip free play "a" Out of specification → Adjust.



Throttle grip free play 3.0–5.0 mm (0.12–0.20 in)

TIP.



- 4. Adjust:
  - Throttle grip free play

TIP\_\_\_

Prior to adjusting the throttle grip free play, throttle body synchronization should be adjusted properly.

#### \*\*\*\*

- a. Slide back the rubber cover "1".
- b. Loosen the locknut "2".
- c. Turn the adjusting nut "3" in direction "a" or "b" until the specified throttle grip free play is obtained.

Direction "a" Throttle grip free play is increased. Direction "b" Throttle grip free play is decreased.



d. Tighten the locknut.



e. Slide the rubber cover to its original position.

TIP

Make sure that the adjusting nut is covered completely by the rubber cover.

#### \*\*\*\*\*

#### EAS21760 CHECKING AND CHARGING THE BATTERY

Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-127.

### EAS21770

### **CHECKING THE FUSES**

Refer to "CHECKING THE FUSES" on page 8-127.

#### EAS21790

### **REPLACING THE HEADLIGHT BULBS**

The following procedure applies to both of the headlight bulbs.

- 1. Remove:
  - Front cover Refer to "GENERAL CHASSIS" on page 4-1.
- 2. Disconnect:
  - Headlight coupler "1"



- 3. Remove:
  - Headlight bulb "1"

# EWA13320

Since the headlight bulb gets extremely hot, keep flammable products and your hands away from the bulb until it has

cooled down.



- 4. Install:
  - Headlight bulb New

# ECA13690

NOTICE

Avoid touching the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the life of the bulb and the luminous flux will be adversely affected. If the headlight bulb gets soiled, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.

5. Connect:Headlight coupler

- 6. Install:
  - Front cover Refer to "GENERAL CHASSIS" on page 4-1.

## EAS21810

# ADJUSTING THE HEADLIGHT BEAMS

The following procedure applies to both of the headlights.

- 1. Adjust:
  - Headlight beam (vertically)

## \*\*\*\*

 a. Turn the adjusting screw "1" in direction "a" or "b".

#### TIP\_

Other than the socket wrench, the adjusting screws can be turned with a screwdriver (Phillips No. 2) "2" as shown in the illustration.





#### \*\*\*\*\*

- 2. Adjust:
  - Headlight beam (horizontally)
- a. Turn the adjusting screw "1" in direction "a" or "b".

#### TIP\_

Other than the socket wrench, the adjusting screws can be turned with a screwdriver (Phillips No. 2) "2" as shown in the illustration.

Left headlight

Direction "a" Headlight beam moves to the left. Direction "b" Headlight beam moves to the right.

**Right headlight** 

Direction "a"

Headlight beam moves to the right. Direction "b" Headlight beam moves to the left.



# CHASSIS

GENERAL CHASSIS	4-1
REMOVING THE WINDSHIELD	4-9
INSTALLING THE WINDSHIELD	4-9
ADJUSTING THE WINDSHIELD HEIGHT	4-10
REMOVING THE FRONT COVER	4-10
INSTALLING THE FRONT COVER	4-11
REMOVING THE WINDSHIELD INNER PANEL	4-11
INSTALLING THE WINDSHIELD INNER PANEL	4-12
REMOVING THE SIDE PANEL	4-12
INSTALLING THE SIDE PANEL	4-12
REMOVING THE CENTER COVER	4-13
INSTALLING THE CENTER COVER	4-13
REMOVING THE SIDE COVER	4-13
INSTALLING THE SIDE COVER	4-13
REMOVING THE SIDE COVER MOULDING	4-14
INSTALLING THE SIDE COVER MOULDING	4-14
REMOVING THE FOOTBOARD	4-14
INSTALLING THE FOOTBOARD	4-15
REMOVING THE REAR COVER	4-15
INSTALLING THE REAR COVER	4-16
REMOVING THE INNER PANEL CENTER COVER	4-16
INSTALLING THE INNER PANEL CENTER COVER	4-16
REMOVING THE FUEL HOSE	4-17
INSTALLING THE FUEL HOSE	4-17
FRONT WHEEL	4-18
BEMOVING THE FRONT WHEEL	4-20
DISASSEMBI ING THE FRONT WHEEI	4-20
CHECKING THE FRONT WHEEL	4-20
MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR	+ 20
BOTOR	4-21
ASSEMBLING THE FRONT WHEEL	4-22
ADJUSTING THE FRONT WHEEL STATIC BALANCE	4-23
INSTALLING THE FRONT WHEEL (DISCS)	4-24
	4 07
	4-27
	4-31 1 01
	4-01
	4-32
	4-32 1 20
	4-32
	4 00
	4-33
	4-33
	4-34
	4-34

FRONT BRAKE	4-37
INTRODUCTION	4-42
CHECKING THE FRONT BRAKE DISCS	4-42
REPLACING THE FRONT BRAKE PADS	4-43
REMOVING THE FRONT BRAKE CALIPERS	4-44
DISASSEMBLING THE FRONT BRAKE CALIPERS	4-44
CHECKING THE FRONT BRAKE CALIPERS	
ASSEMBLING THE FRONT BRAKE CALIPERS	
INSTALLING THE FRONT BRAKE CALIPERS	
REMOVING THE FRONT BRAKE MASTER CYLINDER	4-47
CHECKING THE FRONT BRAKE MASTER CYLINDER	4-47
ASSEMBLING THE FRONT BRAKE MASTER CYLINDER	4-47
INSTALLING THE FRONT BRAKE MASTER CYLINDER	4-48
REAR BRAKE	4-50
INTRODUCTION	4-58
CHECKING THE REAR BRAKE DISC	4-58
REPLACING THE REAR BRAKE PADS	4-58
REMOVING THE REAR BRAKE CALIPER	4-59
DISASSEMBLING THE REAR BRAKE CALIPER	4-60
CHECKING THE REAR BRAKE CALIPER	
ASSEMBLING THE REAR BRAKE CALIPER	4-61
INSTALLING THE REAR BRAKE CALIPER	4-61
REMOVING THE REAR BRAKE MASTER CYLINDER	4-62
CHECKING THE REAR BRAKE MASTER CYLINDER	
ASSEMBLING THE REAR BRAKE MASTER CYLINDER	4-62
INSTALLING THE REAR BRAKE MASTER CYLINDER	
REPLACING THE REAR BRAKE LOCK PADS	
REPLACING THE REAR BRAKE LOCK CABLE	4-65
REMOVING THE REAR BRAKE LOCK CALIPER	4-66
CHECKING THE BEAR BRAKE LOCK CALIPER	4-66
ASSEMBLING THE BEAB BRAKE LOCK CALIPER	4-66
INSTALLING THE REAR BRAKELOCK CALIPER	4-67
ABS (ANTI-LOCK BRAKE SYSTEM)	4-68
REMOVING THE HYDRAULIC UNIT ASSEMBLY	4-70
CHECKING THE HYDRAULIC UNIT ASSEMBLY	4-70
CHECKING THE BRAKE PIPES	4-71
INSTALLING THE HYDRAULIC UNIT ASSEMBLY	4-71
HYDRAULIC UNIT OPERATION TESTS	4-72
CHECKING THE ABS WARNING LIGHT	4-75
HANDI FRAR	4-76
REMOVING THE HANDI ERAR	

FRONT FORK	4-81
REMOVING THE FRONT FORK LEGS	4-83
DISASSEMBLING THE FRONT FORK LEGS	4-83
CHECKING THE FRONT FORK LEGS	4-84
ASSEMBLING THE FRONT FORK LEGS	4-85
INSTALLING THE FRONT FORK LEGS	4-87
STEERING HEAD	4-89
REMOVING THE LOWER BRACKET	4-90
CHECKING THE STEERING HEAD	
INSTALLING THE STEERING HEAD	4-91
BELT DRIVE	4-92
CHECKING THE DRIVE BELT	4-93
INSTALLING THE DRIVE BELT	
REAR SHOCK ABSORBER ASSEMBLY	4-94
HANDLING THE BEAR SHOCK ABSORBER	4-95
DISPOSING OF A BEAB SHOCK ABSOBBER	4-95
REMOVING THE REAR SHOCK ABSORBER ASSEMBLY	4-95
CHECKING THE REAR SHOCK ABSORBER ASSEMBLY	
INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY	
SWINGARM	4-97
BEMOVING THE SWINGARM	۲۰۵۲ ۵-۵۹
CHECKING THE SWINGARM	4-99
INSTALLING THE SWINGARM	

# GENERAL CHASSIS

















#### EAS59C1407 REMOVING THE WINDSHIELD

- 1. Remove:
  - Windshield cover



#### \*\*\*\*

a. Remove the quick fastener "1".



b. Slide it upwards and pull it toward you.

#### \*\*\*\*

- 2. Remove:
  - Windshield

#### \*\*\*\*

- a. Removing the windshield bracket bolts "1".
- b. Removing the windshield assembly.
- c. Removing the windshield screws "2".
- d. Removing the windshield brackets "3".



#### \*\*\*\*\*

EAS59C1408

## INSTALLING THE WINDSHIELD

- 1. Install:
  - Windshield

#### \*\*\*\*

- Assembling the windshield "1" and windshield brackets "2" with the windshield screws "3".
- b. Installing the windshield assembly with the windshield bracket bolts "4".



Windshield screw 0.5 Nm (0.05 m·kgf, 0.36 ft·lbf) Windshield bracket bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)



# 2. Install:

- Install:
- Windshield cover



#### \*\*\*\*

- a. Insert the projection into the hole and slide it downwards.
- b. Installing the quick fastener "1".



. . . . . . . . . . . . . . . . .

## EAS59C1427

# ADJUSTING THE WINDSHIELD HEIGHT

- Adjust:
   Windshield height
- Remove the windshield cover and windshield assembly.
   Refer to "REMOVING THE WINDSHIELD" on page 4-9.
- b. Remove the rubber caps "1".



c. Install the rubber caps "1" in the desired position.



d. Install the windshield assembly to the desired position by installing the bolts "1".



e. Tighten the bolts to the specified torque.

Windshield bracket bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

f. Installing the windshield cover. Refer to "INSTALLING THE WINDSHIELD" on page 4-9.

#### EAS59C1409 REMOVING THE FRONT COVER

- 1. Remove:
  - Front cover



#### \*\*\*\*

a. Remove the two metal clips "1" and six claws "2" from the front cover.



b. Pull the three projections "3" of the front cover to the front side and remove them.



- c. Remove the quick fastener "4".
- d. Remove the two claws "5" from the end of the front cover.

# **GENERAL CHASSIS**



- \*\*\*\*\*
- EAS59C1410
- INSTALLING THE FRONT COVER
- 1. Install:
  - Front cover



#### \*\*\*\*\*

a. Insert the three projections "1" of the front cover.



- b. Fit the two claws "2" of the end of the front cover.
- c. Installing the quick fastener "3".



d. Fit the two metal clips "4" and six claws "5" of the front cover.



## \*\*\*\*

#### EAS59C1411 REMOVING THE WINDSHIELD INNER PANEL

- 1. Remove:
  - Windshield inner panel



#### \*\*\*\*

- a. Removing the quick fasteners "1".
- b. Removing the bolts "2".
- c. Pull the two projections "3" of the windshield inner panel to the front side and remove them.

# **GENERAL CHASSIS**



#### \*\*\*\*

# EAS59C1412

# INSTALLING THE WINDSHIELD INNER PANEL

- 1. Install:
  - Windshield inner panel



#### \*\*\*\*

- a. Insert the two projections "1" of the windshield inner panel.
- b. Installing the bolts "2".
- c. Installing the quick fasteners "3".



#### \*\*\*\*\*

#### EAS59C1413

#### **REMOVING THE SIDE PANEL**

## 1. Remove:

• Side panel



#### \*\*\*\*

- a. Removing the quick fasteners "1".
- b. Removing the screws "2".
- c. Remove the metal clip "3".



#### **\*\*\***

#### EAS59C1414 INSTALLING THE SIDE PANEL

- 1. Install:
  - Side panel



#### \*\*\*\*

- a. Insert the metal clip "1".
- b. Installing the screws "2".
- c. Installing the quick fasteners "3".



#### \*\*\*\*\*

#### EAS59C1415

## **REMOVING THE CENTER COVER**

- 1. Remove:
  - Center cover



# 

- a. Removing the screws "1".
- b. Use an appropriate hook from the service hole "2" to raise the center cover.
- c. When the center cover is raised, pull the center cover upwards and remove the four claws "3".



#### \*\*\*\*\*

## EAS59C1416

# INSTALLING THE CENTER COVER

- 1. Install:
  - Center cover



- \*\*\*\*
- a. Insert the four claws "1".
- b. Installing the screws "2".



#### EAS59C1417 REMOVING THE SIDE COVER

- 1. Remove:
  - Side cover



#### \*\*\*\*

- a. Removing the bolts "1".
- b. Pull the five claws "2" outside of the vehicle and raise them.
- c. When the side cover is raised, pull the side cover outsides of the vehicle and remove the five projections "3".



## EAS59C1418

# INSTALLING THE SIDE COVER

- 1. Install:
  - Side cover

# **GENERAL CHASSIS**



- a. Insert the five projections "1".
- b. Insert the five claws "2".
- c. Installing the bolts "3".



#### EAS59C1419

## **REMOVING THE SIDE COVER MOULDING**

- 1. Remove:
  - Side cover moulding



- a. Removing the quick fastener "1".
- b. Removing the screws "2".
- c. Pull the side moulding outside of the vehicle and remove the five claws "3".



# EAS59C1420 INSTALLING THE SIDE COVER MOULDING

- 1. Install:
  - Side cover moulding



- a. Insert the five claws "1".
- b. Installing the screws "2".
- c. Installing the quick fastener "3".



- EAS59C1421 REMOVING THE FOOTBOARD
- 1. Remove:
  - Footboard



- \*\*\*\*
- a. Removing the screws "1".
- b. Removing the bolts "2".

# **GENERAL CHASSIS**



В



- A. Left side
- B. Right side
- c. Remove the three claws "3".
- d. Slide the footboard upwards, pull it toward you, and then remove it.



#### 

#### EAS59C1422

## **INSTALLING THE FOOTBOARD**

- 1. Install:
  - Footboard



- a. Insert the three hooks of the footboard.

b. Fit the three claws "1".



- c. Installing the bolts "2".d. Installing the screws "3".





- A. Left side
- B. Right side

## \*\*\*\*\*

## EAS59C1423

- **REMOVING THE REAR COVER**
- 1. Remove:
  - · Rear cowling



- a. Removing the quick fasteners "1".

b. Holding the rear side of the rear cover and slightly applying a force upward, slide the cover rearward to remove it.



# EAS59C1424 INSTALLING THE REAR COVER

- 1. Install:
  - Rear cowling



- a. Insert the four claws "1" of the rear cover though the holes of the rear cowling assembly. Slide the cover forward to install it.
- b. Installing the quick fasteners "2".



#### EAS59C1425

## **REMOVING THE INNER PANEL CENTER** COVER

- 1. Remove:
  - Inner panel center cover



- a. Removing the screws "1".
- b. There are six claws "2". Remove them, starting from the top.



#### . . . . .

# EAS59C1426 INSTALLING THE INNER PANEL CENTER COVER

- 1. Install:
  - Inner panel center cover



- a. Fit the six claws "1", starting from the bottom.
- b. Installing the screws "2".



#### EAS59C1428 REMOVING THE FUEL HOSE

- 1. Remove:
  - Fuel hose connector cover "1"
- 2. Disconnect:
  - Fuel hose "2"

EWA15910

#### A WARNING

Cover fuel hose connections with a cloth when disconnecting them. Residual pressure in the fuel lines could cause fuel to spurt out when removing the hose.

#### ECA59C1701

#### NOTICE

- Be sure to disconnect the fuel hose by hand. Do not forcefully disconnect the hose with tools.
- Although the fuel has been removed from the fuel tank, be careful when removing the fuel hose, since there may be fuel remaining in it.
- Do not disconnect the fuel hose from the fuel hose connector. Disconnect the connector from the fuel pump.

#### TIP\_

Before removing the hose, place a few rags in the area under where it will be removed.





#### EAS59C1429

### INSTALLING THE FUEL HOSE

- 1. Connect:
  - Fuel hose

- 2. Install:
- Fuel hose connector cover ECA59C1702

#### NOTICE

When installing the fuel hose, make sure that it is securely connected, and that the fuel hose connector cover is in the correct position, otherwise the fuel hose will not be properly installed.

#### TIP\_

- Wipe up any fuel remaining in the recess "a" in the fuel pump with a dry rag "1".
- After installing the fuel hose connector cover, make sure that it is installed securely.



#### EAS21870 FRONT WHEEL



5	I TOTIL DIAKE Caliper	~	
6	Front wheel axle pinch bolt	1	Loosen.
7	Front wheel axle	1	
8	Front wheel	1	
9	Front wheel sensor housing	1	
10	Collar	1	Length: 12 mm (0.47 in)
11	Collar	1	Length: 18 mm (0.71 in)
12	Front brake disc	2	
13	Front fender	1	
			For installation, reverse the removal proce- dure.

# **FRONT WHEEL**



#### EAS21900 REMOVING THE FRONT WHEEL ECA59C2405

#### NOTICE

Keep magnets (including magnetic pick-up tools, magnetic screwdrivers, etc.) away from the front wheel hub "1", otherwise the wheel sensor rotor equipped in the wheel hub may be damaged, resulting in improper performance of the ABS system.



1. Stand the vehicle on a level surface. EWA13120

### 

Securely support the vehicle so that there is no danger of it falling over.

- 2. Remove:
  - Front wheel sensor
  - Front brake calipers

#### TIP\_

Do not apply the brake lever when removing the brake calipers.

- 3. Elevate:
  - Front wheel

#### TIP\_

Place the vehicle on a suitable stand so that the front wheel is elevated.

- 4. Loosen:
  - Front wheel axle pinch bolt
- 5. Remove:
  - Front wheel axle
  - Front wheel sensor housing
  - Collars
  - Front wheel

#### EAS21910

## DISASSEMBLING THE FRONT WHEEL ECA59C2406

#### NOTICE

• Keep magnets (including magnetic pickup tools, magnetic screwdrivers, etc.) away from the wheel sensor rotor.

- Do not drop the wheel sensor rotor or subject it to shocks.
- If any solvent gets on the wheel sensor rotor, wipe it off immediately.
- 1. Remove:
  - Front wheel sensor rotor
  - Oil seals
  - Wheel bearings

#### \*\*\*\*

- a. Remove the front wheel sensor rotor.
- b. Clean the surface of the front wheel hub.
- c. Remove the oil seals "1" with a flat-head screwdriver.

#### TIP\_

To prevent damaging the wheel, place a rag "2" between the screwdriver and the wheel surface.



d. Remove the wheel bearings "3" with a general bearing puller.



#### \*\*\*\*

### 2. Remove:

• Air valve

### EAS21922

# CHECKING THE FRONT WHEEL

- 1. Check:
  - Wheel axle Roll the wheel axle on a flat surface.
     Bends → Replace.

## EWA13460

**WARNING** 

Do not attempt to straighten a bent wheel axle.



- 2. Check:
  - Tire
    - Front wheel
    - Damage/wear  $\rightarrow$  Replace. Refer to "CHECKING THE TIRES" on page 3-19 and "CHECKING THE WHEELS" on page 3-19.
- 3. Measure:
  - Radial wheel runout "1"
  - Lateral wheel runout "2"
    - Over the specified limits  $\rightarrow$  Replace.

Radial wheel runout limit 1.0 mm (0.04 in) Lateral wheel runout limit 0.5 mm (0.02 in)



- 4. Check:
  - Wheel bearings
     Front wheel turns roughly or is loose →
    - Replace the wheel bearings.
  - Oil seals Damage/wear → Replace.



EAS22010

MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR ECA59C2407

NOTICE

- Handle the ABS components with care since they have been accurately adjusted. Keep them away from dirt and do not subject them to shocks.
- The front wheel sensor cannot be disassembled. Do not attempt to disassemble it. If faulty, replace with a new one.
- Keep magnets (including magnetic pickup tools, magnetic screwdrivers, etc.) away from the wheel sensor rotor.
- Do not drop or shock the wheel sensor or the wheel sensor rotor.
- 1. Check:
  - Front wheel sensor "1" Cracks/bends/distortion → Replace. Iron powder/dust → Clean.



- 2. Check:
  - Front wheel sensor rotor "1" Cracks/damage/scratches → Replace the front wheel sensor rotor. Iron powder/dust/solvent → Clean.

TIP\_

- The wheel sensor rotor is installed on the inner side of the wheel hub.
- When cleaning the wheel sensor rotor, be careful not to damage the surface of the rotor magnet.



- 3. Measure:
  - Front wheel sensor rotor deflection Out of specification → Clean the installation surface of the wheel sensor rotor and correct the wheel sensor rotor deflection, or replace the wheel sensor rotor.



#### \*\*\*\*

- a. Hold the dial gauge at a right angle against the wheel sensor rotor surface.
- b. Measure the deflection 6 mm (0.24 in) below the edge of the wheel sensor rotor.

#### TIP.

Do not touch the surface of the rotor magnet with a sharp object.



c. If the deflection is above specification, remove the sensor rotor from the wheel, rotate it by one bolt hole, and then install it.



Wheel sensor rotor bolt 8 Nm (0.8 m·kgf, 5.8 ft·lbf) LOCTITE®

# ECA59C2408

Replace the wheel sensor rotor bolts with new ones.

d. If the deflection is still above specification, replace the wheel sensor rotor.

\*\*\*\*\*

### EAS21960

ASSEMBLING THE FRONT WHEEL

- 1. Install:
  - Wheel bearings New
  - Oil seals New

#### \*\*\*\*

a. Install the new wheel bearing (left side).

# NOTICE

Do not apply pressure to the wheel bearing inner race "1" or balls "2". Pressure should only be applied to the outer race "3".

#### TIP\_

Use a socket "4" that matches the diameter of the wheel bearing outer race.



- b. Install the collar.
- c. Install the new wheel bearing (right side).

#### TIP\_

Place a suitable washer "1" between the socket "2" and the bearing so that both the inner race "3" and outer race "4" are pressed at the same time, and then press the bearing until the inner race makes contact with the collar "5".

# **FRONT WHEEL**



d. Install the new oil seals

## 

- 2. Install:
  - Air valve

#### TIP\_

- Fasten air valve nut "1" and tighten air valve locknut "2" to 3.0 Nm (0.30 m·kgf, 2.2 ft·lbf).
- When installing the air valve, orient the air valve referring to the illustration.

#### \*\*\*\*

a. Tighten the air valve nut "1".



Air valve nut 2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)

b. Tighten the air valve locknut "2" while holding the air valve nut so as not to turn the nut.



#### Air valve locknut 3.0 Nm (0.30 m·kgf, 2.2 ft·lbf)





- a. 45°–55°
- A. Wheel rotation direction
- B. Left side

#### \*\*\*\*\*

# ADJUSTING THE FRONT WHEEL STATIC BALANCE

#### TIP\_

- After replacing the tire, wheel or both, the front wheel static balance should be adjusted.
- Adjust the front wheel static balance with the brake disc installed.
- 1. Remove:
  - Balancing weight(s)
- 2. Find:
  - Front wheel's heavy spot

#### TIP\_

Place the front wheel on a suitable balancing stand.

#### \*\*\*\*

- a. Spin the front wheel.
- b. When the front wheel stops, put an "X<sub>1</sub>" mark at the bottom of the wheel.



- c. Turn the front wheel  $90^{\circ}$  so that the "X<sub>1</sub>" mark is positioned as shown.
- d. Release the front wheel.
e. When the wheel stops, put an " $X_2$ " mark at the bottom of the wheel.



- f. Repeat steps (c) through (e) several times until all the marks come to rest at the same spot.
- g. The spot where all the marks come to rest is the front wheel's heavy spot "X".

### \*\*\*\*\*

- 3. Adjust:
- Front wheel static balance

### \*\*\*\*

a. Install a balancing weight "1" onto the rim exactly opposite the heavy spot "X".

#### TIP\_

Start with the lightest weight.



b. Turn the front wheel 90° so that the heavy spot is positioned as shown.



c. If the heavy spot does not stay in that position, install a heavier weight.

d. Repeat steps (b) and (c) until the front wheel is balanced.

### \*\*\*\*\*

- 4. Check:
  - Front wheel static balance
- a. Turn the front wheel and make sure it stays at each position shown.



b. If the front wheel does not remain stationary at all of the positions, rebalance it.

### \*\*\*\*\*

#### EAS21990

**INSTALLING THE FRONT WHEEL (DISCS)** 1. Install:

Front brake discs



Front brake disc bolt 23 Nm (2.3 m·kgf, 17 ft·lbf) LOCTITE®

ECA59C1401

NOTICE

Replace the brake disc bolts with new ones.

### TIP\_

Tighten the brake disc bolts in stages and in a crisscross pattern.



- 2. Check:
  - Front brake discs Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-42.
- 3. Lubricate:
  - Oil seal lips

### Recommended lubricant Lithium-soap-based grease

- 4. Install:
  - Collars
  - · Front wheel sensor housing
  - Front wheel
  - Front wheel axle

### TIP.

Align the slot "a" in the front wheel sensor housing with the projection "b" of the front fork before assembly.



- 5. Tighten:
  - Front wheel axle
  - Front wheel axle pinch bolt



### Front wheel axle

72 Nm (7.2 m·kgf, 52 ft·lbf) Front wheel axle pinch bolt 20 Nm (2.0 m·kgf, 14 ft·lbf)

ECA59C1402

Before tightening the wheel axle, push down hard on the handlebar several times and check if the front fork rebounds smoothly.

### 6. Measure:

### TIP\_

Measure the distance "a" only if the wheel bearings, wheel sensor rotor, or both were replaced.

Distance "a"

 (between the wheel sensor rotor "1" and wheel sensor housing "2")
 Out of specification → Reinstall the bearing or replace the wheel sensor rotor.





- 7. Install:
  - Front brake calipers
  - Cable guide
  - Front wheel sensor
  - Front brake hose holders

Front brake caliper bolt 40 Nm (4.0 m·kgf, 29 ft·lbf) Front wheel sensor bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf) Front brake hose holder bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

### TIP\_

When installing the front wheel sensor, check the wheel sensor lead for twists and the sensor electrode for foreign materials.

### ECA59C2409

- Make sure there are no foreign materials in the wheel hub. Foreign materials cause damage to the inner sensor rotor and wheel sensor.
- To route the front wheel sensor lead, refer to "CABLE ROUTING" on page 2-39.

### EWA13500

Make sure the brake hose is routed properly.

8. Check:

 Front wheel sensor installation Check if the wheel sensor housing is installed properly.

## REAR WHEEL



\* When replacing the rear brake caliper or rear brake caliper bracket, replace them as a set.



\* When replacing the rear brake caliper or rear brake caliper bracket, replace them as a set.



### **REAR WHEEL**



#### EAS22040 REMOVING THE REAR WHEEL (DISC) ECA59C2410

### NOTICE

Keep magnets (including magnetic pick-up tools, magnetic screwdrivers, etc.) away from the rear wheel hub "1", otherwise the wheel sensor rotor equipped in the wheel hub may be damaged, resulting in improper performance of the ABS system.



1. Stand the vehicle on a level surface.

### **WARNING**

Securely support the vehicle so that there is no danger of it falling over.

### TIP\_

Place the vehicle on the centerstand so that the rear wheel is elevated.

- 2. Remove:
  - Rear wheel sensor "1"
  - Rear brake caliper "2"
  - Rear brake lock caliper "3"

### TIP.

Do not apply the brake lever when removing the brake caliper.



- 3. Loosen:
  - Locknuts "1"
  - Adjusting bolts "2" (left side and right side)



- 4. Remove:
  - Wheel axle nut "1"
  - Washer
  - Rear wheel axle "2"
  - Rear wheel
  - Rear brake caliper bracket
  - Rear wheel sensor housing
  - Collars
- TIP

Push the rear wheel forward and remove the drive belt from the rear wheel pulley.



#### EAS22080 DISASSEMBLING THE REAR WHEEL ECA59C2406

NOTICE

- Keep magnets (including magnetic pickup tools, magnetic screwdrivers, etc.) away from the wheel sensor rotor.
- Do not drop the wheel sensor rotor or subject it to shocks.
- If any solvent gets on the wheel sensor rotor, wipe it off immediately.
- 1. Remove:
  - Rear wheel sensor rotor
  - Oil seals
  - Wheel bearings Refer to "DISASSEMBLING THE FRONT WHEEL" on page 4-20.

### EAS22091

### CHECKING THE REAR WHEEL

- 1. Check:
  - Wheel axle
  - Wheel bearings
  - Oil seals **Refer to "CHECKING THE FRONT** WHEEL" on page 4-20.
- 2. Check:
  - Tire
    - Rear wheel Damage/wear  $\rightarrow$  Replace. Refer to "CHECKING THE TIRES" on page 3-19 and "CHECKING THE WHEELS" on page 3-19.
- 3. Measure:
  - Radial wheel runout
  - Lateral wheel runout **Refer to "CHECKING THE FRONT** WHEEL" on page 4-20.

### EAS22110

### CHECKING THE REAR WHEEL DRIVE HUB

- 1. Check:
  - Rear wheel drive hub "1" Cracks/damage  $\rightarrow$  Replace the rear wheel.



EAS59C1430

### CHECKING AND REPLACING THE REAR WHEEL PULLEY

- 1. Check:
  - Rear wheel pulley Surface plating has come off  $\rightarrow$  Replace the rear wheel pulley. Bent teeth  $\rightarrow$  Replace the rear wheel pulley.
  - Drive belt guide Cracks/damage/wear  $\rightarrow$  Replace the drive belt guide.
- 2. Replace:
  - Rear wheel pulley

### \*\*\*\*\*

- a. Remove the drive belt guide bolts and the drive belt guide.
- b. Remove the rear wheel pulley bolts and the rear wheel pulley.
- c. Clean the rear wheel drive hub with a clean cloth, especially the surfaces that contact the pulley.
- d. Install the new rear wheel pulley and drive belt guide.



Rear wheel pulley bolt 64 Nm (6.4 m·kgf, 46 ft·lbf) LOCTITE® Drive belt guide bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf) LOCTITE®

### TIP.

- Tighten the rear wheel pulley bolts in stages and in a crisscross pattern.
- When tightening the drive belt guide bolts, tighten the bolt at the punch mark "a" first and then other bolts in stages and in a crisscross pattern.





#### EAS22200 MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR ECA59C2411

### NOTICE

- Handle the ABS components with care since they have been accurately adjusted. Keep them away from dirt and do not subject them to shocks.
- The rear wheel sensor cannot be disassembled. Do not attempt to disassemble it. If faulty, replace with a new one.
- Keep magnets (including magnetic pickup tools, magnetic screwdrivers, etc.) away from the wheel sensor rotor.
- Do not drop or shock the wheel sensor or the wheel sensor rotor.
- 1. Check:
  - Rear wheel sensor
     Refer to "MAINTENANCE OF THE
     FRONT WHEEL SENSOR AND SEN SOR ROTOR" on page 4-21.
- 2. Check:
  - Rear wheel sensor rotor Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SEN-SOR ROTOR" on page 4-21.
- 3. Measure:
  - Rear wheel sensor rotor deflection Out of specification → Clean the installation surface of the wheel sensor rotor and correct the wheel sensor rotor deflection, or replace the wheel sensor rotor.

Z

Wheel sensor rotor deflection limit 0.15 mm (0.0059 in)

### \*\*\*\*

- a. Hold the dial gauge at a right angle against the wheel sensor rotor surface.
- b. Measure the deflection 5.5 mm (0.22 in) below the edge of the wheel sensor rotor.

### TIP\_

Do not touch the surface of the rotor magnet with a sharp object.



c. If the deflection is above specification, remove the sensor rotor from the wheel, rotate it by two bolt holes, and then install it.



Wheel sensor rotor bolt 8 Nm (0.8 m·kgf, 5.8 ft·lbf) LOCTITE®

### ECA59C2408

Replace the wheel sensor rotor bolts with new ones.

d. If the deflection is still above specification, replace the wheel sensor rotor.

\*\*\*\*\*

### EAS22140

### ASSEMBLING THE REAR WHEEL

- 1. Install:
  - Wheel bearings New
  - Oil seals New

a. Install the new wheel bearing (right side). ECA4B56011

NOTICE

Do not contact the wheel bearing inner race "1" or balls "2". Contact should be made only with the outer race "3".

### TIP\_\_\_

Use a socket "4" that matches the diameter of the wheel bearing outer race.



- b. Install the collar.
- c. Install the new wheel bearing (left side).

### TIP\_

Place a suitable washer "1" between the socket "2" and the bearing so that both the inner race "3" and outer race "4" are pressed at the same time, and then press the bearing until the inner race makes contact with the collar "5".



### 

### ADJUSTING THE REAR WHEEL STATIC BALANCE

### TIP\_

- After replacing the tire, wheel or both, the rear wheel static balance should be adjusted.
- Adjust the rear wheel static balance with the brake disc and rear wheel pulley installed.

### 1. Adjust:

• Rear wheel static balance Refer to "ADJUSTING THE FRONT WHEEL STATIC BALANCE" on page 4-23.

#### EAS22160 INSTALLING THE REAR WHEEL (DISC)

- 1. Install:
  - Rear brake disc

Rear brake disc bolt 30Nm (3.0 m·kgf, 22 ft·lbf) LOCTITE®

ECA59C1401

NOTICE

Replace the brake disc bolts with new ones.

### TIP\_

Tighten the brake disc bolts in stages and in a crisscross pattern.



- 2. Check:
  - Rear brake disc Refer to "CHECKING THE REAR BRAKE DISC" on page 4-58.
- 3. Lubricate:
  - Oil seal lips

### Recommended lubricant Lithium-soap-based grease

- 4. Install:
  - Dust cover
  - Collars
  - Rear wheel sensor housing
  - Rear brake caliper bracket
  - Rear wheel
  - Adjusting blocks
  - Rear wheel axle
  - Washer
  - Wheel axle nut

TIP\_

- Do not install the brake caliper and brake lock caliper.
- Fit the brake torque stop pin "a" on the swingarm into the slot "b" on the rear brake caliper bracket.

### **REAR WHEEL**

- When installing the rear brake caliper bracket and the rear wheel sensor housing, align the projection "c" on the rear brake caliper bracket with the slot "d" of the rear wheel sensor housing.
- After installing the rear wheel to the vehicle, make sure that the projection "e" on the brake caliper bracket and the projection "f" on the rear wheel sensor housing are aligned.
- Install the left adjusting block so that projection "g" faces to the front of the vehicle.
- Install the right adjusting block so that upper chamfer "h" faces to the top of the vehicle and lower chamfer "h" faces to the bottom of the vehicle.







- A. Left side
- B. Right side
- 5. Install:
  - Rear brake caliper
  - Rear brake lock caliper (temporarily)
- 6. Adjust:
  - Drive belt slack Refer to "ADJUSTING THE DRIVE BELT SLACK" on page 3-21.
- 7. Tighten:
  - Wheel axle nut
  - Rear brake caliper bolts
  - Rear brake lock caliper bolts



Wheel axle nut 160 Nm (16 m·kgf, 116 ft·lbf) Rear brake caliper bolt 27 Nm (2.7 m·kgf, 20 ft·lbf) Rear brake lock caliper bolt 23 Nm (2.3 m·kgf, 17 ft·lbf)

### 

### 

Make sure the brake hose is routed properly.

### TIP.

When tightening the wheel axle nut, there should be no clearance "a" between the adjusting block "1" and adjusting bolt "2".



### 8. Measure:

### TIP\_

Measure the distance "a" only if the wheel bearings, wheel sensor rotor, or both were replaced.

• Distance "a" (between the wheel sensor rotor "1" and wheel sensor housing "2")

Out of specification  $\rightarrow$  Reinstall the bearing or replace the wheel sensor rotor.



Distance "a" (between the wheel sensor rotor and wheel sensor housing) 29.2–29.7 mm (1.15–1.17 in)



- 9. Install:
  - Rear wheel sensor "1"



### TIP.

When installing the rear wheel sensor, check the rear wheel sensor lead for twists and the sensor electrode for foreign materials.



#### ECA14500 NOTICE

To route the rear wheel sensor lead, refer to "CABLE ROUTING" on page 2-39.

- 10. Check:
  - Rear wheel sensor installation Check if the wheel sensor housing is installed properly.











#### EAS22221 INTRODUCTION EWA14101

### 

Disc brake components rarely require disassembly. Therefore, always follow these preventive measures:

- Never disassemble brake components unless absolutely necessary.
- If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal brake components.
- Use only clean or new brake fluid for cleaning brake components.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.
- Avoid brake fluid coming into contact with the eyes as it can cause serious injury.

FIRST AID FOR BRAKE FLUID ENTERING THE EYES:

• Flush with water for 15 minutes and get immediate medical attention.

### EAS22240

**CHECKING THE FRONT BRAKE DISCS** The following procedure applies to both brake discs.

- 1. Remove:
  - Front wheel
    - Refer to "FRONT WHEEL" on page 4-18.
- 2. Check:
  - Brake disc
    - Damage/galling  $\rightarrow$  Replace.
- 3. Measure:
  - Brake disc deflection Out of specification → Correct the brake disc deflection or replace the brake disc.



Brake disc deflection limit 0.15 mm (0.0059 in)

- \*\*\*\*
- a. Place the vehicle on a suitable stand so that the front wheel is elevated.
- b. Before measuring the front brake disc deflection, turn the handlebar to the left or right to ensure that the front wheel is stationary.

- c. Remove the brake caliper.
- d. Hold the dial gauge at a right angle against the brake disc surface.
- e. Measure the deflection 1.5 mm (0.06 in) below the edge of the brake disc.



\*\*\*\*\*

- 4. Measure:
  - Brake disc thickness Measure the brake disc thickness at a few different locations.
     Out of ensettient is Depleted

Out of specification  $\rightarrow$  Replace.



5. Adjust:

Brake disc deflection

- a. Remove the brake disc.
- b. Rotate the brake disc by two bolt hole.
- c. Install the brake disc and new brake disc bolts.



Front brake disc bolt 23 Nm (2.3 m·kgf, 17 ft·lbf) LOCTITE®

ECA59C1401

Replace the brake disc bolts with new ones.

### TIP\_

Tighten the brake disc bolts in stages and in a crisscross pattern.



- d. Measure the brake disc deflection.
- e. If out of specification, repeat the adjustment steps until the brake disc deflection is within specification.
- f. If the brake disc deflection cannot be brought within specification, replace the brake disc.

### \*\*\*\*\*

- 6. Install:
  - Front wheel Refer to "FRONT WHEEL" on page 4-18.

### EAS22271

### **REPLACING THE FRONT BRAKE PADS**

The following procedure applies to both brake calipers.

### TIP\_

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.

- 1. Remove:
  - Brake hose holder
  - Front brake caliper
  - Brake pad clips "1"
  - Brake pad pin "2"
  - Brake pad spring



- 2. Remove:
  - Brake pads "1"



- 3. Measure:
  - Brake pad wear limit "a" Out of specification → Replace the brake pads as a set.





- 4. Install:
  - Brake pads
  - Brake pad spring

### TIP\_

Always install new brake pads, and new brake pad spring as a set.

### \*\*\*\*

- a. Connect a clear plastic hose "1" tightly to the bleed screw "2". Put the other end of the hose into an open container.
- b. Loosen the bleed screw and push the brake caliper pistons into the brake caliper with your finger.



c. Tighten the bleed screw.

### Bleed screw 5 Nm (0.5 m·kgf, 3.6 ft·lbf)

d. Install a brake pads and brake pad spring.

The arrow mark "a" on the brake pad spring must point in the direction of disc rotation.



**5.** Install:

- Brake pad pin
- Brake pad clips
- Front brake caliper

# 1 and 1 and

### Front brake caliper bolt 40 Nm (4.0 m·kgf, 29 ft·lbf)

- 6. Check:
  - Brake fluid level

Below the minimum level mark "a" $\rightarrow$  Add the specified brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-14.



- 7. Check:
  - Brake lever operation Soft or spongy feeling → Bleed the brake system.
     Refer to "BLEEDING THE HYDRAULIC

BRAKE SYSTEM (ABS)" on page 3-16.

### EAS22300

**REMOVING THE FRONT BRAKE CALIPERS** The following procedure applies to both of the brake calipers.

### TIP

Before removing the brake caliper, drain the brake fluid from the entire brake system.

### 1. Remove:

- Front brake hose holder bolt "1"
- Brake hose union bolt "2"
- Brake hose gaskets "3"
- Front brake hose "4"

### TIP\_

Put the end of the brake hose into a container and pump out the brake fluid carefully.



#### EAS22351 DISASSEMBLING THE FRONT BRAKE CALIPERS

The following procedure applies to both of the brake calipers.

- 1. Remove:
  - Brake caliper pistons "1"
  - Brake caliper piston dust seals "2"
  - Brake caliper piston seals "3"



### \*\*\*\*

 Blow compressed air into the brake hose joint opening "a" to force out the pistons from the brake caliper.

EWA13560

### 

- Cover the brake caliper pistons with a rag. Be careful not to get injured when the pistons are expelled from the brake caliper.
- Never try to pry out the brake caliper pistons.
- Do not loosen the bolts "4".





b. Remove the brake caliper piston dust seals and brake caliper piston seals.

\*\*\*\*\*

#### EAS22391 CHECKING THE FRONT BRAKE CALIPERS

The following procedure applies to both of the brake calipers.

Recommended brake component replace-									
ment schedule									
-				14					

Brake pads	If necessary		
Piston seals	Every two years		
Piston dust seals	Every two years		
Brake hoses	Every four years		
Brake fluid	Every two years and whenever the brake is disassembled		

1. Check:

- Brake caliper pistons "1" Rust/scratches/wear → Replace the brake caliper pistons.
- Brake caliper cylinders "2" Scratches/wear → Replace the brake caliper assembly.
- Brake caliper body "3" Cracks/damage → Replace the brake caliper assembly.
- Brake fluid delivery passages (brake caliper body)
   Obstruction → Blow out with compressed air.

### EWA13611

Whenever a brake caliper is disassembled, replace the brake caliper piston dust seals and brake caliper piston seals.



### EAS22411

ASSEMBLING THE FRONT BRAKE CALI-PERS EWA13621

### 

• Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.

- Never use solvents on internal brake components as they will cause the brake caliper piston dust seals and brake caliper piston seals to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston dust seals and brake caliper piston seals.



Specified brake fluid DOT 4

### EAS22440

### INSTALLING THE FRONT BRAKE CALI-PERS

The following procedure applies to both of the brake calipers.

1. Install:

- Front brake caliper "1" (temporarily)
- Brake hose gaskets New
- Front brake hose "2"
- Brake hose union bolt "3"



Brake hose union bolt

30 Nm (3.0 m·kgf, 22 ft·lbf)

### EWA13530

Proper brake hose routing is essential to insure safe vehicle operation. Refer to "CABLE ROUTING" on page 2-39.

#### ECA14170 **NOTICE**

When installing the brake hose onto the brake caliper "1", make sure the brake pipe "a" touches the projection "b" on the brake caliper.



- 2. Remove:
  - Front brake caliper

- 3. Install:
  - Brake pads
  - Brake pad spring
  - Brake pad pin
  - Brake pad clips
  - Front brake caliper
  - Front brake hose holder



### Front brake caliper bolt 40 Nm (4.0 m·kgf, 29 ft·lbf) Front brake hose holder bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf)

Refer to "REPLACING THE FRONT BRAKE PADS" on page 4-43.

- 4. Fill:
  - Brake master cylinder reservoir (with the specified amount of the specified brake fluid)



Specified brake fluid DOT 4

### EWA59C2401

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

#### ECA13540 **NOTICE**

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 5. Bleed:
  - Brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-16.

### 6. Check:

• Brake fluid level

Below the minimum level mark "a" $\rightarrow$  Add the specified brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-14.



- 7. Check:
  - Brake lever operation

Soft or spongy feeling  $\rightarrow$  Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-16.

### EAS22490

### REMOVING THE FRONT BRAKE MASTER CYLINDER

### TIP.

Before removing the front brake master cylinder, drain the brake fluid from the entire brake system.

- 1. Disconnect:
  - Brake light switch connectors (from the front brake light switch)
- 2. Remove:
  - Brake hose union bolt "1"
  - Brake hose gaskets "2"
  - Front brake hose "3"

### TIP\_

To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.



## CHECKING THE FRONT BRAKE MASTER

### 1. Check:

- Brake master cylinder Damage/scratches/wear → Replace.
- Brake fluid delivery passages (brake master cylinder body)
   Obstruction → Blow out with compressed air.
- 2. Check:
  - Brake master cylinder kit Damage/scratches/wear → Replace.
- 3. Check:
  - Brake master cylinder reservoir cap "1"
  - Brake master cylinder reservoir "2"
  - Brake master cylinder reservoir diaphragm holder "3" Cracks/damage → Replace.
  - Brake master cylinder reservoir diaphragm "4"

Damage/wear  $\rightarrow$  Replace.



- 4. Check:
  - Brake hose Cracks/damage/wear → Replace.

### EAS22520

ASSEMBLING THE FRONT BRAKE MAS-TER CYLINDER EWA13520

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.



#### EAS22530 INSTALLING THE FRONT BRAKE MASTER CYLINDER

- 1. Install:
  - Brake master cylinder "1"
  - Brake master cylinder holder "2"



Brake master cylinder holder bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

TIP.

- Install the brake master cylinder holder with the " ∧" mark "a" facing up.
- Align the end of the brake master cylinder holder with the welding line "b" on the handlebar.
- First, tighten the upper bolt, then the lower bolt.



- 2. Install:
  - Brake hose gaskets "1" New
  - Front brake hose "2"
  - Brake hose union bolt "3"

K

Brake hose union bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)

### EWA13530

Proper brake hose routing is essential to insure safe vehicle operation. Refer to "CABLE ROUTING" on page 2-39.

ECA14160

NOTICE

When installing the brake hose onto the brake master cylinder, make sure the brake pipe touches the projection "a" as shown.

### TIP

Turn the handlebar to the left and right to make sure the brake hose does not touch other parts

(e.g., wire harness, cables, leads). Correct if necessary.



3. Fill:

• Brake master cylinder reservoir (with the specified amount of the specified brake fluid)



Specified brake fluid DOT 4

### WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

#### ECA13540 **NOTICE**

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 4. Bleed:
  - Brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-16.
- 5. Check:
  - Brake fluid level Below the minimum level mark "a"→ Add the specified brake fluid to the proper level.
     Refer to "CHECKING THE BRAKE

FLUID LEVEL" on page 3-14.



- 6. Check:
  - Brake lever operation Soft or spongy feeling → Bleed the brake system.
     Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-16.

## EAS22550









Bemoving the rear brake lock pads				
1 2 3 3 2 2	A second second parts			
Order	Job/Parts to remove	Q'ty	Remarks	
1	Hear brake lock cable adjusting hut	1		
2	MIN   De en la sta de sta service s			
3 Rear brake lock spring		1		
4 Rear brake lock caliper		1		
5	Rear brake lock pad	2		
			For installation, reverse the removal proce- dure.	

Removing the rear brake lock caliner					
removing 1 2 2 2 2	the rear brake lock caliper				
Order	Job/Parts to remove	Q'ty	Remarks		
1	Rear brake lock cable adjusting nut	1			
2	Pin				
3	Rear brake lock spring				
4	Rear brake lock caliper	1			
			For installation, reverse the removal proce- dure.		



### EAS22561 INTRODUCTION EWA14101

### 

Disc brake components rarely require disassembly. Therefore, always follow these preventive measures:

- Never disassemble brake components unless absolutely necessary.
- If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal brake components.
- Use only clean or new brake fluid for cleaning brake components.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.
- Avoid brake fluid coming into contact with the eyes as it can cause serious injury.

FIRST AID FOR BRAKE FLUID ENTERING THE EYES:

• Flush with water for 15 minutes and get immediate medical attention.

### EAS22570

### CHECKING THE REAR BRAKE DISC

- 1. Remove:
  - Rear wheel
  - Refer to "REAR WHEEL" on page 4-27.
- 2. Check:
  - Brake disc
    - $\mathsf{Damage/galling} \to \mathsf{Replace}.$
- 3. Measure:
  - Brake disc deflection Out of specification → Correct the brake disc deflection or replace the brake disc. Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-42.



### Brake disc deflection limit 0.15 mm (0.0059 in)

- 4. Measure:
  - Brake disc thickness Measure the brake disc thickness at a few different locations. Out of specification → Replace. Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-42.



### Brake disc thickness limit 4.5 mm (0.18 in)

5. Adjust:

• Brake disc deflection Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-42.



Rear brake disc bolt 30 Nm (3.0 m·kgf, 22 ft·lbf) LOCTITE®

6. Install:

Rear wheel
 Refer to "REAR WHEEL" on page 4-27.

## REPLACING THE REAR BRAKE PADS

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.

- 1. Remove:
  - Rear brake caliper bolts "1"
  - Rear brake caliper "2"



- 2. Remove:
  - Rear brake pads "1"
  - Brake pad supports "2"



- 3. Measure:
  - Brake pad wear limit "a" Out of specification → Replace the brake pads as a set.





- 4. Install:
  - · Brake pad supports
  - Rear brake pads

### TIP\_

Always install new brake pads, brake pad supports as a set.

#### \*\*\*\*

a. Connect a clear plastic hose "1" tightly to the bleed screw "2". Put the other end of the hose into an open container.



- b. Loosen the bleed screw and push the brake caliper piston into the brake caliper with your finger.
- c. Tighten the bleed screw.

Bleed screw 6 Nm (0.6 m·kgf, 4.3 ft·lbf) d. Install brake pad supports and brake pads.

### \*\*\*\*

### 5. Install:

- Rear brake caliper
- Rear brake caliper bolts

### Rear brake caliper bolt 27 Nm (2.7 m·kgf, 20 ft·lbf)

### 6. Check:

 Brake fluid level Below the minimum level mark "a"→ Add the specified brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-14.



- 7. Check:
  - Brake lever operation Soft or spongy feeling → Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-16.

### EAS22590 REMOVING THE REAR BRAKE CALIPER

TIP\_

Before removing the brake caliper, drain the brake fluid from the entire brake system.

- 1. Remove:
  - Brake hose union bolt "1"
  - Brake hose gaskets
  - Rear brake hose "2"

### TIP\_

Put the end of the brake hose into a container and pump out the brake fluid carefully.


### DISASSEMBLING THE REAR BRAKE CALI-PER

- 1. Remove:
  - Brake caliper piston "1"
  - Brake caliper piston dust seal "2"
  - Brake caliper piston seal "3"



#### \*\*\*\*

a. Blow compressed air into the brake hose joint opening "a" to force out the piston from the brake caliper.

EWA13550

## 

- Cover the brake caliper piston with a rag. Be careful not to get injured when the piston is expelled from the brake caliper.
- Never try to pry out the brake caliper piston.



b. Remove the brake caliper piston dust seal and brake caliper piston seal.

EAS22642 CHECKING THE REAR BRAKE CALIPER

Recommended brake component replace- ment schedule		
Brake pads	If necessary	
Piston seal	Every two years	
Piston dust seal	Every two years	
Brake hoses	Every four years	
Brake fluid	Every two years and whenever the brake is disassembled	

- 1. Check:
  - Brake caliper piston "1" Rust/scratches/wear → Replace the brake caliper piston.
  - Brake caliper cylinder "2" Scratches/wear → Replace the brake caliper assembly.
  - Brake caliper body "3" Cracks/damage → Replace the brake caliper assembly.
  - Brake fluid delivery passages (brake caliper body)
     Obstruction → Blow out with compressed air.

EWA59C1403

## A WARNING

Whenever a brake caliper is disassembled, replace the brake caliper piston dust seal and brake caliper piston seal.



- 2. Check:
  - Brake caliper bracket "1" Cracks/damage → Replace.



ASSEMBLING THE REAR BRAKE CALIPER

## A WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the brake caliper piston dust seal and brake caliper piston seal to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston dust seal and brake caliper piston seal.

Specified brake fluid DOT 4

EAS22670

#### **INSTALLING THE REAR BRAKE CALIPER** 1. Install:

- Rear brake caliper "1" (temporarily)
- Brake hose gaskets New
- Rear brake hose "2"
- Brake hose union bolt "3"



Brake hose union bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)

EWA13530

### **WARNING**

Proper brake hose routing is essential to insure safe vehicle operation. Refer to "CABLE ROUTING" on page 2-39.

### ECA14170

## NOTICE

When installing the brake hose onto the brake caliper "1", make sure the brake pipe "a" touches the projection "b" on the brake caliper.



- 2. Remove:
  - Rear brake caliper
- 3. Install:
  - Brake pad supports
  - Rear brake pads
  - Rear brake caliper
  - Rear brake caliper bolt Refer to "REPLACING THE REAR BRAKE PADS" on page 4-58.



#### Rear brake caliper bolt 27 Nm (2.7 m⋅kgf, 20 ft⋅lbf)

- 4. Fill:
  - Brake master cylinder reservoir (with the specified amount of the specified brake fluid)



Specified brake fluid DOT 4

## EWA4B51011

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

#### ECA13540 **NOTICE**

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

## REAR BRAKE

## 5. Bleed:

- Brake system
   Refer to "BLEEDING THE HYDRAULIC
   BRAKE SYSTEM (ABS)" on page 3-16.
- 6. Check:
  - Brake fluid level Below the minimum level mark "a"→ Add the specified brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-14.



## 7. Check:

Brake lever operation

Soft or spongy feeling  $\rightarrow$  Bleed the brake system.

Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-16.

EAS22700

# REMOVING THE REAR BRAKE MASTER CYLINDER

#### TIP\_

Before removing the rear brake master cylinder, drain the brake fluid from the entire brake system.

## 1. Remove:

- Brake hose union bolt "1"
- Brake hose gaskets "2"
- Rear brake hose "3"

#### TIP.

To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.



# CHECKING THE REAR BRAKE MASTER

- 1. Check:
  - Brake master cylinder Damage/scratches/wear → Replace.
  - Brake fluid delivery passages (brake master cylinder body)
     Obstruction → Blow out with compressed air.
- 2. Check:
  - Brake master cylinder kit Damage/scratches/wear → Replace.
- 3. Check:
  - Brake master cylinder reservoir cap
  - Brake master cylinder reservoir
  - Brake master cylinder reservoir diaphragm holder
    - $Cracks/damage \rightarrow Replace.$
- 4. Check:
  - Brake hose

Cracks/damage/wear  $\rightarrow$  Replace.

#### EAS22730

#### ASSEMBLING THE REAR BRAKE MASTER CYLINDER EWA13520

## 

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.



Specified brake fluid DOT 4

#### EAS22750 INSTALLING THE REAR BRAKE MASTER CYLINDER

1. Install:

- Brake master cylinder "1"
- Brake master cylinder holder "2"



#### Brake master cylinder holder bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

#### TIP

- Install the brake master cylinder holder with the " △" mark "a" facing up.
- Align the end of the brake master cylinder holder with the welding line "b" on the handlebar.
- First, tighten the upper bolt, then the lower bolt.



- 2. Install:
  - Brake hose gaskets "1" New
  - Rear brake hose "2"
  - Brake hose union bolt "3"

N.

Brake hose union bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)

#### EWA13530

## **WARNING**

Proper brake hose routing is essential to insure safe vehicle operation. Refer to "CABLE ROUTING" on page 2-39.

## ECA59C1406

When installing the brake hose onto the brake master cylinder, make sure the brake pipe passes between the projections "a" as shown.

#### TIP.

Turn the handlebar to the left and right to make sure that the brake hose does not touch other parts (e.g., wire harness, cables, leads). Correct if necessary.



- 3. Fill:
  - Brake master cylinder reservoir (with the specified amount of the specified brake fluid)



Specified brake fluid DOT 4

## EWA4B51011

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

#### ECA13540 **NOTICE**

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 4. Bleed:
  - Brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-16.
- 5. Check:
  - Brake fluid level

Below the minimum level mark "a"  $\rightarrow$  Add the specified brake fluid to the proper level.

Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-14.

## **REAR BRAKE**



- 6. Check:
  - Brake lever operation Soft or spongy feeling → Bleed the brake

system. Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-16.

EAS59C1401

### REPLACING THE REAR BRAKE LOCK PADS

- 1. Remove:
  - Rear brake lock cable adjusting nut "1"
  - Pin "2"
  - Rear brake lock spring "3"



- 2. Remove:
  - Rear brake lock caliper bolts "1"
  - Rear brake lock caliper "2"



- 3. Remove:
  - Rear brake lock pad (left side) "1"



### TIP.

Push on the back of the pad using a rod with a round end.

- 4. Remove:
  - Rear brake lock pad (right side) "2"



#### \*\*\*\*

a. Slide the rear brake lock caliper bracket.



 Insert a flathead screwdriver in between the piston adjusting bolt and rear brake lock pad and then remove the rear brake lock pad.
 ECA59C1404

NOTICE

Avoid scratching the dust seal on the side of the piston adjusting bolt carefully.



#### \*\*\*\*\*

- 5. Measure:
  - Rear brake lock pads wear limit "a" Out of specification → Replace the rear brake lock pads.



Brake pad lining thickness 3.0 mm (0.12 in) Limit 0.8 mm (0.03 in)



- 6. Remove:
  - Cap
  - Rear brake lock adjusting nut
  - Rear brake lock caliper arm
- 7. Adjust:
  - Piston adjusting bolt Refer to "ASSEMBLING THE REAR BRAKE LOCK CALIPER" on page 4-66.
- 8. Install:
  - Rear brake lock caliper arm
  - Rear brake lock adjusting nut
  - Cap
  - Rear brake lock pads Refer to "ASSEMBLING THE REAR BRAKE LOCK CALIPER" on page 4-66.
- 9. Install:
  - Rear brake lock caliper
  - Rear brake lock caliper bolts
  - Rear brake lock spring
  - Pin
  - Rear brake lock cable adjusting nut



### Rear brake lock caliper bolt 23 Nm (2.3 m·kgf, 17 ft·lbf)

10. Adjust:

• Rear brake lock cable length Refer to "ADJUSTING THE REAR BRAKE LOCK CABLE" on page 3-17.

#### EAS59C1431 REPLACING THE REAR BRAKE LOCK CABLE

- 1. Remove:
  - Rear brake lock cable
- 2. Check:
  - Rear brake lock cable Cracks/damage/wear → Replace the rear brake lock cable.
- 3. Install:
  - Rear brake lock cable

## EWA59C1405

Proper brake lock cable routing is essential to insure safe vehicle operation. Refer to "CABLE ROUTING" on page 2-39.

- 4. Adjust:
  - Rear brake lock cable length
- a. Adjust the clearance for the rear brake lock pad.

Refer to "ADJUSTING THE REAR BRAKE LOCK CABLE" on page 3-17.

- b. Activate the rear brake lock cable 10 times.
- c. Carry out adjustment using rear brake lock cable adjusting nut "1" so that dimension "a" is 43–45 mm (1.69–1.77 in).
- d. Repeat steps (a) to (c) until dimension "a" is 43–45 mm (1.69–1.77 in).



#### EAS59C1402 REMOVING THE REAR BRAKE LOCK CALI-PER

- 1. Remove:
  - Rear brake lock cable adjusting nut "1"
  - Pin "2"
  - Rear brake lock spring "3"
  - Rear brake lock caliper bolts "4"
  - Rear brake lock caliper "5"



#### EAS59C1404

#### CHECKING THE REAR BRAKE LOCK CALI-PER

- 1. Check:
  - Rear brake lock caliper arm "1"
  - Rear brake lock caliper bracket "2"
  - Sleeve "3"
  - Rear brake lock caliper "4"
  - Locknut "5"
  - Shaft L "6"
  - Piston adjusting bolt "7"
  - Boots "8"
    - Cracks/damage  $\rightarrow$  Replace.



#### EAS59C1405

# ASSEMBLING THE REAR BRAKE LOCK CALIPER

- 1. Install:
  - Slide pin bolt "1" (to the rear brake lock caliper bracket)



Slide pin bolt 17 Nm (1.7 m·kgf, 12 ft·lbf)





- 2. Install:
  - Rear brake lock caliper bracket



- 3. Install:
- Boots "1"
  - Sleeve "2"





- 4. Install:
  - Boot "1"



## REAR BRAKE

- 5. Install:
  - Shaft L "1"
  - Piston adjusting bolt "2"
  - Locknut "3"

## **Recommended lubricant** Silicone grease

Locknut 22 Nm (2.2 m·kgf, 16 ft·lbf) Left-hand thread



- 6. Adjust:
  - Piston adjusting bolt
- \*\*\*
- a. Tighten shaft L manually until it touches the locknut.
- b. With shaft L fastened, turn and adjust the piston adjusting bolt so that the length "a" between the end of shaft L and the end of the piston adjusting bolt is changed to 19 mm (0.75 in).



- 7. Install:
  - Boot
  - Rear brake lock caliper arm

#### TIP

- · Check that the boot is installed correctly.
- Install rear brake lock caliper arm "1" in the position closest to cable holder "2".



- 8. Install:
  - · Rear brake lock adjusting nut
  - Cap

Rear brake lock adjusting nut 15 Nm (1.5 m·kgf, 11 ft·lbf)

9. Install:

Rear brake lock pads

#### ECA59C1405 NOTICE

After installing the rear brake lock pad to the caliper, check that the pad rotates smoothly.

#### EAS59C1406

### **INSTALLING THE REAR BRAKE LOCK** CALIPER

- 1. Install:
  - Rear brake lock caliper "1"
  - Rear brake lock caliper bolts "2"



Rear brake lock spring "3"

- Pin "4"
- Rear brake lock cable adjusting nut "5"



- 2. Adjust:
  - Rear brake lock cable length Refer to "ADJUSTING THE REAR BRAKE LOCK CABLE" on page 3-17.

# ABS (ANTI-LOCK BRAKE SYSTEM)





EAS59C2401 REMOVING THE HYDRAULIC UNIT ASSEM-

BLY

#### ECA4B56013

NOTICE

Unless necessary, avoid removing and installing the brake pipes of the hydraulic unit assembly.

## EWA13930

Refill with the same type of brake fluid that is already in the system. Mixing fluids may result in a harmful chemical reaction, leading to poor braking performance.

ECA4B56014

#### NOTICE

- Handle the ABS components with care, since they have been accurately adjusted. Keep them away from dirt and do not subject them to shocks.
- Do not set the main switch to "ON" when removing the hydraulic unit assembly.
- Do not clean with compressed air.
- Do not reuse the brake fluid.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.
- Do not allow any brake fluid to contact the couplers. Brake fluid may damage the couplers and cause bad contacts.
- If the brake hose flare nuts and union bolts for the hydraulic unit assembly have been removed, be sure to tighten them to the specified torque and bleed the brake system.
- 1. Remove:
  - Brake hoses
  - Rear brake pipe/joint assembly

#### TIP\_

Do not operate the brake levers while removing the brake hoses and rear brake pipe/joint assembly.

#### ECA59C2412

NOTICE

When removing the brake hoses and rear brake pipe/joint assembly, cover the area around the hydraulic unit assembly to catch any spilt brake fluid. Do not allow the brake fluid to contact other parts. 2. Disconnect:

ABS ECU coupler "1"

#### TIP\_

Pull up the coupler ejection slider to disconnect the ABS ECU coupler.



- 3. Remove:
  - Hydraulic unit assembly "1"

#### TIP\_

To avoid brake fluid leakage and to prevent foreign materials from entering the hydraulic unit assembly, insert a rubber plug "a" or a bolt (M10  $\times$  1.0) into each flare nut hole.

ECA17300 **NOTICE** 

When using a bolt, do not tighten the bolt until the bolt head touches the hydraulic unit. Otherwise, the brake pipe seating surface could be deformed.



#### EAS59C2402 CHECKING THE HYDRAULIC UNIT ASSEM-BLY

- 1. Check:
  - Hydraulic unit assembly Cracks/damage → Replace the hydraulic unit assembly and the brake pipes that are connected to the assembly as a set.

#### EAS59C2403 CHECKING THE BRAKE PIPES

The following procedure applies to all of the brake pipes.

- 1. Check:
  - Brake pipe end (flare nut)
     Damage → Replace the hydraulic unit, brake pipes, and related parts as a set.



#### EAS59C2404

### INSTALLING THE HYDRAULIC UNIT ASSEMBLY

#### 1. Install:

- Hydraulic unit assembly
- ECA4B56016

### NOTICE

Do not remove the rubber plugs or bolts (M10  $\times$  1.0) installed in the flare nut holes before installing the hydraulic unit assembly.

#### TIP.

Do not allow any foreign materials to enter the hydraulic unit assembly or the brake hoses or brake pipes when installing the hydraulic unit assembly.

- 2. Remove:
  - Rubber plugs or bolts (M10 × 1.0)
- 3. Connect:
  - ABS ECU coupler "1"

#### TIP\_

Push down the coupler ejection slider until a click is heard, making sure that is installed securely.



- 4. Install:
  - Rear brake pipe/joint assembly "1"
  - Rear brake pipe/joint assembly bolt
  - Brake hose gaskets New
  - Brake hose union bolt "2"



Rear brake pipe/joint assembly flare nut 16 Nm (1.6 m·kgf, 12 ft·lbf) Rear brake pipe/joint assembly

bolt 7 Nm (0.7 m·kgf, 5.1 ft·lbf) Brake hose union bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)

### ECA59C2401

NOTICE

If the brake pipe flare nut does not turn easily, replace the hydraulic unit, brake pipes, and related parts as a set.

#### TIP\_

- When installing the rear brake pipe/joint assembly (hydraulic unit to rear brake hose), temporarily tighten the flare nut and rear brake pipe/joint assembly bolt first. After that, tighten the flare nut and then the rear brake pipe/joint assembly bolt to the specified torque.
- When tightening the brake hose union bolt "2", make sure that the metal part "a" of the brake hose touches the hydraulic unit assembly bracket "b".



- 5. Install:
  - Rear brake hose (rear brake master cylinder to hydraulic unit) "1"
  - Front brake hose (front brake master cylinder to hydraulic unit) "2"
  - Front brake hose (hydraulic unit to front brake hose joint) "3"
  - Brake hose gaskets New
  - Brake hose union bolts



Rear brake hose flare nut 16 Nm (1.6 m·kgf, 12 ft·lbf) Front brake hose flare nut 16 Nm (1.6 m·kgf, 12 ft·lbf) Brake hose union bolt 30 Nm (3.0 m·kgf, 22 ft·lbf)

#### ECA59C2413 **NOTICE**

If the brake hose flare nut does not turn easily, replace the hydraulic unit, brake pipes, and related parts as a set.

#### TIP

- When installing the front brake hose (hydraulic unit to front brake hose joint), front brake hose (front brake master cylinder to hydraulic unit), and rear brake hose (rear brake master cylinder to hydraulic unit), temporarily tighten each flare nut and brake hose holder nut first. After that, tighten the flare nuts and then the brake hose holder nut to the specified torque.
- When tightening the brake hose union bolt "4", make sure that the metal part "a" of the brake hose touches the brake hose bracket "b".



- 6. Fill:
  - Brake master cylinder reservoir (with the specified amount of the specified brake fluid)

·M

Specified brake fluid DOT 4

## EWA59C2401

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

### ECA13540

#### NOTICE

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

- 7. Bleed:
  - Brake system Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM (ABS)" on page 3-16.
- Check the operation of the hydraulic unit according to the response at both brake levers. (Refer to "HYDRAULIC UNIT OPERATION TESTS" on page 4-72.)

#### NOTICE

Always check the operation of the hydraulic unit according to the response at both brake levers.

- Delete the fault codes. (Refer to "[C-1] DELETING THE FAULT CODES" on page 8-115.)
- 10. Perform a trial run. (Refer to "CHECKING THE ABS WARNING LIGHT" on page 4-75.)

#### EAS59C2405

## HYDRAULIC UNIT OPERATION TESTS

The reaction-force pulsating action generated in the brake levers when the ABS is activated can be tested when the vehicle is stopped. The hydraulic unit operation can be tested using the following two methods.

- Hydraulic unit operation test 1: this test checks the function of the ABS after the system was disassembled, adjusted, or serviced.
- Hydraulic unit operation test 2: this test generates the same reaction-force pulsating action that is generated in the brake levers when the ABS is activated.

#### Hydraulic unit operation test 1 EWA13120

## A WARNING

# Securely support the vehicle so that there is no danger of it falling over.

1. Place the vehicle on the centerstand.

Battery voltage

- 2. Set the main switch to "OFF".
- 3. Remove:
  - Front left storage box Refer to "GENERAL CHASSIS" on page 4-1.
- 4. Check:
  - Battery voltage
    - Lower than 12.8 V  $\rightarrow$  Charge or replace the battery.

# 0

#### TIP\_

• If the battery voltage is lower than 12.8 V, charge the battery, and then perform hydraulic unit operation test 1.

Higher than 12.8 V

• If the battery voltage is lower than 10 V, the ABS does not operate.



5. Connect the test coupler adapter "1" to the ABS test coupler "2".

Test coupler adapter 90890-03149



6. Set the main switch to "ON" while operating the front brake lever and the rear brake lever simultaneously.

#### TIP\_

Do not push the start switch when setting the main switch to "ON", otherwise the operation test will not begin.



- 7. Check:
  - Hydraulic unit operation When the main switch is set to "ON", a single pulse will be generated in the front brake lever "1", rear brake lever "2", and again in the front brake lever, in this order.



## ECA59C2403

• Check that the pulse is felt in the front brake lever, rear brake lever, and again in the front brake lever, in this order.

- If the pulse is felt in the rear brake lever before it is felt in the front brake lever, check that the brake hoses and brake pipes are connected correctly to the hydraulic unit assembly.
- If the pulse is hardly felt in either the brake levers, check that the brake hoses and brake pipes are connected correctly to the hydraulic unit assembly.
  - If the operation of the hydraulic unit is normal, delete all of the fault codes.

Hydraulic unit operation test 2 EWA13120

## **WARNING**

# Securely support the vehicle so that there is no danger of it falling over.

- 1. Place the vehicle on the centerstand.
- 2. Set the main switch to "OFF".
- 3. Remove:
  - Front left storage box Refer to "GENERAL CHASSIS" on page 4-1.
- 4. Check:
  - Battery voltage Lower than 12.8 V → Charge or replace the battery.

0

Battery voltage Higher than 12.8 V

## TIP

- If the battery voltage is lower than 12.8 V, charge the battery, and then perform hydraulic unit operation test 2.
- If the battery voltage is lower than 10 V, the ABS does not operate.



5. Connect the test coupler adapter "1" to the ABS test coupler "2".



### Test coupler adapter 90890-03149



- 6. Set the engine stop switch "1" to " $\boxtimes$ ".
- 7. Set the main switch to "ON".
- 8. Push the start switch "2" for at least 4 seconds.

ECA59C2404

NOTICE

#### Do not operate the brake levers.



9. After releasing the start switch, operate the front brake lever and the rear brake lever simultaneously.



 A reaction-force pulsating action is generated in the front brake lever "1" 0.5 second after the brake levers are operated simultaneously and continues for approximately 1.5 seconds.

#### TIP\_

- The reaction-force pulsating action consists of quick pulses.
- Be sure to continue operating the brake levers even after the pulsating action has stopped.



11. After the pulsating action has stopped in the front brake lever, it is generated in the rear brake lever "1" 0.5 second later and continues for approximately 2 seconds.

#### TIP\_

- The reaction-force pulsating action consists of quick pulses.
- Be sure to continue operating the brake levers even after the pulsating action has stopped.



12. After the pulsating action has stopped in the rear brake lever, it is generated in the front brake lever 0.5 second later and continues for approximately 1.5 seconds.

#### TIP\_

The reaction-force pulsating action consists of quick pulses.

## ECA59C2403

- NOTICE
- Check that the pulse is felt in the front brake lever, rear brake lever, and again in the front brake lever, in this order.
- If the pulse is felt in the rear brake lever before it is felt in the front brake lever, check that the brake hoses and brake pipes are connected correctly to the hydraulic unit assembly.
- If the pulse is hardly felt in either the brake levers, check that the brake hoses and brake pipes are connected correctly to the hydraulic unit assembly.
- 13. Set the main switch to "OFF".
- 14. Remove the test coupler adapter from the ABS test coupler.
- 15. Set the main switch to "ON".
- 16. Set the engine stop switch to " $\bigcirc$ ".
- 17. Check for brake fluid leakage around the hydraulic unit.

Brake fluid leakage  $\rightarrow$  Replace the hydraulic unit, brake pipes, and related parts as a set.

#### EAS59C2406

## CHECKING THE ABS WARNING LIGHT

After all checks and servicing are completed, ensure that the ABS warning light goes off by walking the vehicle at a speed of faster than 7 km/h (4.4 mi/h) or performing a trial run.



\* YAMAHA GREASE "F"



\* YAMAHA GREASE "F"

#### EAS22860 REMOVING THE HANDLEBAR

1. Stand the vehicle on a level surface.

## WARNING

# Securely support the vehicle so that there is no danger of it falling over.

## 2. Remove:

• Handlebar grip "1"

### TIP\_

Blow compressed air between the left handlebar and the handlebar grip, and gradually push the grip off the handlebar.



- 3. Remove:
  - Right handlebar switch "1"
  - Throttle grip "2"



#### EAS22880

## CHECKING THE HANDLEBAR

- 1. Check:
  - Handlebar

Bends/cracks/damage  $\rightarrow$  Replace.

## **WARNING**

Do not attempt to straighten a bent handlebar as this may dangerously weaken it.



#### EAS22931 INSTALLING THE HANDLEBAR

1. Stand the vehicle on a level surface.

## EWA13120

# Securely support the vehicle so that there is no danger of it falling over.

- 2. Install:
  - Brake hose bracket
  - Lower handlebar holder
  - · Front brake pipe/joint assembly



Lower handlebar holder nut 34 Nm (3.4 m·kgf, 25 ft·lbf) Front brake pipe/joint assembly bolt

7 Nm (0.7 m·kgf, 5.1 ft·lbf)

3. Install:

- Handlebar
- Upper handlebar holder

#### TIP.

- Align the punch mark on the handlebar to the end of the lower handlebar holder.
- First, tighten the bolts on the front side of the upper handlebar holder, and then on the rear side.



#### Upper handlebar holder bolt 23 Nm (2.3 m·kgf, 17 ft·lbf)

- 4. Install:
  - Lower handlebar cover
- 5. Install:
  - Handlebar grip
- \*\*\*\*
- a. Apply a thin coat of a rubber adhesive to the left end of the handlebar.
- b. Slide the handlebar grip over the left end of the handlebar.
- c. Wipe off any excess rubber adhesive with a clean rag.

## HANDLEBAR

EWA13700

**WARNING** 

Do not touch the handlebar grip until the rubber adhesive has fully dried.

### \*\*\*\*\*

- 6. Install:
  - Rear brake master cylinder assembly "1"
  - Rear brake master cylinder holder "2"



Brake master cylinder holder bolt

10 Nm (1.0 m·kgf, 7.2 ft·lbf)

TIP.

- Install the rear brake master cylinder holder with the " △" mark "a" facing up.
- Align the end of the brake master cylinder holder with the welding line "b" on the handlebar.
- First, tighten the upper bolt, then the lower bolt.



- 7. Connect:
  - Rear brake lock cable (to rear brake lock lever)

#### TIP\_

Lubricate the rear brake lock cable end with YAMAHA GREASE "F".

- 8. Install:
  - Left handlebar switch "1"
  - Rear brake lock lever
  - Rear brake lock lever holder

#### TIP.

- Align the projection "a" on the left handlebar switch with the hole "b" in the handlebar.
- Install the rear brake lock cable after rotating the lever to the position shown in the illustration.



- 9. Connect:
- Rear brake light switch connector 10. Install:
  - Front brake master cylinder assembly "1"
  - Front brake master cylinder holder "2"



Brake master cylinder holder 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

#### TIP.

- Install the front brake master cylinder holder with the "△" mark "a" facing up.
- Align the end of the brake master cylinder holder with the welding line "b" on the handlebar.
- First, tighten the upper bolt, then the lower bolt.



- 11. Install:
  - Throttle grip "1"
  - Throttle cables "2"

### TIP\_

Lubricate the inside of the throttle grip with a thin coat of lithium-soap-based grease and install it onto the handlebar.



## 12. Install:

• Right handlebar switch "1" EWA13720

## 

# Make sure the throttle grip operates smoothly.

### TIP\_

Align the projection "a" on the right handlebar switch with the hole "b" in the handlebar.



- 13. Connect:
- Front brake light switch connector
- 14. Adjust:
  - Throttle grip free play Refer to "CHECKING THE THROTTLE GRIP" on page 3-32.



- 15. Adjust:
  - Rear brake lock cable length Refer to "ADJUSTING THE REAR BRAKE LOCK CABLE" on page 3-17.
- 16. Install:
  - Grip end
  - Holder
  - Upper handlebar cover

#### EAS22950 FRONT FORK



## **FRONT FORK**



## **REMOVING THE FRONT FORK LEGS**

The following procedure applies to both of the front fork legs.

1. Stand the vehicle on a level surface.

## A WARNING

# Securely support the vehicle so that there is no danger of it falling over.

#### TIP\_

Place the vehicle on a suitable stand so that the front wheel is elevated.

- 2. Remove:
  - Cap bolt cover
  - (right front fork side)
- 3. Loosen:
  - Upper bracket pinch bolt "1"
  - Cap bolt "2"
  - Lower bracket pinch bolts "3"
- EWA13640

## A WARNING

Before loosening the upper and lower bracket pinch bolts, support the front fork leg.





- 4. Remove:
  - Front fork leg

## EAS22980 DISASSEMBLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

1. Remove:

- Cap bolt
- Spacer
- · Fork spring seat
- Fork spring
- 2. Drain:
  - Fork oil

#### TIP\_

Stroke the inner tube several times while draining the fork oil.



- 3. Remove:
  - Dust seal "1"
  - Oil seal clip "2" (with a flathead screwdriver)
- ECA14180

## NOTICE

#### Do not scratch the inner tube.

#### TIP\_

- Do not remove the fork leg protector from the outer tube.
- If the front fork leg protector must be removed, always install a new one.



- 4. Remove:
  - Damper rod bolt "1"
  - Copper washer

### TIP\_

While holding the damper rod with the damper rod holder "2" and T-handle "3", loosen the damper rod bolt.

Damper rod holder 90890-01460 T-handle 90890-01326 T-handle 3/8" drive 60 cm long YM-01326



## 5. Remove:

Inner tube

#### \*\*\*\*

- a. Hold the front fork leg horizontally.
- b. Securely clamp the brake caliper bracket in a vise with soft jaws.
- c. Separate the inner tube from the outer tube by pulling the inner tube forcefully but carefully.

#### ECA14190 **NOTICE**

- Excessive force will damage the oil seal and bushing. A damaged oil seal or bushing must be replaced.
- Avoid bottoming the inner tube into the outer tube during the above procedure, as the oil flow stopper will be damaged.



#### EAS23011 CHECKING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

- 1. Check:
  - Inner tube "1"
  - Outer tube "2"
- Bends/damage/scratches  $\rightarrow$  Replace.

## WARNING

Do not attempt to straighten a bent inner tube as this may dangerously weaken it.



- 2. Measure:
  - Spring free length "a" Out of specification → Replace.





3. Check:

Damper rod "1"
 Damage/wear → Replace.
 Obstruction → Blow out all of the oil passages with compressed air.

- Oil flow stopper "2"
   Damage → Replace.
- ECA14200

#### NOTICE

When disassembling and assembling the front fork leg, do not allow any foreign material to enter the front fork.



## **ASSEMBLING THE FRONT FORK LEGS**

The following procedure applies to both of the front fork legs. EWA13660

## WARNING

- Make sure the oil levels in both front fork legs are equal.
- Uneven oil levels can result in poor handling and a loss of stability.

#### TIP\_

- When assembling the front fork leg, be sure to replace the following parts:
  - Inner tube bushing
  - Outer tube bushing
  - Oil seal
  - Dust seal
  - Oil seal clip
  - O-ring
- Before assembling the front fork leg, make sure all of the components are clean.
- 1. Install:
  - Damper rod "1"
  - Rebound spring "2"

#### ECA14210

#### NOTICE

Allow the damper rod assembly to slide slowly down the inner tube "3" until it protrudes from the bottom of the inner tube. Be careful not to damage the inner tube.



- 2. Install:
- Oil flow stopper "1"
- 3. Lubricate:
  - Inner tube's outer surface "2"





- 4. Install:
  - Inner tube (into the outer tube)
  - Copper washer New
  - Damper rod bolt
- 5. Tighten:
  - Damper rod bolt "1"



Damper rod bolt 30 Nm (3.0 m·kgf, 22 ft·lbf) LOCTITE®

## TIP\_

While holding the damper rod with the damper rod holder "2" and T-handle "3" tighten the damper rod bolt.



Damper rod holder 90890-01460 T-handle 90890-01326

T-handle 3/8" drive 60 cm long YM-01326



- 6. Install:
  - Outer tube bushing "1" New
  - Washer "2"

(with the fork seal driver weight "3" and fork seal driver attachment "4")

Fork seal driver weight 90890-01367 Replacement hammer YM-A9409-7 Fork seal driver attachment (ø43) 90890-01374 Replacement 43 mm YM-A5142-3



- 7. Install:
  - Oil seal "1" New

(with the fork seal driver weight "2" and fork seal driver attachment "3")

ECA14220 **NOTICE** 

Make sure the numbered side of the oil seal faces up.

## TIP\_

- Lubricate the outer surface of the inner tube with fork oil.
- Before installing the oil seal, cover the top of the front fork leg with a plastic bag to protect the oil seal during installation.





8. Install:

Oil seal clip "1" New

TIP\_

Adjust the oil seal clip so that it fits into the outer tube's groove.



- 9. Install:
  - Dust seal "1" New (with the fork seal driver weight "2")





- 10. Fill:
  - Front fork leg (with the specified amount of the recommended fork oil)

·Z

Recommended oil Fork oil 10W or equivalent Quantity 517.0 cm<sup>3</sup> (17.48 US oz, 18.23 Imp.oz)

ECA14230

NOTICE

- Be sure to use the recommended fork oil. Other oils may have an adverse effect on front fork performance.
- When disassembling and assembling the front fork leg, do not allow any foreign material to enter the front fork.
- 11. After filling the front fork leg, slowly stroke the inner tube "1" up and down (at least ten times) to distribute the fork oil.

#### TIP\_

Be sure to stroke the damper rod slowly because the fork oil may spurt out.



12. Before measuring the fork oil level, wait ten minutes until the oil has settled and the air bubbles have dispersed.

#### TIP\_

Be sure to bleed the front fork leg of any residual air.

13. Measure:

 Front fork leg oil level "a" Out of specification → Correct.



Level 87.0 mm (3.43 in)



- 14. Install:
  - Fork spring
  - Fork spring seat
  - Spacer
  - Cap bolt
    - (along with the O-ring New)

#### TIP\_

Temporarily tighten the cap bolt.

#### EAS23050 INSTALLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

- 1. Install:
  - Front fork leg Temporarily tighten the upper and lower bracket pinch bolts.

#### TIP\_

Make sure the inner tube end "a" is flush with the lower edge "b" of the upper bracket.



- 2. Tighten:
  - Lower bracket pinch bolts "1"

Lower bracket pinch bolt 23 Nm (2.3 m·kgf, 17 ft·lbf)

• Cap bolt "2"

Cap bolt 23 Nm (2.3 m·kgf, 17 ft·lbf)

• Upper bracket pinch bolt "3"



- 3. Install:
  - Cap bolt cover (right front fork side)

### EAS23090 STEERING HEAD

Removing	the lower bracket		
			14 / 🕅 30 Nm (3.0 m · kaf 22 ft · lbf)
	<u> </u>		
		5 Nm (11.5	$5 \text{ m} \cdot \text{kgf}, 83 \text{ ft} \cdot \text{lbf}$
		H P Pm	
	10 10	VIST	
		AT/-	
		AB) /	
N		$\setminus$ /1	
		$\kappa $	
-CLS		$\sim$	3 -
_		$\Pi$	
		V!/ / ~	
	Martin Martin	lpt -	5
		$\overline{\bigcirc}$	
a		$\bigvee$ (	
R <sup>TB</sup>			
		LS	$\langle (\hat{\mathbf{Q}}) \rangle_{\mathbf{R}}$
	7		
			, 'O, '9
🔌 23 Nm	(2.3 m ⋅ kgf, 17 ft ⋅ lbf)		, 0, '9 , 0, '9
🎉 23 Nm	(2.3 m ⋅ kgf, 17 ft ⋅ lbf)		, , , , , , , , , , , , , , , , , , ,
🔌 23 Nm	(2.3 m ⋅ kgf, 17 ft ⋅ lbf)		y y y y y y y y y y y y y y
23 Nm Order	(2.3 m ⋅ kgf, 17 ft ⋅ lbf) Job/Parts to remove	Q'ty	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks
23 Nm Order	(2.3 m • kgf, 17 ft • lbf) Job/Parts to remove Front cowling assembly	Q'ty	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks Refer to "GENERAL CHASSIS" on page 4-1.
Order	(2.3 m • kgf, 17 ft • lbf) Job/Parts to remove Front cowling assembly Meter assembly	Q'ty	1st       52 Nm (5.2 m · kgf, 38 ft · lbf)         2nd       14 Nm (1.4 m · kgf, 10 ft · lbf)         Remarks         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "GENERAL CHASSIS" on page 4-1.
Order	(2.3 m • kgf, 17 ft • lbf) Job/Parts to remove Front cowling assembly Meter assembly Front wheel	Q'ty	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks Refer to "GENERAL CHASSIS" on page 4-1. Refer to "FRONT WHEEL" on page 4-18.
Order	(2.3 m · kgf, 17 ft · lbf) Job/Parts to remove Front cowling assembly Meter assembly Front wheel Handlebar	Q'ty	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks Refer to "GENERAL CHASSIS" on page 4-1. Refer to "GENERAL CHASSIS" on page 4-1. Refer to "FRONT WHEEL" on page 4-18. Refer to "HANDLEBAR" on page 4-76.
Order	(2.3 m · kgf, 17 ft · lbf) Job/Parts to remove Front cowling assembly Meter assembly Front wheel Handlebar Front fork legs	Q'ty	1st       52 Nm (5.2 m · kgf, 38 ft · lbf)         2nd       14 Nm (1.4 m · kgf, 10 ft · lbf)         Remarks         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "FRONT WHEEL" on page 4-18.         Refer to "HANDLEBAR" on page 4-76.         Refer to "FRONT FORK" on page 4-81.
23 Nm Order	(2.3 m · kgf, 17 ft · lbf) Job/Parts to remove Front cowling assembly Meter assembly Front wheel Handlebar Front fork legs Steering stem nut	Q'ty	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks Refer to "GENERAL CHASSIS" on page 4-1. Refer to "GENERAL CHASSIS" on page 4-1. Refer to "FRONT WHEEL" on page 4-18. Refer to "HANDLEBAR" on page 4-76. Refer to "FRONT FORK" on page 4-81.
23 Nm Order	(2.3 m · kgf, 17 ft · lbf) Job/Parts to remove Front cowling assembly Meter assembly Front wheel Handlebar Front fork legs Steering stem nut Upper bracket	Q'ty 	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks Refer to "GENERAL CHASSIS" on page 4-1. Refer to "GENERAL CHASSIS" on page 4-1. Refer to "FRONT WHEEL" on page 4-18. Refer to "HANDLEBAR" on page 4-76. Refer to "FRONT FORK" on page 4-81.
23 Nm Order 1 2 3	Job/Parts to remove         Front cowling assembly         Meter assembly         Front wheel         Handlebar         Front fork legs         Steering stem nut         Upper bracket         Lock washer	Q'ty	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks Refer to "GENERAL CHASSIS" on page 4-1. Refer to "GENERAL CHASSIS" on page 4-1. Refer to "FRONT WHEEL" on page 4-18. Refer to "HANDLEBAR" on page 4-76. Refer to "FRONT FORK" on page 4-81.
23 Nm Order 1 2 3 4	(2.3 m · kgf, 17 ft · lbf) Job/Parts to remove Front cowling assembly Meter assembly Front wheel Handlebar Front fork legs Steering stem nut Upper bracket Lock washer Upper ring nut Dubber weeper	Q'ty 	Ist       52 Nm (5.2 m · kgf, 38 ft · lbf)         2nd       14 Nm (1.4 m · kgf, 10 ft · lbf)         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "FRONT WHEEL" on page 4-18.         Refer to "FRONT FORK" on page 4-76.         Refer to "FRONT FORK" on page 4-81.
23 Nm Order 1 2 3 4 5	Job/Parts to remove         Front cowling assembly         Meter assembly         Front wheel         Handlebar         Front fork legs         Steering stem nut         Upper bracket         Lock washer         Upper ring nut         Rubber washer         Lower ring nut	Q'ty 1 1 1 1 1 1 1	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks Refer to "GENERAL CHASSIS" on page 4-1. Refer to "GENERAL CHASSIS" on page 4-18. Refer to "FRONT WHEEL" on page 4-18. Refer to "HANDLEBAR" on page 4-76. Refer to "FRONT FORK" on page 4-81.
23 Nm Order 1 2 3 4 5 6 7	Job/Parts to remove         Front cowling assembly         Meter assembly         Front wheel         Handlebar         Front fork legs         Steering stem nut         Upper bracket         Lock washer         Upper ring nut         Rubber washer         Lower ring nut	Q'ty	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks Refer to "GENERAL CHASSIS" on page 4-1. Refer to "GENERAL CHASSIS" on page 4-1. Refer to "FRONT WHEEL" on page 4-18. Refer to "HANDLEBAR" on page 4-76. Refer to "FRONT FORK" on page 4-81.
23 Nm Order 1 2 3 4 5 6 7 8	Job/Parts to remove         Front cowling assembly         Meter assembly         Front wheel         Handlebar         Front fork legs         Steering stem nut         Upper bracket         Lock washer         Upper ring nut         Rubber washer         Lower ring nut         Lower bracket	Q'ty 1 1 1 1 1 1 1 1 1 1 1 1	1st       52 Nm (5.2 m · kgf, 38 ft · lbf)         2nd       14 Nm (1.4 m · kgf, 10 ft · lbf)         Remarks         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "FRONT WHEEL" on page 4-18.         Refer to "FRONT FORK" on page 4-76.         Refer to "FRONT FORK" on page 4-81.
23 Nm Order 1 2 3 4 5 6 7 8 9	Job/Parts to remove         Front cowling assembly         Meter assembly         Front wheel         Handlebar         Front fork legs         Steering stem nut         Upper bracket         Lock washer         Upper ring nut         Rubber washer         Lower ring nut         Lower bracket         Upper bearing cover	Q'ty 1 1 1 1 1 1 1 1 1 1 1 1 1	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks Refer to "GENERAL CHASSIS" on page 4-1. Refer to "GENERAL CHASSIS" on page 4-18. Refer to "FRONT WHEEL" on page 4-18. Refer to "HANDLEBAR" on page 4-76. Refer to "FRONT FORK" on page 4-81.
Order           1           2           3           4           5           6           7           8           9           10	Job/Parts to remove         Front cowling assembly         Meter assembly         Front wheel         Handlebar         Front fork legs         Steering stem nut         Upper bracket         Lock washer         Upper ring nut         Rubber washer         Lower ring nut         Lower bracket         Upper bearing cover         Upper bearing         Lower bearing	Q'ty 1 1 1 1 1 1 1 1 1 1 1 1 1	9 1st 52 Nm (5.2 m · kgf, 38 ft · lbf) 2nd 14 Nm (1.4 m · kgf, 10 ft · lbf) Remarks Refer to "GENERAL CHASSIS" on page 4-1. Refer to "FRONT WHEEL" on page 4-18. Refer to "HANDLEBAR" on page 4-76. Refer to "FRONT FORK" on page 4-81.
Order       1       2       3       4       5       6       7       8       9       10       11	(2.3 m · kgf, 17 ft · lbf)         Job/Parts to remove         Front cowling assembly         Meter assembly         Front wheel         Handlebar         Front fork legs         Steering stem nut         Upper bracket         Lock washer         Upper ring nut         Rubber washer         Lower ring nut         Upper bearing cover         Upper bearing         Lower bearing         Dust seal	Q'ty Q'ty 1 1 1 1 1 1 1 1 1 1 1 1 1	1st       52 Nm (5.2 m · kgf, 38 ft · lbf)         2nd       14 Nm (1.4 m · kgf, 10 ft · lbf)         Remarks         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "FRONT WHEEL" on page 4-18.         Refer to "HANDLEBAR" on page 4-76.         Refer to "FRONT FORK" on page 4-81.
Order       1       2       3       4       5       6       7       8       9       10       11	Job/Parts to remove         Front cowling assembly         Meter assembly         Front wheel         Handlebar         Front fork legs         Steering stem nut         Upper bracket         Lock washer         Upper ring nut         Rubber washer         Lower ring nut         Lower bracket         Upper bearing cover         Upper bearing         Lower bearing         Dust seal	Q'ty 1 1 1 1 1 1 1 1 1 1 1 1 1	1st       52 Nm (5.2 m · kgf, 38 ft · lbf)         2nd       14 Nm (1.4 m · kgf, 10 ft · lbf)         Remarks         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "GENERAL CHASSIS" on page 4-1.         Refer to "FRONT WHEEL" on page 4-18.         Refer to "HANDLEBAR" on page 4-76.         Refer to "FRONT FORK" on page 4-81.

#### EAS23110 REMOVING THE LOWER BRACKET

1. Stand the vehicle on a level surface.

## EWA13120

Securely support the vehicle so that there is no danger of it falling over.

### 2. Remove:

- Upper ring nut
- Rubber washer
- Lower ring nut "1"
- Lower bracket

#### TIP\_

Remove the upper ring nut and lower ring nut with the steering nut wrench "2".

## EWA13730

A WARNING Securely support the lower bracket so that there is no danger of it falling.

Steering nut wrench 90890-01403 Exhaust flange nut wrench YU-A9472



#### EAS23120

## CHECKING THE STEERING HEAD

- 1. Wash:
  - Bearings
  - Bearing races

## Recommended cleaning solvent Kerosene

- 2. Check:
  - Bearings "1"
  - Bearing races "2" Damage/pitting → Replace.



- 3. Replace:
  - Bearings
  - Bearing races

- a. Remove the bearing races from the steering head pipe "1" with a long rod "2" and hammer.
- b. Remove the bearing race from the lower bracket "3" with a floor chisel "4" and hammer.
- c. Install a new rubber seal and new bearing races.

ECA14270

#### NOTICE

# If the bearing race is not installed properly, the steering head pipe could be damaged.

#### TIP\_

- Always replace the bearings and bearing races as a set.
- Whenever the steering head is disassembled, replace the dust seal.



- 4. Check:
  - Upper bracket
  - Lower bracket (along with the steering stem) Bends/cracks/damage → Replace.

## INSTALLING THE STEERING HEAD

- 1. Lubricate:
  - Upper bearing
  - Lower bearing



- 2. Install:
  - Lower ring nut "1"
  - Rubber washer "2"
  - Upper ring nut "3"
  - Lock washer "4" Refer to "CHECKING AND ADJUSTING THE STEERING HEAD" on page 3-23.



- 3. Install:
  - Upper bracket
  - Washer
  - Steering stem nut

#### TIP\_

Temporarily tighten the steering stem nut.

- 4. Install:
  - Front fork legs
    - Refer to "FRONT FORK" on page 4-81.

### TIP\_

Temporarily tighten the upper and lower bracket pinch bolts.

- 5. Tighten:
  - Steering stem nut



Steering stem nut 115 Nm (11.5 m·kgf, 83 ft·lbf)

# BELT DRIVE



\* Filling the YAMAHA GREASE "H" or Polyurea Grease®.

#### EAS23530 CHECKING THE DRIVE BELT

Clean:
 Drive belt

### \*\*\*\*

- a. Wipe the drive belt with a clean cloth.
- b. Put the drive belt in a mixture of mild detergent and water. Then, remove any dirt from the drive belt.
- c. Remove the drive belt from the mixture and rinse it off with clean water. Then, let the drive belt thoroughly dry.



#### \*\*\*\*\*

- 2. Check:
  - Drive belt Refer to "CHECKING THE DRIVE BELT" on page 3-20.
- 3. Check:
  - Drive pulley "1"
  - Rear wheel pulley "2" Bent teeth → Replace the drive belt and pulleys as a set.



- 4. Check:
  - Holder "1"

Cracks/damage  $\rightarrow$  Replace.



#### EAS23540 INSTALLING THE DRIVE BELT

- 1. Install:
  - Drive belt
- 2. Adjust:
  - Drive belt slack Refer to "ADJUSTING THE DRIVE BELT SLACK" on page 3-21.



#### HANDLING THE REAR SHOCK ABSORBER EWA13740

## **WARNING**

This rear shock absorber contains highly compressed nitrogen gas. Before handling the rear shock absorber, read and make sure you understand the following information. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling of the rear shock absorber.

- Do not tamper or attempt to open the rear shock absorber.
- Do not subject the rear shock absorber to an open flame or any other source of high heat. High heat can cause an explosion due to excessive gas pressure.
- Do not deform or damage the rear shock absorber in any way. Rear shock absorber damage will result in poor damping performance.

#### EAS23190 DISPOSING OF A REAR SHOCK ABSORBER

Gas pressure must be released before disposing of a rear shock absorber. To release the gas pressure, drill a 2–3 mm (0.08–0.12 in) hole through the rear shock absorber at a point from its end as shown.

## 

Wear eye protection to prevent eye damage from released gas or metal chips.



#### EAS23210

#### REMOVING THE REAR SHOCK ABSORBER ASSEMBLY

1. Stand the vehicle on a level surface.

## 

Securely support the vehicle so that there is no danger of it falling over.

#### TIP\_

Place the vehicle on the centerstand so that the rear wheel is elevated.

#### 2. Remove:

Rear shock absorber assembly bolts "1"

#### TIP\_

- Straighten the lock washer tab.
- When removing the rear shock absorber assembly bolts "1", hold the swingarm so that it does not drop down.



- 3. Remove:
  - Rear shock absorber assembly

#### EAS23240 CHECKING THE REAR SHOCK ABSORBER ASSEMBLY

- 1. Check:
  - Rear shock absorber Gas leaks/oil leaks → Replace the rear shock absorber assembly.
  - Spring Damage/wear → Replace the rear shock absorber assembly.
  - Bearing Damage/wear → Replace.
  - Spacer
     Damage/wear → Replace.
  - Bolts

Bends/damage/wear  $\rightarrow$  Replace.

#### EAS23301

#### INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY

- 1. Lubricate:
  - Spacer
  - Bearings
  - Rear shock absorber assembly front bolt

#### TIP.

Lubricate the rear shock absorber assembly front bolt seats with lithium-soap-based grease.
# Recommended lubricant Lithium-soap-based grease

- 2. Install:
  - Rear shock absorber assembly

## TIP\_

- Make sure that the warning label "1" on the rear shock absorber assembly faces up.
- When installing the rear shock absorber assembly, lift up the swingarm.



- 3. Tighten:
  - Rear shock absorber assembly rear nut
  - Rear shock absorber assembly front bolt



Rear shock absorber assembly rear nut 53 Nm (5.3 m·kgf, 38 ft·lbf) Rear shock absorber assembly front bolt 68 Nm (6.8 m·kgf, 49 ft·lbf)

TIP\_

- With the swingarm and rear wheel lowered by own weight, tighten the rear shock absorber assembly front bolt and rear shock absorber assembly rear nut.
- After tightening the rear shock absorber assembly front bolt, align the wide claw with the bolt head and bent it.

#### EAS23330 SWINGARM





# SWINGARM



#### EAS23340 REMOVING THE SWINGARM

1. Stand the vehicle on a level surface.

# 

Securely support the vehicle so that there is no danger of it falling over.

## TIP\_

Place the vehicle on a suitable stand so that the rear wheel is elevated.

- 2. Measure:
  - Swingarm side play
  - Swingarm vertical movement

## \*\*\*\*\*

a. Measure the tightening torque of the drive pulley assembly bolts, swingarm bolts and pivot shaft nut.

Drive pulley assembly bolt 48 Nm (4.8 m·kgf, 35 ft·lbf) Swingarm bolt 40 Nm (4.0 m·kgf, 29 ft·lbf) Pivot shaft 7 Nm (0.7 m·kgf, 5.1 ft·lbf) Pivot shaft nut 100 Nm (10 m·kgf, 72 ft·lbf)

- b. Measure the swingarm side play "A" by moving the swingarm from side to side.
- c. If the swingarm side play is out of specification, check the bearings.



Swingarm side play (at the end of the swingarm) 1.0 mm (0.04 in)

 d. Check the swingarm vertical movement "B" by moving the swingarm up and down. If swingarm vertical movement is not smooth or if there is binding, check the bearings.



- 3. Remove:
  - Drive belt Refer to "BELT DRIVE" on page 4-92.
- 4. Remove:
  - Drive pulley assembly bolt
  - Swingarm bolt
  - Pivot shaft nut

## EAS23371

# CHECKING THE SWINGARM

- 1. Check:
  - Left swingarm "1"
  - Right swingarm "2" Bends/cracks/damage  $\rightarrow$  Replace.



- 2. Check:
  - Drive pulley assembly bolts
  - Swingarm bolts Damage/wear → Replace.

# EAS28780

- 1. Lubricate:
  - Taper roller bearing

# TIP\_

Lubricate the space in the swingarm with lithium-soap-based grease before installing the taper roller bearing.



- 2. Install:
  - Pivot shaft "1"
  - Washer "2"
  - Pivot shaft nut "3"

## TIP\_

Install the parts to the swingarm "4" temporarily, making sure that the portion "a" of the pivot shaft does not protrude past the swingarm surface "b".



- 3. Install:
  - Dowel pins
  - Swingarm
  - Swingarm bolts
  - Drive pulley assembly
  - Drive pulley assembly bolt



Swingarm bolt 40 Nm (4.0 m·kgf, 29 ft·lbf) Drive pulley assembly bolt 48 Nm (4.8 m·kgf, 35 ft·lbf)

- 4. Tighten:
  - Pivot shaft
  - Pivot shaft nut

Pivot shaft 7 Nm (0.7 m·kgf, 5.1 ft·lbf) Pivot shaft nut 100 Nm (10 m·kgf, 72 ft·lbf)

\*\*\*\*

- a. With your fingers, screw in the pivot shaft until it touches the collar, and then tighten the pivot shaft to the specified torque.
- b. Tighten the pivot shaft nut to the specified torque.

\*\*\*\*\*

# ENGINE

MEASURING THE COMPRESSION PRESSURE	5-1
ENGINE REMOVAL	5-3
INSTALLING THE ENGINE	
CAMSHAFTS	5-8
REMOVING THE CAMSHAFTS	
CHECKING THE CAMSHAFTS	
CHECKING THE CAMSHAFT SPROCKETS	
CHECKING THE TIMING CHAIN GUIDES	
CHECKING THE TIMING CHAIN TENSIONER	
INSTALLING THE CAMSHAFTS	5-14
CYLINDER HEAD	5-18
REMOVING THE CYLINDER HEAD	5-19
CHECKING THE CYLINDER HEAD	5-19
INSTALLING THE CYLINDER HEAD	5-19
	E 01
	L ()()
	5-22
CHECKING THE VALVES AND VALVE GUIDES	5-22 5-23
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVES AND VALVE GUIDES	5-22 5-23 5-24
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIETERS	5-22 5-23 5-24 5-26 5-27
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS	5-22 5-23 5-24 5-26 5-27 5-27
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS INSTALLING THE VALVES	
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS INSTALLING THE VALVES	
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE SPRINGS INSTALLING THE VALVE LIFTERS INSTALLING THE VALVES	
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE SPRINGS INSTALLING THE VALVE LIFTERS INSTALLING THE VALVES CYLINDER AND PISTONS REMOVING THE PISTONS	
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS INSTALLING THE VALVES <b>CYLINDER AND PISTONS</b> REMOVING THE PISTONS CHECKING THE CYLINDERS AND PISTONS	
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS INSTALLING THE VALVES CYLINDER AND PISTONS REMOVING THE PISTONS CHECKING THE PISTON RINGS	
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS INSTALLING THE VALVES CYLINDER AND PISTONS REMOVING THE PISTONS CHECKING THE PISTON RINGS CHECKING THE PISTON RINGS CHECKING THE PISTON PINS	
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS INSTALLING THE VALVES. CHECKING THE PISTONS CHECKING THE PISTONS CHECKING THE PISTON RINGS CHECKING THE PISTON RINGS CHECKING THE PISTON PINS INSTALLING THE PISTONS AND CYLINDER.	5-22 5-23 5-24 5-26 5-27 5-27 5-27 5-29 5-30 5-30 5-31 5-32 5-32 5-33
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS INSTALLING THE VALVES CYLINDER AND PISTONS REMOVING THE PISTONS CHECKING THE PISTONS AND PISTONS CHECKING THE PISTON RINGS CHECKING THE PISTON PINS INSTALLING THE PISTONS AND CYLINDER	5-22 5-23 5-24 5-26 5-27 5-27 5-27 5-29 5-30 5-30 5-31 5-32 5-33
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS INSTALLING THE VALVES CYLINDER AND PISTONS REMOVING THE PISTONS CHECKING THE PISTONS CHECKING THE PISTON RINGS CHECKING THE PISTON RINGS CHECKING THE PISTON PINS INSTALLING THE PISTONS AND CYLINDER CHECKING THE PISTONS AND CYLINDER	5-22 5-23 5-24 5-26 5-27 5-27 5-27 5-29 5-30 5-30 5-31 5-32 5-33 5-33
CHECKING THE VALVES CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS INSTALLING THE VALVES CYLINDER AND PISTONS REMOVING THE PISTONS CHECKING THE PISTONS CHECKING THE PISTON RINGS CHECKING THE PISTON RINGS CHECKING THE PISTON PINS INSTALLING THE PISTONS AND CYLINDER ELECTRIC STARTER CHECKING THE STABLEB MOTOR	5-22 5-23 5-24 5-26 5-27 5-27 5-27 5-29 5-30 5-30 5-31 5-32 5-33 5-35 5-35 5-37
CHECKING THE VALVES AND VALVE GUIDES CHECKING THE VALVE SEATS CHECKING THE VALVE SPRINGS CHECKING THE VALVE SPRINGS CHECKING THE VALVE LIFTERS INSTALLING THE VALVES NSTALLING THE VALVES CYLINDER AND PISTONS REMOVING THE PISTONS CHECKING THE PISTONS AND PISTONS CHECKING THE PISTON PINS INSTALLING THE PISTON PINS INSTALLING THE PISTONS AND CYLINDER ELECTRIC STARTER CHECKING THE STARTER MOTOR ASSEMBLING THE STARTER MOTOR	5-22 5-23 5-24 5-26 5-27 5-27 5-27 5-29 5-30 5-30 5-30 5-31 5-32 5-33 5-35 5-37 5-38
REMOVING THE VALVES.         CHECKING THE VALVES AND VALVE GUIDES.         CHECKING THE VALVE SEATS         CHECKING THE VALVE SPRINGS.         CHECKING THE VALVE LIFTERS.         INSTALLING THE VALVES.         CYLINDER AND PISTONS.         CHECKING THE PISTONS.         CHECKING THE PISTONS.         CHECKING THE PISTONS         CHECKING THE PISTON RINGS         CHECKING THE PISTON RINGS         CHECKING THE PISTON PINS         INSTALLING THE PISTONS AND CYLINDER.         ELECTRIC STARTER         CHECKING THE STARTER MOTOR         ASSEMBLING THE STARTER MOTOR         INSTALLING THE STARTER MOTOR	5-22 5-23 5-24 5-26 5-26 5-27 5-27 5-27 5-29 5-30 5-30 5-31 5-32 5-33 5-35 5-37 5-38 5-38 5-38

V-BELT AUTOMATIC TRANSMISSION	5-39
REMOVING THE PRIMARY SHEAVE AND SECONDARY	
SHEAVE	5-44
DISASSEMBLING THE SECONDARY SHEAVE	5-44
CHECKING THE V-BELT	5-45
CHECKING THE PRIMARY SHEAVE	5-45
CHECKING THE V-BELT CASE AIR DUCT	5-45
CHECKING THE PRIMARY SHEAVE WEIGHTS	5-45
CHECKING THE SLIDERS	5-45
CHECKING THE SECONDARY SHEAVE	5-46
ASSEMBLING THE PRIMARY SHEAVE	5-46
ASSEMBLING THE SECONDARY SHEAVE	5-46
INSTALLING THE PRIMARY SHEAVE ASSEMBLY, SECONDARY	
SHEAVE ASSEMBLY AND V-BELT	5-48
INSTALLING THE V-BELT CASE	5-49
	5-50
	5-53
	5-53
	5-53
	5-54
	5-54
	5-54
	ວ-ວວ
CLUTCH	5-57
CLUTCH REMOVING THE CLUTCH	5-57 5-60
CLUTCH REMOVING THE CLUTCH DISASSEMBLING THE CLUTCH	5-57 5-60 5-60
CLUTCH REMOVING THE CLUTCH DISASSEMBLING THE CLUTCH CHECKING THE FRICTION PLATES	5-57 5-60 5-60 5-61
CLUTCH REMOVING THE CLUTCH DISASSEMBLING THE CLUTCH CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES	5-57 5-60 5-60 5-61 5-61
CLUTCH REMOVING THE CLUTCH DISASSEMBLING THE CLUTCH CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES CHECKING THE CLUTCH DAMPER SPRINGS	5-57 5-60 5-60 5-61 5-61 5-61
CLUTCH REMOVING THE CLUTCH. DISASSEMBLING THE CLUTCH. CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE	5-57 5-60 5-61 5-61 5-61 5-61 5-61
CLUTCH REMOVING THE CLUTCH DISASSEMBLING THE CLUTCH CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES CHECKING THE CLUTCH DAMPER SPRINGS CHECKING THE CLUTCH SPRING PLATE CHECKING THE CLUTCH SPRINGS	5-57 5-60 5-61 5-61 5-61 5-61 5-61 5-62
CLUTCH REMOVING THE CLUTCH DISASSEMBLING THE CLUTCH CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES CHECKING THE CLUTCH DAMPER SPRINGS CHECKING THE CLUTCH SPRING PLATE CHECKING THE CLUTCH SPRINGS CHECKING THE CLUTCH HOUSING	5-57 5-60 5-61 5-61 5-61 5-61 5-62 5-62
CLUTCH REMOVING THE CLUTCH. DISASSEMBLING THE CLUTCH. CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING CHECKING THE CLUTCH HOUSING	5-57 5-60 5-61 5-61 5-61 5-61 5-62 5-62 5-62
CLUTCH REMOVING THE CLUTCH. DISASSEMBLING THE CLUTCH. CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE. CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING CHECKING THE CLUTCH BOSS CHECKING THE PRESSURE PLATE AND THRUST PLATE.	5-57 5-60 5-61 5-61 5-61 5-61 5-62 5-62 5-62 5-62
CLUTCH REMOVING THE CLUTCH. DISASSEMBLING THE CLUTCH. CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE. CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING CHECKING THE CLUTCH HOUSING CHECKING THE CLUTCH BOSS. CHECKING THE PRESSURE PLATE AND THRUST PLATE. ASSEMBLING THE CLUTCH.	5-57 5-60 5-61 5-61 5-61 5-62 5-62 5-62 5-62 5-62 5-62
CLUTCH REMOVING THE CLUTCH. DISASSEMBLING THE CLUTCH. CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE. CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING CHECKING THE CLUTCH HOUSING CHECKING THE CLUTCH BOSS. CHECKING THE PRESSURE PLATE AND THRUST PLATE. ASSEMBLING THE CLUTCH. INSTALLING THE CLUTCH.	5-57 5-60 5-61 5-61 5-61 5-61 5-62 5-62 5-62 5-63 5-63 5-64
CLUTCH REMOVING THE CLUTCH. DISASSEMBLING THE CLUTCH. CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING CHECKING THE CLUTCH HOUSING CHECKING THE CLUTCH BOSS CHECKING THE PRESSURE PLATE AND THRUST PLATE. ASSEMBLING THE CLUTCH. INSTALLING THE CLUTCH.	5-57 5-60 5-61 5-61 5-61 5-62 5-62 5-62 5-63 5-63 5-64
CLUTCH. REMOVING THE CLUTCH. DISASSEMBLING THE CLUTCH. CHECKING THE FRICTION PLATES. CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE. CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING. CHECKING THE CLUTCH BOSS. CHECKING THE PRESSURE PLATE AND THRUST PLATE. ASSEMBLING THE CLUTCH. INSTALLING THE CLUTCH.	5-57 5-60 5-61 5-61 5-61 5-62 5-62 5-62 5-62 5-63 5-64
CLUTCH REMOVING THE CLUTCH. DISASSEMBLING THE CLUTCH. CHECKING THE FRICTION PLATES. CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE. CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING. CHECKING THE CLUTCH HOUSING. CHECKING THE CLUTCH BOSS. CHECKING THE CLUTCH BOSS. CHECKING THE CLUTCH. INSTALLING THE CLUTCH. INSTALLING THE CLUTCH.	5-57 5-60 5-61 5-61 5-61 5-62 5-62 5-62 5-63 5-63 5-64 5-65 5-65
CLUTCH REMOVING THE CLUTCH DISASSEMBLING THE CLUTCH CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES CHECKING THE CLUTCH DAMPER SPRINGS CHECKING THE CLUTCH SPRING PLATE CHECKING THE CLUTCH SPRINGS CHECKING THE CLUTCH HOUSING CHECKING THE CLUTCH BOSS CHECKING THE PRESSURE PLATE AND THRUST PLATE ASSEMBLING THE CLUTCH INSTALLING THE CLUTCH CHECKING THE OIL PUMP CHECKING THE OIL PUMP CHECKING THE RELIEF VALVE	5-57 5-60 5-61 5-61 5-61 5-62 5-62 5-62 5-63 5-64 5-65 5-67 5-67
CLUTCH REMOVING THE CLUTCH DISASSEMBLING THE CLUTCH CHECKING THE FRICTION PLATES. CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE. CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING. CHECKING THE CLUTCH BOSS. CHECKING THE CLUTCH BOSS. CHECKING THE PRESSURE PLATE AND THRUST PLATE ASSEMBLING THE CLUTCH INSTALLING THE CLUTCH CHECKING THE OIL PUMP. CHECKING THE OIL PUMP. CHECKING THE RELIEF VALVE. CHECKING THE OIL PIPES.	5-57 5-60 5-61 5-61 5-61 5-62 5-62 5-62 5-62 5-63 5-64 5-67 5-67 5-67 5-67
CLUTCH. REMOVING THE CLUTCH DISASSEMBLING THE CLUTCH CHECKING THE FRICTION PLATES CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING CHECKING THE CLUTCH BOSS. CHECKING THE PRESSURE PLATE AND THRUST PLATE ASSEMBLING THE CLUTCH. INSTALLING THE CLUTCH. OIL PUMP CHECKING THE OIL PUMP DRIVE CHAIN	5-57 5-60 5-61 5-61 5-61 5-62 5-62 5-62 5-62 5-63 5-63 5-64 5-67 5-67 5-67 5-67 5-67
CLUTCH. REMOVING THE CLUTCH DISASSEMBLING THE CLUTCH CHECKING THE FRICTION PLATES. CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE. CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING. CHECKING THE CLUTCH BOSS. CHECKING THE CLUTCH BOSS. CHECKING THE PRESSURE PLATE AND THRUST PLATE ASSEMBLING THE CLUTCH. INSTALLING THE CLUTCH. INSTALLING THE CLUTCH. CHECKING THE OIL PUMP. CHECKING THE OIL PUMP. CHECKING THE RELIEF VALVE. CHECKING THE OIL PUMP DRIVE CHAIN ASSEMBLING THE OIL PUMP.	5-57 5-60 5-61 5-61 5-61 5-62 5-62 5-62 5-62 5-63 5-63 5-64 5-67 5-67 5-67 5-67 5-67 5-67
CLUTCH. REMOVING THE CLUTCH. DISASSEMBLING THE CLUTCH. CHECKING THE FRICTION PLATES. CHECKING THE CLUTCH PLATES. CHECKING THE CLUTCH DAMPER SPRINGS. CHECKING THE CLUTCH SPRING PLATE. CHECKING THE CLUTCH SPRINGS. CHECKING THE CLUTCH HOUSING. CHECKING THE CLUTCH HOUSING. CHECKING THE CLUTCH BOSS. CHECKING THE CLUTCH BOSS. CHECKING THE CLUTCH BOSS. CHECKING THE CLUTCH. INSTALLING THE CLUTCH. OIL PUMP. CHECKING THE OIL PUMP. CHECKING THE OIL PUMP. CHECKING THE OIL PUMP. CHECKING THE OIL PUMP DRIVE CHAIN ASSEMBLING THE OIL PUMP. INSTALLING THE OIL PUMP. INSTALLING THE OIL PUMP.	5-57 5-60 5-61 5-61 5-61 5-62 5-62 5-62 5-62 5-63 5-63 5-64 5-67 5-67 5-67 5-67 5-67 5-67 5-67 5-67

<b>CRANKCASE</b>
DISASSEMBLING THE CRANKCASE
CHECKING THE CRANKCASE
CHECKING THE TIMING CHAIN
ASSEMBLING THE CRANKCASE
<b>CRANKSHAFT</b>
REMOVING THE CONNECTING RODS5-76
REMOVING THE CRANKSHAFT JOURNAL BEARINGS
CHECKING THE CRANKSHAFT AND CONNECTING RODS
INSTALLING THE CRANKSHAFT JOURNAL BEARINGS
INSTALLING THE CONNECTING RODS5-80
INSTALLING THE CRANKSHAFT ASSEMBLY
TRANSMISSION
CHECKING THE TRANSMISSION5-84

#### EAS59C1501 ENGINE INSPECTION

#### EAS59C1502

#### MEASURING THE COMPRESSION PRES-SURE

The following procedure applies to all of the cylinders.

#### TIP.

Insufficient compression pressure will result in a loss of performance.

- 1. Measure:
  - Valve clearance Out of specification → Adjust. Refer to "ADJUSTING THE VALVE CLEARANCE" on page 3-5.
- 2. Start the engine, warm it up for several minutes, and then turn it off.
- 3. Remove:
  - Radiator cover Refer to "GENERAL CHASSIS" on page 4-1.
- 4. Disconnect:
  - Spark plug caps
- 5. Remove:
  - Spark plugs

ECA13340

# NOTICE

Before removing the spark plugs, use compressed air to blow away any dirt accumulated in the spark plug wells to prevent it from falling into the cylinders.

6. Install:

Compression gauge "1"



Compression gauge 90890-03081 Engine compression tester YU-33223



- 7. Measure:
  - Compression pressure Out of specification → Refer to steps (c) and (d).



Standard compression pressure (at sea level) 1950 kPa/470 r/min (19.5 kgf/ cm²/470 r/min, 282.8 psi/470 r/ min) Minimum-maximum 1700-2180 kPa/470 r/min (17.0-21.8 kgf/cm²/470 r/min,

246.1–316.8 psi/470 r/min)

#### \*\*\*\*

- a. Set the main switch to "ON".
- b. With the throttle wide open, crank the engine until the reading on the compression gauge stabilizes.

#### TIP\_

The difference in compression pressure between cylinders should not exceed 100 kPa (1 kgf/cm<sup>2</sup>, 14 psi).

- c. If the compression pressure is above the maximum specification, check the cylinder head, valve surfaces and piston crown for carbon deposits.
- Carbon deposits → Eliminate.
  d. If the compression pressure is below the minimum specification, pour a teaspoonful
  - of engine oil into the spark plug bore and measure again. Refer to the following table.

Compression pressure (with oil applied into

the cylinder)	
Reading	Diagnosis
Higher than without oil	Piston ring(s) wear or damage $\rightarrow$ Replace.
Same as without oil	Piston, valves or cyl- inder head gasket possibly defective $\rightarrow$ Replace.

# 8. Install:

Spark plugs

Spark plug 13 Nm (1.3 m⋅kgf, 9.4 ft⋅lbf) 9. Connect:

- Spark plug caps
- 10. Install:
  - Radiator cover Refer to "GENERAL CHASSIS" on page 4-1.

# ENGINE REMOVAL









#### EAS23720 INSTALLING THE ENGINE

- 1. Install:
  - All removed parts

TIP\_

- Apply locking agent (LOCTITE®) to engine mounting bolts (front right lower side) "2", engine mounting bolts (front left lower side) "3", and rear frame bolts "5".
- For installation, reverse the removal procedure.
- Do not fully tighten the bolts and nuts.
- 2. Tighten:
  - Engine mounting nut (front upper side) "1"
  - Engine mounting bolts (front right lower side) "2"
  - Engine mounting bolts (front left lower side) "3"
  - Engine mounting nut (rear side) "4"
  - Rear frame bolts "5"

TIP\_

When tightening the engine mounting nuts and engine mounting bolts, do not apply an upward load to the frame, such as supporting the area around steering head of the frame upwards. Also, do not apply an upward or downward load on the rear frame, such as supporting the rear end of the rear frame upwards or pushing it downwards.

Engine mounting nut (front upper side) 88 Nm (8.8 m·kgf, 64 ft·lbf) Engine mounting bolt (front right lower side) 45 Nm (4.5 m·kgf, 33 ft·lbf) **LOCTITE®** Engine mounting bolt (front left lower side) 45 Nm (4.5 m·kgf, 33 ft·lbf) **LOCTITE®** Engine mounting nut (rear side) 105 Nm (10.5 m·kgf, 76 ft·lbf) Rear frame bolt 83 Nm (8.3 m·kgf, 60 ft·lbf) LOCTITE®



#### EAS23760 CAMSHAFTS







#### EAS23810 REMOVING THE CAMSHAFTS

- 1. Align:
  - "I" mark "a" on the generator rotor (with the stationary pointer "b" on the generator cover)

a. Turn the crankshaft clockwise.



b. When piston #1 is at TDC on the compression stroke, align the "I" mark "a" on the generator rotor with the stationary pointer "b" on the generator cover.

#### TIP\_

- TDC on the compression stroke can be found when the cylinder #1 camshaft lobes are turned away from each other.
- In order to be sure that the piston is at TDC, the alignment marks "c" on the intake camshaft sprocket and the alignment marks "d" on the exhaust camshaft sprocket must align with the cylinder head mating surface as shown in the illustration.





- 2. Remove:
  - Timing chain tensioner "1"
  - Timing chain tensioner gasket



- 3. Remove:
  - Intake camshaft cap "1"
  - Exhaust camshaft cap "2"
  - Dowel pins

#### ECA13720 **NOTICE**

To prevent damage to the cylinder head, camshafts or camshaft caps, loosen the camshaft cap bolts in stages and in a crisscross pattern, working from the outside in.



- 4. Remove:
  - Intake camshaft "1"
  - Exhaust camshaft "2"

TIP\_

To prevent the timing chain from falling into the crankcase, fasten with a wire "3".



# EAS23850 CHECKING THE CAMSHAFTS

- 1. Check:
  - Camshaft lobes Blue discoloration/pitting/scratches  $\rightarrow$ Replace the camshaft.
- 2. Measure:
  - Camshaft lobe dimensions "a" and "b" Out of specification  $\rightarrow$  Replace the camshaft.

-
-
-
-
_





- 3. Measure:
  - Camshaft runout Out of specification  $\rightarrow$  Replace.



Camshaft runout limit 0.030 mm (0.0012 in)



11151402

- 4. Measure:
  - Camshaft-journal-to-camshaft-cap clearance

Out of specification  $\rightarrow$  Measure the camshaft journal diameter.



# \*\*\*\*

- a. Install the camshaft into the cylinder head (without the dowel pins and camshaft caps).
- b. Position a strip of Plastigauge® "1" onto the camshaft journal as shown.



c. Install the dowel pins and camshaft caps.

## TIP\_

- When tightening the camshaft cap, tighten the four bolts on the both ends of the cap temporarily to lower the entire cap, while paying attention not to twist the dowel pins and camshaft journal. After the camshaft cap touches the cylinder head, tighten the two bolts in the middle to the specified torque and then the remaining four bolts to the specified torque.
- To prevent the camshaft cap from cracking, tighten the camshaft cap carefully by tapping

the camshaft using a soft-face hammer (both for temporary and final tightening).

• Do not turn the camshaft when measuring the camshaft journal-to-camshaft cap clearance with the Plastigauge®.



## Camshaft cap bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

d. Remove the camshaft caps and then measure the width of the Plastigauge® "1".



## \*\*\*\*\*

- 5. Measure:
  - Camshaft journal diameter "a" Out of specification → Replace the camshaft.

Within specification  $\rightarrow$  Replace the cylinder head and the camshaft caps as a set.





# EAS4B51035

**CHECKING THE CAMSHAFT SPROCKETS** The following procedure applies to both of the camshaft sprockets.

1. Check:

Camshaft sprocket

More than 1/4 tooth wear "a"  $\rightarrow$  Replace the camshafts and the timing chain as a set.



- a. 1/4 tooth
- b. Correct
- 1. Timing chain
- 2. Camshaft sprocket

# EAS23950 CHECKING THE TIMING CHAIN GUIDES 1. Check:

- - Timing chain guide (intake side) "1" • Timing chain guide (exhaust side) "2"
  - Timing chain guide (upper side) "3" Damage/wear  $\rightarrow$  Replace the defective part(s).



#### EAS23960

## CHECKING THE TIMING CHAIN TEN-SIONER

- 1. Check:
  - Timing chain tensioner Cracks/damage  $\rightarrow$  Replace.

#### \*\*\*\*

a. Push the timing chain tensioner rod "1" into the timing chain tensioner housing by hand.

#### TIP\_

While pushing the timing chain tensioner rod "a", turn it clockwise "b" with the timing chain tensioner body "2" until if stops.



b. Lock the timing chain tensioner rod by setting the circlip "3" to groove "4" while pushing the timing chain tensioner rod.



- c. Push the timing chain tensioner rod "c".
- d. Make sure that the timing chain tensioner rod comes out "d" of the timing chain tensioner housing smoothly. If there is rough movement, replace the timing chain tensioner.



#### 

#### EAS24000 **INSTALLING THE CAMSHAFTS**

- 1. Install:
  - Exhaust camshaft "1"
  - Intake camshaft "2"



- \*\*\*\*
- a. Turn the crankshaft clockwise.



b. When piston #1 is at TDC on the compression stroke, align the "I" mark "a" on the generator rotor with the stationary pointer "b" on the generator cover.



c. Install the timing chain onto both camshaft sprockets, and then install the camshafts onto the cylinder head.

TIP\_

- Lubricate the camshaft journal with the molybdenum disulfide oil.
- When installing the timing chain, start with the exhaust camshaft and be sure to keep the timing chain as tight as possible on the exhaust side.
- The camshafts should be installed onto the cylinder head so that the alignment marks "c" on the intake camshaft sprocket and the alignment marks "d" on the exhaust camshaft

sprocket align with the cylinder head mating surface, as shown in the illustration.

#### ECA4B51015 **NOTICE**

Do not turn the crankshaft when installing the camshafts to avoid damage or improper valve timing.



#### \*\*\*\*\*

- 2. Install:
  - Dowel pins
  - Exhaust camshaft cap "1"
  - Intake camshaft cap "2"

TIP\_

Make sure each camshaft cap is installed in its original place. Refer to the identification marks as follows: "IN": Intake

"EX": Exhaust



- 3. Install:
  - Camshaft cap bolts



The camshaft cap bolts must be tightened evenly or damage to the cylinder head, camshaft caps, and camshafts will result.

## TIP\_

- Lubricate the camshaft cap bolt seats with the engine oil.
- When tightening the camshaft cap, tighten the four bolts on the both ends of the cap temporarily to lower the entire cap, while paying attention not to twist the dowel pins and camshaft journal. After the camshaft cap touches the cylinder head, tighten the two bolts in the middle to the specified torque and then the remaining four bolts to the specified torque.
- To prevent the camshaft cap from cracking, tighten the camshaft cap carefully by tapping the camshaft using a soft-face hammer (both for temporary and final tightening).
- 4. Install:
  - Timing chain tensioner gasket New
  - Timing chain tensioner

## \*\*\*\*

 Push the timing chain tensioner rod "1" into the timing chain tensioner housing by hand.

## TIP\_

While pushing the timing chain tensioner rod "a", turn it clockwise "b" with the timing chain tensioner body "2" until if stops.



b. Lock the timing chain tensioner rod by setting the circlip "3" into groove "4" while pushing the timing chain tensioner rod.



c. Install the timing chain tensioner to the cylinder block.

## TIP\_

Always use a new gasket.



Timing chain tensioner bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

d. Release the timing chain tensioner rod by pushing up the timing chain guide "5" from the hole "6".

ECA4B51014

NOTICE

Do not push up the timing chain. Push up "c" the timing chain guide "5".



## \*\*\*\*

- 5. Turn:
  - Crankshaft
    - (several turns clockwise)
- 6. Check:
  - "I" mark "a"

Make sure that the "l" mark is aligned with the stationary pointer "b" on the generator cover.

 Camshaft sprocket alignment marks "c" and "d".

Make sure that the camshaft sprocket alignment marks are aligned with the cylinder head mating surface.

Out of alignment  $\rightarrow$  Correct.

Refer to the installation steps above.





- 7. Measure:
  - Valve clearance Out of specification → Adjust. Refer to "ADJUSTING THE VALVE CLEARANCE" on page 3-5.
- 8. Install:
  - Timing chain guide (upper side)
  - Gaskets New
     (to the cylinder head cover)

# TIP\_

Apply Yamaha bond No.1215 "1" onto the mating surfaces of the cylinder head cover and gaskets.



Yamaha bond No.1215 90890-85505 (Three bond No.1215®)



- 9. Install:
  - Cylinder head cover gasket New
  - Cylinder head cover



# Cylinder head cover bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

## TIP

Tighten the cylinder head cover bolts in stages and in a crisscross pattern.

#### EAS24100 CYLINDER HEAD



#### EAS24120 **REMOVING THE CYLINDER HEAD**

- 1. Remove:
  - Cylinder head bolts
  - Cylinder head nuts

## TIP

- Loosen the bolts and nuts in the proper sequence as shown.
- Loosen each nut 1/2 of a turn at a time. After all of the nuts are fully loosened, remove them.



## EAS24160

# CHECKING THE CYLINDER HEAD

- 1. Eliminate:
  - Combustion chamber carbon deposits (with a rounded scraper)

#### TIP\_

Do not use a sharp instrument to avoid damaging or scratching:

- · Spark plug bore threads
- Valve seats



- 2. Check:
  - Cylinder head
  - Damage/scratches  $\rightarrow$  Replace.
  - Cylinder head water jacket Mineral deposits/rust  $\rightarrow$  Eliminate.

- 3. Measure:
  - Cylinder head warpage Out of specification  $\rightarrow$  Resurface the cylinder head.





a. Place a straightedge "1" and a thickness gauge "2" across the cylinder head.



90890-03180 Feeler gauge set YU-26900-9



- b. Measure the warpage.
- c. If the limit is exceeded, resurface the cylinder head as follows.
- d. Place a 400-600 grit wet sandpaper on the surface plate and resurface the cylinder head using a figure-eight sanding pattern.

#### TIP\_

To ensure an even surface, rotate the cylinder head several times.

## 

#### FAS24240 **INSTALLING THE CYLINDER HEAD** 1. Install:

- Dowel pins
  - Cylinder head gasket New

# 2. Install:

- Cylinder head
- Washers New
- Cylinder head nuts New
- Cylinder head bolts

## TIP\_

- Pass the timing chain through the timing chain cavity.
- Lubricate the cylinder head nuts and washers with engine oil.

# 3. Tighten:

- Cylinder head nuts "1"-"6"
- Cylinder head bolts "7", "8"
- Cylinder bolt "9"



Cylinder head nut 1st: 10 Nm (1.0 m·kgf, 7.2 ft·lbf) 2nd: 20 Nm (2.0 m·kgf, 14 ft·lbf) 3rd: 120° Cylinder head bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf) Cylinder bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

TIP\_

- Using the indicated tightening sequence, tighten the cylinder head nuts, cylinder head bolts, and cylinder bolt when the cylinder head and cylinder are cold.
- Use three steps to tighten the cylinder head nuts.



- 4. Install:
  - Exhaust camshaft
  - Intake camshaft Refer to "INSTALLING THE CAM-SHAFTS" on page 5-14.

# VALVES AND VALVE SPRINGS



\* Silicone fluid

# **VALVES AND VALVE SPRINGS**

#### EAS24280 REMOVING THE VALVES

The following procedure applies to all of the valves and related components.

#### TIP\_

Before removing the internal parts of the cylinder head (e.g., valves, valve springs, valve seats), make sure the valves properly seal.

- 1. Remove:
  - Valve lifter "1"
  - Valve pad "2"

#### TIP\_

Make a note of the position of each valve lifter and valve pad so that they can be reinstalled in their original place.



- 2. Check:
  - Valve sealing

Leakage at the valve seat  $\rightarrow$  Check the valve face, valve seat, and valve seat width.

Refer to "CHECKING THE VALVE SEATS" on page 5-24.

#### \*\*\*\*

- a. Pour a clean solvent "a" into the intake and exhaust ports.
- b. Check that the valves properly seal.

#### TIP.

There should be no leakage at the valve seat "1".



## \*\*\*\*

- 3. Remove:
  - Valve cotters

#### TIP\_

Remove the valve cotters by compressing the valve spring with the valve spring compressor "1" and the valve spring compressor attachment "2".



Valve spring compressor 90890-04019 YM-04019 Valve spring compressor attachment 90890-04114 Valve spring compressor adapter 19.5 mm YM-04114



- 4. Remove:
  - Valve spring retainer "1"
  - Valve spring "2"
  - Valve "3"
  - Valve stem seal "4"
  - Valve spring seat "5"

#### TIP.

Identify the position of each part very carefully so that it can be reinstalled in its original place.



#### EAS24290

# CHECKING THE VALVES AND VALVE GUIDES

The following procedure applies to all of the valves and valve guides.

- 1. Measure:
  - Valve-stem-to-valve-guide clearance Out of specification → Replace the valve guide.
- Valve-stem-to-valve-guide clearance = Valve guide inside diameter "a" -Valve stem diameter "b"







2. Replace:Valve guide

TIP\_

To ease valve guide removal and installation, and to maintain the correct fit, heat the cylinder head to 100  $^{\circ}$ C (212  $^{\circ}$ F) in an oven.

#### \*\*\*\*

a. Remove the valve guide with the valve guide remover "1".



 Install the new valve guide with the valve guide installer "2" and valve guide remover "1".



c. After installing the valve guide, bore the valve guide with the valve guide reamer "3" to obtain the proper valve-stem-to-valve-guide clearance.



# TIP.

After replacing the valve guide, reface the valve seat.

A	Valve guide remover (ø4) 90890-04111
	Valve guide remover (4.0 mm) YM-04111
	Valve guide installer (ø4) 90890-04112
	Valve guide installer (4.0 mm) YM-04112
	Valve guide reamer (ø4) 90890-04113
	Valve guide reamer (4.0 mm) YM-04113

\*\*\*\*

- 3. Eliminate:
  - Carbon deposits

(from the valve face and valve seat)

- 4. Check:
  - Valve face Pitting/wear  $\rightarrow$  Grind the valve face.
  - Valve stem end Mushroom shape or diameter larger than the body of the valve stem → Replace the valve.
- 5. Measure:
  - Valve margin thickness "a"
     Out of specification → Replace the valve.





- 6. Measure:
  - Valve stem runout Out of specification → Replace the valve.

## TIP\_

- When installing a new valve, always replace the valve guide.
- If the valve is removed or replaced, always replace the valve stem seal.





# EAS24300

# CHECKING THE VALVE SEATS

The following procedure applies to all of the valves and valve seats.

- 1. Eliminate:
  - Carbon deposits (from the valve face and valve seat)
- 2. Check:
  - Valve seat Pitting/wear → Replace the cylinder head.
- 3. Measure:
  - Valve seat width "a" Out of specification → Replace the cylinder head.





## \*\*\*\*

a. Apply Mechanic's blueing dye (Dykem) "b" onto the valve face.



- b. Install the valve into the cylinder head.
- c. Press the valve through the valve guide and onto the valve seat to make a clear impression.
- d. Measure the valve seat width.

#### TIP\_

Where the valve seat and valve face contacted one another, the blueing will have been removed.

## \*\*\*\*\*

- 4. Lap:
  - Valve face
  - Valve seat

#### TIP\_

After replacing the cylinder head or replacing the valve and valve guide, the valve seat and valve face should be lapped. \*\*\*\*

a. Apply a coarse lapping compound "a" to the valve face.

#### ECA13790 **NOTICE**

Do not let the lapping compound enter the gap between the valve stem and the valve guide.



b. Apply molybdenum disulfide oil onto the valve stem.



- c. Install the valve into the cylinder head.
- d. Turn the valve until the valve face and valve seat are evenly polished, then clean off all of the lapping compound.

## TIP.

For the best lapping results, lightly tap the valve seat while rotating the valve back and forth between your hands.



e. Apply a fine lapping compound to the valve face and repeat the above steps.

# VALVES AND VALVE SPRINGS

- f. After every lapping procedure, be sure to clean off all of the lapping compound from the valve face and valve seat.
- g. Apply Mechanic's blueing dye (Dykem) "b" onto the valve face.



- h. Install the valve into the cylinder head.
- i. Press the valve through the valve guide and onto the valve seat to make a clear impression.
- j. Measure the valve seat width "c" again. If the valve seat width is out of specification, reface and lap the valve seat.



#### **\*\*\*\***

#### EAS24310

## CHECKING THE VALVE SPRINGS

The following procedure applies to all of the valve springs.

- 1. Measure:
  - Valve spring free length "a" Out of specification → Replace the valve spring.





- 2. Measure:
  - Compressed valve spring force "a" Out of specification → Replace the valve spring.
  - Installed compression spring force (intake) 96.6–111.2 N (9.85–11.34 kgf, 21.72–25.00 lbf) Installed compression spring force (exhaust) 96.6–111.2 N (9.85–11.34 kgf, 21.72–25.00 lbf) Installed length (intake) 30.60 mm (1.20 in) Installed length (exhaust) 30.60 mm (1.20 in)



- b. Installed length
- 3. Measure:
  - Valve spring tilt "a" Out of specification → Replace the valve spring.



Spring tilt (intake) 1.6 mm (0.06 in) Spring tilt (exhaust) 1.6 mm (0.06 in)



## EAS24320

# CHECKING THE VALVE LIFTERS

The following procedure applies to all of the valve lifters.

- 1. Check:
  - Valve lifter

Damage/scratches  $\rightarrow$  Replace the valve lifters and cylinder head.



#### EAS24340

## INSTALLING THE VALVES

The following procedure applies to all of the valves and related components.

- 1. Deburr:
  - Valve stem end (with an oil stone)



- 2. Lubricate:
  - Valve stem "1"
  - Valve stem seal "2" (with the recommended lubricant)



Recommended lubricant Molybdenum disulfide oil



- 3. Install:
  - Valve spring seat "1"
  - Valve stem seal "2" New
  - Valve "3"
  - Valve spring "4"
  - Valve spring retainer "5" (into the cylinder head)

#### TIP\_

- Make sure each valve is installed in its original place.
- Install the valve springs with the larger pitch "a" facing up.





- b. Smaller pitch
- 4. Install:
  - Valve cotters "1"

TIP\_

Install the valve cotters by compressing the valve spring with the valve spring compressor
"2" and the valve spring compressor attachment "3".



Valve spring compressor 90890-04019 YM-04019 Valve spring compressor attachment 90890-04114 Valve spring compressor adapter 19.5 mm YM-04114



 To secure the valve cotters onto the valve stem, lightly tap the valve tip with a softface hammer. ECA13800

#### NOTICE

Hitting the valve tip with excessive force could damage the valve.



- 6. Lubricate:
  - Valve pad (with the recommended lubricant)



- 7. Lubricate:
  - Valve lifter
    - (with the recommended lubricant)

#### Recommended lubricant Engine oil

#### 8. Install:

- Valve pad
- Valve lifter
- ECA4B51016

#### NOTICE

After making sure that the valve pads are fully inserted, install the valve lifter taking care so that the pads do not fall.

TIP\_

- The valve lifter must move smoothly when rotated with a finger.
- Each valve lifter and valve pad must be reinstalled in its original position.



#### EAS24380 REMOVING THE PISTONS

The following procedure applies to all of the piston.

- 1. Remove:
  - Piston pin clips "1"
  - Piston pin "2"
  - Piston "3"

ECA13810

#### NOTICE

# Do not use a hammer to drive the piston pin out.

TIP\_

- Before removing the piston pin clip, cover the crankcase opening with a clean rag to prevent the piston pin clip from falling into the crankcase.
- For reference during installation, put an identification mark on each piston crown.
- Before removing the piston pin, deburr the piston pin clip's groove and the piston's pin bore area. If both areas are deburred and the piston pin is still difficult to remove, remove it with the piston pin puller set "4".

Piston pin puller set 90890-01304 Piston pin puller YU-01304





- 2. Remove:
  - Top ring
  - 2nd ring
  - Oil ring

#### TIP\_

When removing a piston ring, open the end gap with your fingers and lift the other side of the ring over the piston crown.



#### EAS24400

# CHECKING THE CYLINDERS AND PISTONS

The following procedure applies to all of the cylinders and pistons.

- 1. Check:
  - Piston wall
  - Cylinder wall Vertical scratches → Replace the cylinder, piston and piston rings as a set.
- 2. Measure:
  - Piston-to-cylinder clearance

#### \*\*\*\*

a. Measure cylinder bore with the cylinder bore gauge.

#### TIP\_

Measure cylinder bore by taking side-to-side and front-to-back measurements of the cylinder. Then, find the average of the measurements.

Bore 68.000–68.010 mm (2.6772– 2.6776 in) Wear limit 68.100 mm (2.6811 in) Taper limit 0.050 mm (0.0020 in) Out of round limit 0.050 mm (0.0020 in)

Bore = maximum of  $D_1 - D_2$ 

Taper limit = maximum of  $D_1$  or  $D_2$  - maxi-

mum of D<sub>5</sub> or D<sub>6</sub>

Out of round limit = maximum of  $D_1$ ,  $D_3$  or  $D_5$ - minimum of  $D_2$ ,  $D_4$  or  $D_6$ 



- b. If out of specification, replace the cylinder, piston and piston rings as a set.
- c. Measure piston skirt diameter "a" with the micrometer.



b. 9.0 mm (0.35 in) from the bottom edge of the piston



- d. If out of specification, replace the piston and piston rings as a set.
- e. Calculate the piston-to-cylinder clearance with the following formula.
- Piston-to-cylinder clearance = Cylinder bore -Piston skirt diameter



#### Piston-to-cylinder clearance 0.010–0.035 mm (0.0004– 0.0014 in)

Limit 0.15 mm (0.0059 in)

f. If out of specification, replace the cylinder, piston and piston rings as a set.

\*\*\*\*\*

#### EAS24430

## CHECKING THE PISTON RINGS

- 1. Measure:
  - Piston ring side clearance Out of specification → Replace the piston and piston rings as a set.

TIP\_

Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.

2ª	Piston ring Top ring Ring side clearand 0.030–0.065 m 0.0026 in)	ce nm	(0.0012–
	0 100 mm (0 003	9 in)	
	2nd ring	5 111)	
	Ring side clearand	e	
	0.020–0.055 m	nm	(0.0008–
	0.0022 in)		-
	Limit		
	0.100 mm (0.0039 in)		



- 2. Install:
  - Piston ring (into the cylinder)

TIP\_

Level the piston ring into the cylinder with the piston crown.

- 3. Measure:
  - Piston ring end gap
    - Out of specification  $\rightarrow$  Replace the piston ring set.

#### TIP\_

The oil ring expander spacer's end gap cannot be measured. If the oil ring rail's gap is excessive, replace all three piston rings.





a. 40 mm (1.57 in)

#### EAS24440

#### CHECKING THE PISTON PINS

The following procedure applies to both of the piston pins.

- 1. Check:
  - Piston pin Blue discoloration/grooves → Replace the piston pin and then check the lubrication system.
- 2. Measure:
  - Piston pin outside diameter "a" Out of specification → Replace the piston pin.



#### Piston pin outside diameter

- 15.991–16.000 mm (0.6296–
- 0.6299 in)
- Limit
  - 15.971 mm (0.6288 in)



- 3. Measure:
  - Piston pin bore inside diameter "b" Out of specification → Replace the piston.





- 4. Calculate:
  - Piston-pin-to-piston-pin-bore clearance Out of specification → Replace the piston pin and piston as a set.

 Piston-pin-to-piston-pin-bore clearance = Piston pin bore inside diameter -Piston pin outside diameter



#### EAS24470 INSTALLING THE PISTONS AND CYLINDER

The following procedure applies to all of the pistons and cylinders.

- 1. Install:
  - Oil ring expander "1"
  - Lower oil ring rail "2"
  - Upper oil ring rail "3"
  - 2nd ring "4"
  - Top ring "5"
    - (into the piston)

#### TIP\_

Be sure to install the top and 2nd rings so that the manufacturer marks or numbers "a" face up.



- 2. Install:
  - Piston "1"
  - Piston pin "2"
  - Piston pin clips "3" New

#### TIP\_

- Apply engine oil onto the piston pin.
- Make sure the mark "a" on the piston points towards the exhaust side of the cylinder.
- Before installing the piston pin clip, cover the crankcase opening with a clean rag to prevent the piston pin clip from falling into the crankcase.
- Install the piston pin clips so that the clip ends are 3 mm (0.12 in) "b" or more from the cutout in the piston.
- Reinstall each piston into its original cylinder.





- 3. Install:
  - Dowel pins
  - Cylinder gasket New
- 4. Lubricate:
  - Piston
  - Piston rings
  - Cylinder
    - (with the recommended lubricant)

### Recommended lubricant Engine oil

- 5. Offset:
  - Piston ring end gaps



- a. Top ring
- b. 2nd ring
- c. Upper oil ring rail
- d. Oil ring expander
- e. Lower oil ring rail
- A. Exhaust side

- 6. Install:
  - Cylinder
  - Cylinder bolt

#### TIP\_

- While compressing the piston rings, install the cylinder.
- Pass the timing chain and timing chain guide (intake side) through the timing chain cavity.
- 7. Tighten:
  - Cylinder bolt



Cylinder bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

# ELECTRIC STARTER



Order	Job/Parts to remove	Q'ty	Remarks
	Storage box		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
1	Ground lead	1	Disconnect.
2	Starter motor lead	1	Disconnect.
3	Starter motor assembly	1	
			For installation, reverse the removal proce- dure.

# **ELECTRIC STARTER**



\* When replacing any of the starter motor front cover, armature assembly, starter motor yoke, insulator, and starter motor rear cover, replace the starter motor assembly.

#### EAS24791 CHECKING THE STARTER MOTOR

- 1. Check:
  - Commutator

 $\mbox{Dirt} \rightarrow \mbox{Clean}$  with 600 grit sandpaper.

- 2. Measure:
  - Mica undercut "a" Out of specification → Scrape the mica to the proper measurement with a hacksaw blade that has been grounded to fit the commutator.



Mica undercut (depth) 0.70 mm (0.03 in)

#### TIP\_

The mica of the commutator must be undercut to ensure proper operation of the commutator.



- 3. Measure:
  - Armature assembly resistances (commutator and insulation)
     Out of specification → Replace the starter motor.
- \*\*\*\*
- a. Measure the armature assembly resistances with the digital circuit tester.



Digital circuit tester 90890-03189 Model 88 Multimeter with tachometer YU-A1927



Armature coil Commutator resistance Continuity ( $0.0100-0.0200 \Omega$ ) Insulation resistance No continuity (Above 1 M $\Omega$ )

b. If any resistance is out of specification, replace the starter motor assembly.



- 1. Commutator resistance
- 2. Insulation resistance

#### \*\*\*\*

- 4. Measure:
  - Brush length "a" Out of specification → Replace the brush holder set.





- 5. Measure:
  - Brush spring force Out of specification → Replace the brush holder set.



Brush spring force 6.02–6.51 N (614–664 gf, 21.65–23.41 oz)

# **ELECTRIC STARTER**



- 6. Check:
  - Gear teeth

- 7. Check:
  - Bearing

 $\label{eq:def-Damage/pitting} \begin{array}{l} \rightarrow \mbox{Replace the starter} \\ \mbox{motor assembly.} \end{array}$ 

# ASSEMBLING THE STARTER MOTOR

- 1. Install:
  - Insulator "1"

#### TIP\_

Install the insulator so that the slot "a" is positioned as shown in the illustration.





#### EAS24810 INSTALLING THE STARTER MOTOR

- 1. Connect:
  - Battery negative lead "1"

#### TIP\_

Make sure that the battery negative lead "1" does not touch the starter motor bolt "2".



- 2. Install:
  - Starter motor yoke "1"
  - Starter motor rear cover "2"
  - Starter motor front cover "3"

#### TIP.

- Align tab "a" of the starter motor rear cover with notch "b" of the starter motor yoke.
- Align the match mark "c" on the starter motor yoke with the match mark "d" on the starter motor front cover.

# V-BELT AUTOMATIC TRANSMISSION



\* Water

# **V-BELT AUTOMATIC TRANSMISSION**



\* Water



\*1 Apply Shell Sunlight Grease 3®.

\*2 Apply YAMAHA GREASE "H" or Polyurea Grease®.

## **V-BELT AUTOMATIC TRANSMISSION**



\*1 Apply YAMAHA GREASE "H" or Polyurea Grease®.

\*2 When replacing the primary sliding sheave or collar, replace them as a set.

# **V-BELT AUTOMATIC TRANSMISSION**



\* Apply YAMAHA GREASE "H" or Polyurea Grease®.

#### EAS4B51022 REMOVING THE PRIMARY SHEAVE AND SECONDARY SHEAVE

- 1. Remove:
  - Primary sheave nut "1"
  - Secondary sheave nut "2"

#### TIP\_

While holding the primary and secondary sheave with the sheave holder "3", loosen the nut.







- 2. Remove:
  - Primary sheave assembly "1"
  - Secondary sheave assembly "2"
  - V-belt "3"

#### TIP.

- Before removal, put alignment marks "a" and "b" as shown.
- Align these marks during reassembly.



#### EAS24640 DISASSEMBLING THE SECONDARY SHEAVE

- 1. Loosen:
  - Secondary sheave spring seat nut "1"

#### TIP\_

- While holding the secondary fixed sheave "2" with the sheave holder "3", loosen the secondary sheave spring seat nut with the lock-nut wrench "4".
- Do not loosen the secondary sheave spring seat nut "1" more than 1/4 turn.

Sheave holder 90890-01481 Locknut wrench 90890-01348 YM-01348



- 2. Remove:
  - Secondary sheave spring seat nut "1"

#### TIP.

Install the sheave spring compressor "2" and sheave fixed block "3" onto the secondary sheave assembly as shown. Then, compress the spring, and remove the secondary sheave spring seat nut with locknut wrench "4".





#### EAS24670

## CHECKING THE V-BELT

 Check:

 V-belt "1" Cracks/damage/we

Cracks/damage/wear  $\rightarrow$  Replace. Grease/oil  $\rightarrow$  Clean the primary and secondary sheave.

- 2. Measure:
  - V-belt width "a"

Out of specification  $\rightarrow$  Replace.

#### TIP\_

Place plate "2" on the upper of the belt and measure the width of the upper end of the belt.

V-belt width 32.9 mm (1.30 in) Limit 31.4 mm (1.24 in)



#### EAS24680 CHECKING THE PRIMARY SHEAVE

- 1. Check:
  - Primary sliding sheave
  - Primary fixed sheave Cracks/damage/wear → Replace the primary sliding sheave and primary fixed sheave as a set.

#### EAS4B51023

# CHECKING THE V-BELT CASE AIR DUCT

- 1. Check
  - V-belt case air duct Cracks/damage → Replace.

#### EAS24690 CHECKING THE PRIMARY SHEAVE WEIGHTS

The following procedure applies to all of the primary sheave weights.

- 1. Check:
  - Primary sheave weight
    - Cracks/damage/wear  $\rightarrow$  Replace.
- 2. Measure:
  - Primary sheave weight outside diameter Out of specification → Replace.

Primary sheave weight outside diameter 24.9–25.1 mm (0.98–0.99 in) Limit 24.4 mm (0.96 in)



#### EAS24700 CHECKING THE SLIDERS

The following procedure applies to all of the sliders.

- 1. Check:
  - Slider

Cracks/damage/wear  $\rightarrow$  Replace.

### 

### CHECKING THE SECONDARY SHEAVE

- 1. Check:
  - Secondary fixed sheave
  - Secondary sliding sheave Cracks/damage/wear → Replace the secondary fixed and sliding sheaves as a set.
- 2. Check:
  - Torque cam groove "1" Damage/wear → Replace the secondary fixed and sliding sheaves as a set.
- 3. Check:
  - Guide pin "2"

Damage/wear  $\rightarrow$  Replace the secondary fixed and sliding sheaves as a set.



#### EAS24720 ASSEMBLING THE PRIMARY SHEAVE

#### 1. Clean:

- Primary fixed sheave
- Primary sliding sheave
- Collar
- Cam
- Primary sheave weights
- 2. Install:
  - Primary sheave weights "1"
  - Sliders "2"
  - Cam "3"

#### TIP\_

Do not apply the grease inside of the primary sheave.



#### EAS24730 ASSEMBLING THE SECONDARY SHEAVE

- 1. Lubricate:
  - Secondary fixed sheave inner surface "1"
  - Secondary sliding sheave inner surface "2"
  - Oil seals New

(with the recommended lubricant)





- 2. Install:
  - Guide pins

#### TIP.

Before installing the guide pin, align the position (where fixed sheave rivet head "a" and guide pin hole "b" are in alignment with each other) with alignment mark "c" of the sliding sheave. Install the guide pin. Then, make sure that the sliding sheave slides to the LOW side without an interference of rivet head "d".



# V-BELT AUTOMATIC TRANSMISSION



3. Lubricate:

• Guide pin groove "1"

 O-rings "2" New (with the recommended lubricant)





- 4. Install:
  - Secondary sheave spring seat nut "1"

#### TIP\_

- Install the secondary sheave spring seat nut with its beveled side "a" facing the spring seat.
- Attach the sheave spring compressor "2" and sheave fixed block "3" onto the secondary sheave as shown.

Then compress the spring, and temporarily tighten the secondary sheave spring seat nut.



90890-04134 Sheave fixed block 90890-04135 Sheave fixed bracket YM-04135





5. Tighten:

Secondary sheave spring seat nut "1"

#### TIP\_

While holding the secondary fixed sheave "2" with the sheave holder "3", tighten the secondary sheave spring seat nut "1" with the locknut wrench "4".





#### EAS4B51024 INSTALLING THE PRIMARY SHEAVE **ASSEMBLY, SECONDARY SHEAVE ASSEM-BLY AND V-BELT**

- 1. Apply:
  - Sealant

(onto the inner V-belt case seal)



Yamaha bond No.1215 90890-85505 (Three bond No.1215®)



- 2. Install:
  - V-belt case air duct joint clamp "1"
  - V-belt case air duct "2"

#### TIP

- Align the projection "a" in the V-belt case air duct "2" with the slot "b" on the V-belt case air duct joint clamp "1".
- Align the projection "c" in the V-belt case air duct "2" with the slot "d" in the inner V-belt case "3".



- 3. Install:
  - Primary fixed sheave "1"
  - V-belt "2"
  - Secondary sheave assembly "3"

ECA4B51017

#### NOTICE

Do not allow grease to contact the V-belt, primary and secondary sheave.

#### TIP\_

- When installing the belt, screw M6 (more than 45 mm (1.77 in)) bolts "4" to spread apart the secondary sheave and then install the V-belt. Make sure to install the V-belt with the arrow facing in the direction shown.
- · Install the V-belt and secondary sheave assembly then pass the V-belt the primary sheave side.
- Align the "a" and "b" during reassembly.



- 4. Tighten:
  - Secondary sheave nut "1"

#### TIP.

While holding the secondary sheave with the sheave holder "2", tighten the secondary sheave nut.



- 5. Tighten:
  - Primary sheave nut "1"

#### ECA4B51022 NOTICE

 Before tightening the nut to remount the primary sheave, make sure that the serra-

# **V-BELT AUTOMATIC TRANSMISSION**

tions of the cam are fitted firmly into the serrations of the crankshaft.

- Also, make sure that cam is properly seated.
- Apply grease to the thread and seat of the primary sheave nut.



Recommended lubricant Shell Sunlight Grease 3®

TIP.

While holding the primary sheave with the sheave holder "2", tighten the primary sheave nut.



Primary sheave nut 160 Nm (16 m·kgf, 116 ft·lbf)

Sheave holder 90890-01481



EAS4B51025

#### **INSTALLING THE V-BELT CASE**

- 1. Install:
  - Oil seal "1"

(into outer V-belt case)

Installed depth of oil seal "a" 4.0–4.3 mm (0.16–0.17 in)

2. Fill the space "b" shown in the illustration with 10 g (0.35 oz) or more of lithium-soap-based grease.



3. Install:

• Bearing retainer "1"

TIP\_

- Install the bearing retainer "1" with its mark "a" facing outward.
- Apply locking agent (LOCTITE®) to the threads of the bearing retainer bolt.











\* When replacing the crankshaft position sensor or stator coil, replace them as a set.

#### EAS24490 REMOVING THE GENERATOR

- 1. Remove:
  - Generator cover

#### TIP\_

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.



- 2. Remove:
  - Generator rotor nut "1"
  - Spacer "2"

#### TIP\_

- While holding the generator rotor "3" with the sheave holder "4", loosen the generator rotor nut.
- Do not allow the sheave holder to touch the projection on the generator rotor.





- 3. Remove:
  - Generator rotor "1" (with the flywheel puller "2")
  - Woodruff key

#### TIP\_

Make sure the flywheel puller is centered over the generator rotor.





#### EAS24560 REMOVING THE STARTER CLUTCH

- 1. Remove:
  - Starter clutch bolts "1"
  - Starter clutch

#### TIP.

- While holding the generator rotor "2" with the sheave holder "3", remove the starter clutch bolts.
- Do not allow the sheave holder to touch the projection on the generator rotor.





EAS24570

### CHECKING THE STARTER CLUTCH

- 1. Check:
  - Starter clutch rollers "1" Damage/wear → Replace.



- 2. Check:
  - Starter clutch idle gear "1"
  - Starter clutch gear "2" Burrs/chips/roughness/wear  $\rightarrow$  Replace the defective part(s).



- 3. Check:
  - Starter clutch gear contacting surfaces Damage/pitting/wear  $\rightarrow$  Replace the starter clutch gear.
- 4. Check:
  - Starter clutch operation

- a. Install the starter clutch gear "1" onto the starter clutch "2" and hold the starter clutch.
- b. When turning the starter clutch gear counterclockwise "A", the starter clutch and the starter clutch gear should engage, otherwise the starter clutch is faulty and must be replaced.
- c. When turning the starter clutch gear clockwise "B", it should turn freely, otherwise the starter clutch is faulty and must be replaced.



#### FAS24990

#### **CHECKING THE OIL STRAINER**

- 1. Check:
  - Oil strainer Damage  $\rightarrow$  Replace. Contaminants  $\rightarrow$  Clean with solvent.

#### EAS59C1505

### ASSEMBLING THE OIL TANK

- 1. Install:
  - Bearing

#### TIP

Seal "a" is adhered only on one side of the bearing. Note the press-in orientation.



#### EAS24600

- **INSTALLING THE STARTER CLUTCH**
- 1. Install:
  - Starter clutch
  - Starter clutch bolts "1"



**LOCTITE®** 

TIP.

- While holding the generator rotor "2" with the sheave holder "3", tighten the starter clutch bolts.
- Do not allow the sheave holder to touch the projection on the generator rotor.





EAS24500

#### INSTALLING THE GENERATOR

- 1. Install:
  - Woodruff key
  - Generator rotor "1"
  - Spacer "2"
  - Generator rotor nut "3" New

#### TIP\_

- Clean the tapered portion of the crankshaft and the generator rotor hub.
- When installing the generator rotor, make sure the woodruff key is properly sealed in the keyway of the crankshaft.
- Lubricate the generator rotor nut seats and threads with engine oil.



- 2. Tighten:
  - Generator rotor nut "1"

### Generator rotor nut (1st) 65 Nm (6.5 m·kgf, 47 ft·lbf)

#### TIP.

• While holding the generator rotor "2" with the sheave holder "3", tighten the generator rotor nut.

• Do not allow the sheave holder to touch the projection on the generator rotor.





Generator rotor nut (2nd) Specified angle 120°

#### ECA4B51018

NOTICE

- When tightening the generator rotor nut, be sure to use a beam type torque wrench.
- Tighten the nut until it is at the specified angle.



- 3. Apply:
- Sealant

(onto the crankshaft position sensor/stator lead grommet)



Yamaha bond No.1215 90890-85505 (Three bond No.1215®)



- 4. Install:
  - Generator cover



TIP\_

Tighten the generator cover bolts in stages and in a crisscross pattern.

# EAS25061





Order	Job/Parts to remove	Q'ty	Remarks
1	Clip	1	
2	Spring stopper plate	1	
3	Clutch spring plate	1	
4	Pressure plate	1	
5	Clutch plate 2	2	
6	Clutch damper spring	7	
7	Friction plate	6	
8	Clutch plate 1	5	
9	Clutch spring	6	
10	Thrust plate	1	
11	Clutch boss nut	1	
12	Primary drive gear	1	
13	Bearing	2	
14	Clutch boss	1	
15	Collar	1	



#### EAS25070 REMOVING THE CLUTCH

- 1. Remove:
  - Clutch assembly nut "1"
  - Clutch assembly "2"

#### TIP\_

- Before removal, put alignment marks "a" and "b" as shown.
- While holding the clutch assembly with the rotor holding tool "3", loosen the clutch assembly nut.
- Align these marks during reassembly.



Rotor holding tool 90890-01235 Universal magneto & rotor holder YU-01235





#### EAS4B51026

#### DISASSEMBLING THE CLUTCH

- 1. Remove:
  - Clip "1"

#### TIP\_

While compressing the clutch springs with the clutch spring compressor "2", remove the clip.



Clutch spring compressor 90890-01482



- 2. Remove:
  - Spring stopper plate "1"

#### TIP\_\_\_

To ensure proper balance of the clutch assembly, one to three holes "a", or no hole at all, may have been drilled in the spring stopper plate. Before removing the spring stopper plate, make alignment marks on both the plate and the clutch housing so that the plate can be reinstalled in its original position.



- 3. Loosen:
- Clutch boss nut "1"

#### TIP.

While holding the clutch boss "2" with the universal clutch holder "3", loosen the clutch boss nut.





#### EAS25100 CHECKING THE FRICTION PLATES

The following procedure applies to all of the friction plates.

- 1. Check:
  - Friction plate Damage/wear → Replace the friction plates as a set.
- 2. Measure:
  - Friction plate thickness Out of specification → Replace the friction plates as a set.

TIP\_

Measure the friction plate at four places.



Friction plate thickness 2.92–3.08 mm (0.115–0.121 in) Wear limit 2.82 mm (0.1110 in)

#### EAS25111

### CHECKING THE CLUTCH PLATES

The following procedure applies to all of the clutch plates.

- 1. Check:
  - Clutch plate

Damage  $\rightarrow$  Replace the clutch plates as a set.

- 2. Measure:
  - Clutch plate warpage

(with a surface plate and thickness gauge "1")

Out of specification  $\rightarrow$  Replace the clutch plates as a set.



Thickness gauge 90890-03180 Feeler gauge set YU-26900-9



Warpage limit Clutch plate 1 0.10 mm (0.0039 in) Clutch plate 2 0.20 mm (0.0079 in)



#### EAS4B51027 CHECKING THE CLUTCH DAMPER SPRINGS

The following procedure applies to all of the clutch damper springs.

- 1. Check:
  - Clutch damper spring Damage → Replace.
- 2. Measure:
  - Clutch damper spring free height "a" Out of specification → Replace the clutch damper springs as a set.



Clutch damper spring height 3.50 mm (0.14 in) Minimum height 3.10 mm (0.12 in)



EAS25130 CHECKING THE CLUTCH SPRING PLATE

- 1. Check:
  - Clutch spring plate
  - Damage  $\rightarrow$  Replace.
- 2. Measure:
  - Clutch spring plate free height "a" Out of specification → Replace the clutch spring plate.



#### Clutch spring plate height 4.70 mm (0.19 in) Minimum height 4.40 mm (0.17 in)



#### EAS25140

#### CHECKING THE CLUTCH SPRINGS

The following procedure applies to all of the clutch springs.

- 1. Check:
  - Clutch spring Damage → Replace the clutch springs as a set.
- 2. Measure:
  - Clutch spring free length Out of specification → Replace the clutch springs as a set.





I1412901

#### EAS25150 CHECKING THE CLUTCH HOUSING

- 1. Check:
  - Clutch housing dogs Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

#### TIP\_

Pitting on the clutch housing dogs will cause erratic clutch operation.



#### EAS25160

### CHECKING THE CLUTCH BOSS

- 1. Check:
  - Clutch boss splines Damage/pitting/wear → Replace the clutch boss.

TIP\_

Pitting on the clutch boss splines will cause erratic clutch operation.



EAS59C1504

CHECKING THE PRESSURE PLATE AND THRUST PLATE

- 1. Check:
  - Pressure plate "1"
  - Thrust plate "2" Cracks/damage  $\rightarrow$  Replace.



#### EAS4B51029 ASSEMBLING THE CLUTCH

- 1. Install:
  - Clutch boss
  - Primary drive gear
  - Clutch boss nut
- 2. Tighten:
  - Clutch boss nut "1"



#### Clutch boss nut 130 Nm (13 m·kgf, 94 ft·lbf)

TIP\_

While holding the clutch boss "2" with the universal clutch holder "3", tighten the clutch boss nut.



Universal clutch holder 90890-04086 YM-91042



- 3. Install:
  - Clutch weights
  - Thrust plate "1"
  - Clutch springs
  - Clutch damper springs "2"
  - Clutch plates 2 "3"
  - Friction plates "4"
  - Clutch plates 1 "5"
  - Pressure plate "6"
  - Clutch spring plate "7"

#### TIP\_

- Clutch damper spring "a" installed at the end must be installed backwards.
- The pressure plate "6" and thrust plate "1" can be identified by punch mark "b" on the pressure plate.





- 4. Install:
  - Clip "1"

TIP\_

While compressing the clutch springs with the clutch spring compressor "2", install the clip.




### **CLUTCH**

# EAS25240 INSTALLING THE CLUTCH

- 1. Install:
  - Clutch assembly "1"
  - Clutch assembly nut "2"



#### Clutch assembly nut 65 Nm (6.5 m·kgf, 47 ft·lbf)

#### TIP.

- Align the "a" and "b" during reassembly.
- While holding the clutch assembly with the rotor holding tool "3", tighten the clutch assembly nut.







# EAS24901



### **OIL PUMP**

Disassemb	ling the oil pump assembly			
			<b>6 Nm (0.6 m + kaf 4.2 ft + lbf)</b>	
Order	Job/Parts to remove	Q'ty	Remarks	
1	Oil pump housing 1	1		
2	Dowel pin	2		
3	Oil pump outer rotor 1	1		
4	Oil pump inner rotor 1	1		
5	Pin	1		
6	Washer	1		
7	Oil pump housing center	1		
8	Oil pump outer rotor 2	1		
9	Oil pump inner rotor 2	1		
10	Pin	1		
11	Oil pump driven gear	1		
12	Oil pump housing 2	1		
		-	For assembly, reverse the disassembly pro-	
			cedure.	

\* When replacing any of the part, replace the oil pump assembly.

#### EAS24960 CHECKING THE OIL PUMP

- 1. Check:
  - Oil pump driven gear "1"
  - Oil pump housing 2 "2"
  - Oil pump housing 1 "3" Cracks/damage/wear → Replace the oil pump assembly.



- 2. Check:
  - Oil pump operation Rough movement → Repeat steps (1) and (2) or replace the oil pump assembly.



#### EAS24971

#### CHECKING THE RELIEF VALVE

- 1. Check:
  - Relief valve body Damage/wear → Replace.

#### EAS4B51030

#### CHECKING THE OIL PIPES

- 1. Check:
  - Oil pipe
  - Oil delivery pipe
    - Damage  $\rightarrow$  Replace.

Obstruction  $\rightarrow$  Wash and blow out with compressed air.

#### EAS4B51031

### CHECKING THE OIL PUMP DRIVE CHAIN

- 1. Check:
  - Oil pump drive chain Cracks/stiffness → Replace the oil pump chain and oil pump assembly as a set.



# ASSEMBLING THE OIL PUMP

- 1. Lubricate:
  - Inner rotor
  - Outer rotor
  - Oil pump shaft (with the recommended lubricant)



#### Recommended lubricant Engine oil

- 2. Install:
  - Inner rotors

#### TIP.

When installing the inner rotor, align the pins "1" in the oil pump shaft with the grooves "a" in the inner rotor.



- 3. Check:
  - Oil pump operation Refer to "CHECKING THE OIL PUMP" on page 5-67.

#### EAS25020

#### INSTALLING THE OIL PUMP

- 1. Install:
  - Oil pump assembly



ECA13890

NOTICE

After tightening the bolts, make sure the oil pump turns smoothly.

# CRANKCASE



### CRANKCASE



### CRANKCASE



#### EAS25560 DISASSEMBLING THE CRANKCASE

- 1. Remove:
  - Crankcase bolts

#### TIP\_

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.

- M6 × 35 mm (1.38 in) bolts "1"
- M6 × 50 mm (1.97 in) bolts "2"
- M8 × 110 mm (4.33 in) bolts "3"



#### 2. Remove:

Left crankcase

### ECA13900

Tap on one side of the crankcase with a soft-face hammer. Tap only on reinforced portions of the crankcase, not on the crankcase mating surfaces. Work slowly and carefully and make sure the crankcase halves separate evenly.

#### EAS25580

#### **CHECKING THE CRANKCASE**

- 1. Thoroughly wash the crankcase halves in a mild solvent.
- 2. Thoroughly clean all the gasket surfaces and crankcase mating surfaces.
- 3. Check:
  - Crankcase
    - Cracks/damage  $\rightarrow$  Replace.
  - Oil delivery passages
     Obstruction → Blow out with compressed air.

#### EAS4B51032

#### CHECKING THE TIMING CHAIN

- 1. Check:
  - Timing chain Damage/stiffness → Replace the timing chain, camshafts and crankshaft assembly as a set.

#### EAS25700 ASSEMBLING THE CRANKCASE

- 1. Install:
  - Cylinder stud bolts "1"

#### TIP\_

For the cylinder stud bolt, embedded height "a" is the standard value and the tightening torque is the reference value.





- a. 150.2-152.2 mm (5.91-5.99 in)
- 2. Thoroughly clean all the gasket mating surfaces and crankcase mating surfaces.
- 3. Apply:
  - Sealant
    - (onto the crankcase mating surfaces)
- Å

Yamaha bond No.1215 90890-85505 (Three bond No.1215®)

#### TIP.

Do not allow any sealant to come into contact with the oil gallery.



- 4. Install:
  - Dowel pins
    - Left crankcase



- 5. Install:
  - Crankcase bolts (M8)
  - Crankcase bolts (M6)



24 Nm (2.4 m·kgf, 17 ft·lbf) Crankcase bolt (M6) 10 Nm (1.0 m·kgf, 7.2 ft·lbf)

#### TIP\_

Tighten each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern.

- M8 × 110 mm (4.33 in) bolts "1"
- M6 × 50 mm (1.97 in) bolts "2"
- M6 × 35 mm (1.38 in) bolts "3"



- 6. Check:
  - Crankshaft and transmission operation Rough movement  $\rightarrow$  Repair.

#### EAS25960 CRANKSHAFT



### CRANKSHAFT



#### EAS26010 REMOVING THE CONNECTING RODS

The following procedure applies to all of the connecting rods.

- 1. Remove:
  - Connecting rod cap "1"
  - Connecting rod "2"
  - Big end bearings

#### TIP

Identify the position of each big end bearing so that it can be reinstalled in its original place.



#### EAS26050

# REMOVING THE CRANKSHAFT JOURNAL BEARINGS

The following procedure applies to both of the crankshaft journal bearings.

- 1. Remove:
  - Crankshaft assembly
  - Crankshaft journal bearing "1"

#### TIP\_

Remove the crankshaft journal bearing using the plane bearing installer "2".

P

#### Plane bearing installer 90890-04139





TIP.

Identify the position of each crankshaft journal bearing so that it can be reinstalled in its original place.

#### EAS26090 CHECKING THE CRANKSHAFT AND CON-NECTING RODS

- 1. Measure:
  - Crankshaft runout Out of specification → Replace the crankshaft.





- 2. Check:
  - Crankshaft journal surfaces
  - Crankshaft pin surfaces
  - Bearing surfaces

Scratches/wear  $\rightarrow$  Replace the crank-shaft.

- 3. Measure:
  - Crankshaft-pin-to-big-end-bearing clearance

Out of specification  $\rightarrow$  Replace the big end bearings.

~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	Oil	cleara	ance	(using
	plast	igauge®)		
Connecting rod				
	0.	040-0.064	mm	(0.0016–
	0.	0025 in)		
Balancer connecting rod				
	0.	036-0.060	mm	(0.0014–
	0.	0024 in)		-

The following procedure applies to all of the connecting rods and balancer connecting rod.

NOTICE

Do not interchange the big end bearings and connecting rods. To obtain the correct crankshaft-pin-to-big-end-bearing clearance and prevent engine damage, the big end bearings must be installed in their original positions.

\*\*\*\*

- a. Clean the big end bearings, crankshaft pins, and the inside of the connecting rod halves.
- b. Install the big end upper bearing into the connecting rod and the big end lower bearing into the connecting rod cap.

#### TIP.

Align the projections "a" on the big end bearings with the notches "b" in the connecting rod and connecting rod cap.



c. Put a piece of Plastigauge® "1" on the crankshaft pin.



d. Assemble the connecting rod halves.

#### TIP\_

- Do not move the connecting rod or crankshaft until the clearance measurement has been completed.
- Lubricate the bolts threads and nut seats with molybdenum disulfide grease.
- Make sure the "Y" mark "c" on the connecting rod faces towards the left side of the crank-shaft.
- Make sure the characters "d" on both the connecting rod and connecting rod cap are aligned.



- e. Tighten the connecting rod nuts. Refer to "INSTALLING THE CONNECTING RODS" on page 5-80.
- Remove the connecting rod and big end bearings.
   Refer to "REMOVING THE CONNECTING RODS" on page 5-76.
- g. Measure the compressed Plastigauge® width "e" on the crankshaft pin.
   If the crankshaft-pin-to-big-end-bearing clearance is out of specification, select replacement big end bearings.



- \*\*\*\*\*
- 4. Select:
  - Big end bearings (P<sub>1</sub>-P<sub>3</sub>)

TIP\_

- The numbers "A" stamped into the crankshaft web and the numbers "B" on the connecting rods are used to determine the replacement big end bearing sizes.
- P<sub>1</sub>-P<sub>3</sub> refer to the bearings shown in the crankshaft illustration.



Α



В



For example, if the connecting rod  $P_1$  and the crankshaft web  $P_1$  numbers are 5 and 1 respectively, then the bearing size for  $P_1$  is:

P<sub>1</sub> (connecting rod) - P<sub>1</sub> (crankshaft)

5 - 1 = 4 (green)



5. Measure:

• Crankshaft-journal-to-crankshaft-journal bearing clearance.

Out of specification  $\rightarrow$  Replace the crankshaft journal bearings.

(0.0016-



The following procedure applies to all of the crankshaft journal bearings.

#### ECA13920 **NOTICE**

Do not interchange the crankshaft journal bearings. To obtain the correct crankshaftjournal-to-crankshaft-journal-bearing clearance and prevent engine damage, the crankshaft journal bearings must be installed in their original positions.

# ECA4B51026

NOTICE

On the journal, the larger value is used as a basis for calculation of the oil clearance, and on the journal bearing, the smaller value is used.

- a. Clean the crankshaft journal bearings, crankshaft journals, and bearing portions of the crankcase.
- b. Check the bearing surface. If the bearing surface is worn or scratched, both bearings should be replaced.

TIP\_

If either of the right or left journal bearing is worn or scratched, both bearings should be replaced as a set.

c. Measure the crankshaft journal diameter "a" of each crankshaft journal at two places. If it is out of specification, replace the crankshaft.





d. Measure the crankshaft journal bearing inside diameter "b" of each crankshaft journal bearing at two places.



e. If crankshaft journal bearing inside diameter is "55.03" and crankshaft journal diameter is "54.98", then the journal oil clearance is:

Journal oil clearance:

Crankshaft journal bearing inside diameter -Crankshaft journal diameter = 55.03 - 54.98 = 0.05 mm

If the oil clearance is out of specification, select replacement bearings.

\*\*\*\*

- 6. Select:
  - Crankshaft journal bearings (J<sub>1</sub>–J<sub>2</sub>)

TIP\_

• The numbers "A" stamped into the crankshaft web and the numbers "B" on the crankcase are used to determine the replacement crankshaft journal bearing size. • J<sub>1</sub>–J<sub>2</sub> refer to the bearings shown in the crankshaft illustration.



Α





For example, if the crankcase  $J_1$  and the crankshaft web  $J_1$  numbers are 4 and 2 respectively, then the bearing size for  $J_1$  is:

J <sub>1</sub> (crankcase) - J <sub>1</sub> (crankshaft web) =	
4 - 2 = 2 (black)	

### CRANKSHAFT

Ľ	Bearing co 1.Blue 4.Green	olor code 2.Black	3.Brown	
	Bearing th	ickness		
	Blue:	2.495-2.50	)8 mm	
	(0.0982-0	0.0987 in)		
	Black:	2.491-2.5	04 mm	
	(0.0981–	0.0986 in)		
	Brown:	2.487-2.5	00 mm	
(0.0979–0.0984 in)				
	Green:	2.483-2.4	96 mm	
	(0.0978–	0.0983 in)		

#### EAS25630

#### INSTALLING THE CRANKSHAFT JOUR-NAL BEARINGS

The following procedure applies to both of the crankshaft journal bearings.

- 1. Attach:
  - Crankshaft journal bearing "1"

TIP\_

Attach the crankshaft journal bearing to the plane bearing installer "2".



- 2. Install:
  - Crankshaft journal bearing

TIP.

- Align the projection "a" on the bearing with the projection "b" on the crankcase.
- Place an iron plate "3" beneath the crankcase and press fit until the end of the plain bearing installer touches the iron plate.



#### EAS26150

#### INSTALLING THE CONNECTING RODS

- 1. Lubricate:
  - Bolt threads New
  - Nut seats <u>New</u> (with the recommended lubricant)



#### Recommended lubricant Molybdenum disulfide oil

- 2. Lubricate:
  - · Crankshaft pins
  - Big end bearings inner surface
  - Balancer big end bearings inner surface (with the recommended lubricant)



- 3. Install:
  - Big end bearings
  - Connecting rods
  - Connecting rod caps (onto the crankshaft pins)

#### TIP.

- Align the projections "a" on the big end bearings with the notches "b" in the connecting rods and connecting rod caps.
- Be sure to reinstall each big end bearing in its original place.
- Make sure the "Y" marks "c" on the connecting rods face towards the left side of the crankshaft.

90.

• Make sure the characters "d" on both the connecting rod and connecting rod cap are aligned.





#### 4. Tighten:

- Connecting rod nuts
- EWA59C1502

#### **WARNING**

Replace the connecting rod bolts and nuts with new ones.

#### TIP.

Tighten the connecting rod nuts using the following procedure.

a. Tighten the connecting rod nuts with a torque wrench.



#### Connecting rod nut (1st) 16 Nm (1.6 m·kgf, 12 ft·lbf)

b. Put a mark "1" on the corner of the connecting rod nut "2" and the connecting rod cap "3".



c. Tighten the connecting rod nuts further to reach the specified angle 90°.



# EWA13400

If the connecting rod nut is tightened more than the specified angle, do not loosen the nut and then retighten it. Instead, replace the connecting rod bolt and nut with a new one and perform the procedure again.

### ECA4B51019

- NOTICE
- Do not use a torque wrench to tighten the connecting rod nut to the specified angle.
- Tighten the nut until it is at the specified angle.

#### TIP\_

On a hexagonal nut, note that the angle from one corner to another is  $60^{\circ}$ .

#### \*\*\*\*\*

#### 5. Install:

- Balancer big end bearings
- Balancer connecting rod
- Balancer connecting rod cap (onto the crankshaft pin)

#### TIP.

- Align the projections "a" on the balancer big end bearings with the notches "b" in the balancer connecting rod and balancer connecting rod cap.
- Be sure to reinstall each balancer big end bearing in its original place.
- Make sure the "Y" marks "c" on the balancer connecting rod face towards the left side of the crankshaft.

• Make sure the characters "d" on both the balancer connecting rod and balancer connecting rod cap are aligned.





- 6. Tighten:
  - Balancer connecting rod nuts



ECA4B51020 **NOTICE** 

• When tightening the nuts, be sure to use a beam type torgue wrench.

Balancer connecting rod nut 60 Nm (6.0 m·kgf, 43 ft·lbf)

 Tighten the nuts to the specified torque. Apply continuous torque between 30 Nm (3.0 m·kgf, 22 ft·lbf) and 60 Nm (6.0 m·kgf, 43 ft·lbf) without pausing. After reaching 30 Nm (3.0 m·kgf, 22 ft·lbf), DO NOT STOP TIGHTENING until the specified torque is achieved. If the tightening is interrupted between 30 Nm (3.0 m·kgf, 22 ft·lbf) and 60 Nm (6.0 m·kgf, 43 ft·lbf), loosen the nut to less than 30 Nm (3.0 m·kgf, 22 ft·lbf) and start again.

EAS4B51033

INSTALLING THE CRANKSHAFT ASSEM-BLY

- 1. Install:
  - Crankshaft assembly "1"
  - Balancer cylinder "2"



Balancer cylinder bolt 58 Nm (5.8 m·kgf, 42 ft·lbf) LOCTITE®

## ECA4B51023

To avoid scratching the crankshaft and to ease the installation procedure, apply grease onto the oil seal lips and apply engine oil onto each bearing.



#### EAS26241 TRANSMISSION



#### EAS31560 CHECKING THE TRANSMISSION

- 1. Check:
  - Transmission gears Blue discoloration/pitting/wear → Replace.



- 2. Check:
  - Transmission gear movement Rough movement → Replace the defective part(s).
- 3. Check:
  - Main axle Cracks/damage/wear → Replace the main axle.
- 4. Measure:
  - Drive axle runout (with a centering device and dial gauge) Out of specification → Replace the drive
    - axle. Drive axle runout limit





- 5. Measure:
  - Secondary shaft runout (with a centering device and dial gauge) Out of specification → Replace the secondary shaft.





## **COOLING SYSTEM**

RADIATOR	6-1
CHECKING THE RADIATOR	6-3
INSTALLING THE RADIATOR	6-3
OIL COOLER	6-5
CHECKING THE OIL COOLER	6-6
INSTALLING THE OIL COOLER	6-6
THERMOSTAT	6-7
CHECKING THE THERMOSTAT	6-8
INSTALLING THE THERMOSTAT ASSEMBLY	6-8
WATER PUMP	6-9
DISASSEMBLING THE WATER PUMP	6-11
CHECKING THE WATER PUMP	6-11
ASSEMBLING THE WATER PUMP	6-11
INSTALLING THE WATER PUMP	6-12

#### EAS26380 RADIATOR



### RADIATOR



#### EAS26390 CHECKING THE RADIATOR

- 1. Check:
  - Radiator fins Obstruction  $\rightarrow$  Clean. Apply compressed air to the rear of the radiator. Damage  $\rightarrow$  Repair or replace.

#### TIP\_

Straighten any flattened fins with a thin, flathead screwdriver.



#### 2. Check:

- Radiator hoses
- Radiator pipes
  - Cracks/damage  $\rightarrow$  Replace.
- 3. Measure:
  - Radiator cap opening pressure Below the specified pressure  $\rightarrow$  Replace the radiator cap.



Radiator cap opening pressure 107.9-137.3 kPa (1.08-1.37 kgf/cm<sup>2</sup>, 15.7–19.9 psi)

a. Install the radiator cap tester "1" and radiator cap tester adapter "2" to the radiator cap "3".





b. Apply the specified pressure for ten seconds and make sure there is no drop in pressure.

#### 

- 4. Check:
  - Radiator fan Damage  $\rightarrow$  Replace. Malfunction  $\rightarrow$  Check and repair. Refer to "COOLING SYSTEM" on page 8-25.

#### FAS26400

#### **INSTALLING THE RADIATOR**

- 1. Fill:
  - Cooling system (with the specified amount of the recommended coolant) Refer to "CHANGING THE COOLANT" on page 3-30.
- 2. Check:
  - Cooling system Leaks  $\rightarrow$  Repair or replace any faulty part.

#### \*\*\*\*

a. Attach the radiator cap tester "1" and radiator cap tester adapter "2" to the radiator.

# Radiator cap tester kit

### 90890-01325 Mityvac cooling system tester

YU-24460-A Radiator cap tester adapter 90890-01352

Pressure tester adapter YU-33984

### RADIATOR



- Apply 137.3 kPa (1.37 kgf/cm<sup>2</sup>, 19.9 psi) of pressure.
- c. Measure the indicated pressure with the gauge.

\*\*\*\*

#### EAS26410 OIL COOLER



#### EAS26420 CHECKING THE OIL COOLER

- 1. Check:
  - Oil cooler
    - $\label{eq:cracks} \mathsf{Cracks}/\mathsf{damage} \to \mathsf{Replace}.$
- 2. Check:
  - Oil cooler inlet hose
  - Oil cooler outlet hose
    - Cracks/damage/wear  $\rightarrow$  Replace.

#### EAS26430

#### INSTALLING THE OIL COOLER

- 1. Clean:
  - Mating surfaces of the oil cooler and the crankcase

(with a cloth dampened with lacquer thinner)

- 2. Install:
  - O-ring New
  - Oil cooler "1"
  - Oil filter cartridge union bolt "2"



Oil filter cartridge union bolt 63 Nm (6.3 m·kgf, 46 ft·lbf)

#### TIP.

- Make sure that the O-ring is positioned properly.
- Align the projection "a" on the oil cooler with the slot "b" in the crankcase.



- 3. Install:
  - Oil filter cartridge



Oil filter wrench 90890-01469 YM-01469

Oil filter cartridge 17 Nm (1.7 m·kgf, 12 ft·lbf)

Refer to "CHANGING THE ENGINE OIL" on page 3-26.

- 4. Fill:
  - Cooling system (with the specified amount of the recommended coolant)

Refer to "CHANGING THE COOLANT" on page 3-30.

 Crankcase (with the specified amount of the recommended engine oil)
 Refer to "CHANGING THE ENGINE OIL"

on page 3-26.

- 5. Check:
  - Cooling system Leaks → Repair or replace any faulty part. Refer to "INSTALLING THE RADIATOR"

on page 6-3.

- 6. Measure:
  - Radiator cap opening pressure Below the specified pressure → Replace the radiator cap.

Refer to "CHECKING THE RADIATOR" on page 6-3.

#### EAS26440 THERMOSTAT



Order	Job/Parts to remove	Q'ty	Remarks
	Storage box		Refer to "GENERAL CHASSIS" on page 4-1.
	Fuel tank		Refer to "FUEL TANK" on page 7-1.
	Coolant		Drain. Refer to "CHANGING THE COOLANT" on page 3-30.
1	Coolant temperature sensor coupler	1	Disconnect.
2	Coolant temperature sensor	1	
3	Copper washer	1	
4	Cooling system air bleed hose	1	Disconnect.
5	Thermostat outlet hose	1	Disconnect.
6	Thermostat cover	1	
7	Thermostat	1	
8	Fast idle plunger inlet coolant hose	1	Disconnect.
9	Coolant hose	1	Disconnect.
			For installation, reverse the removal proce- dure.

#### EAS26450 CHECKING THE THERMOSTAT

- 1. Check:
  - Thermostat
    - Does not open at 71–85 °C (159.8–185.0 °F)  $\rightarrow$  Replace.



#### \*\*\*\*

- a. Suspend the thermostat "1" in a container "2" filled with water.
- b. Slowly heat the water "3".
- c. Place a thermometer "4" in the water.
- d. While stirring the water, observe the thermostat and thermometer's indicated temperature.





- A. Fully closed
- B. Fully open

#### TIP\_

If the accuracy of the thermostat is in doubt, replace it. A faulty thermostat could cause serious overheating or overcooling.

#### \*\*\*\*

- 2. Check:
  - Thermostat cover
    - Cracks/damage  $\rightarrow$  Replace.

#### EAS26480 INSTALLING THE THERMOSTAT ASSEM-BLY

- 1. Install:
  - Thermostat

#### TIP\_

Install the thermostat with its breather hole "a" facing forward.



- 2. Fill:
  - Cooling system (with the specified amount of the recommended coolant) Refer to "CHANGING THE COOLANT" on page 3-30.
- 3. Check:

Cooling system
 Leaks → Repair or replace any faulty
 part.

Refer to "INSTALLING THE RADIATOR" on page 6-3.

- 4. Measure:
  - Radiator cap opening pressure Below the specified pressure → Replace the radiator cap. Refer to "CHECKING THE RADIATOR" on page 6-3.

# EAS26500



\* Water or silicone fluid



#### EAS26510 DISASSEMBLING THE WATER PUMP

- 1. Remove:
  - Rubber damper holder "1"
  - Rubber damper "2" (from the impeller, with a thin, flathead screwdriver)

#### TIP\_

Do not scratch the impeller shaft.



#### 2. Remove:

• Water pump seal "1"

#### TIP\_

Remove the water pump seal from the inside of the water pump housing.



- 3. Remove:
  - Bearing "1"
  - Oil seal "2"

#### TIP\_

Remove the bearing and oil seal from the outside of the water pump housing.



#### EAS26541 CHECKING THE WATER PUMP

- 1. Check:
  - Water pump housing cover "1"
  - Water pump housing "2"
  - Impeller shaft "3" Cracks/damage/wear  $\rightarrow$  Replace.



- 2. Check:
  - Water pump inlet pipe
  - Water pump outlet pipe Cracks/damage/wear → Replace.

#### EAS26560

#### ASSEMBLING THE WATER PUMP

- 1. Install:
  - Oil seal "1" New
  - Bearing "2" New (into the water pump housing)

#### TIP\_

- Before installing the oil seal, apply tap water or coolant onto its outer surface.
- Install the oil seal with a socket that matches its outside diameter.
- Install the oil seal from the inside of the water pump housing.





- 2. Install:
  - Water pump seal "1" New

#### ECA14080

#### NOTICE

Never lubricate the water pump seal surface with oil or grease.

#### TIP\_

- Install the water pump seal with the special tools.
- Before installing the water pump seal, apply Yamaha bond No.1215 "2" to the water pump housing "3".



Mechanical seal installer 90890-04132 Water pump seal installer YM-33221-A Middle driven shaft bearing driver 90890-04058 Middle drive bearing installer 40 & 50 mm YM-04058 Yamaha bond No.1215 90890-85505 (Three bond No.1215®)



- A. Push down
- 4. Mechanical seal installer
- 5. Middle driven shaft bearing driver
- 3. Install:
  - Rubber damper holder "1" New
  - Rubber damper "2" New

#### TIP\_

Before installing the rubber damper, apply tap water or coolant onto its outer surface.



- 4. Measure:
  - Impeller shaft tilt Out of specification → Repeat step (3) and (4).

ECA14090

#### NOTICE

Make sure the rubber damper and rubber damper holder are flush with the impeller.



- 1. Straightedge
- 2. Impeller shaft

EAS26590

#### INSTALLING THE WATER PUMP

- 1. Install:
  - O-ring New
  - · Water pump assembly

#### TIP\_

- Align the slit "a" on the impeller shaft with the projection "b" on the oil pump shaft.
- Lubricate the O-ring with a thin coat of lithium-soap-based grease.



Water pump assembly bolt 10 Nm (1.0 m·kgf, 7.2 ft·lbf)



- 2. Fill:
  - Cooling system (with the specified amount of the recommended coolant) Refer to "CHANGING THE COOLANT" on page 3-30.
- 3. Check:
  - Cooling system Leaks → Repair or replace any faulty part. Refer to "INSTALLING THE RADIATOR" on page 6-3.
- 4. Measure:
  - Radiator cap opening pressure Below the specified pressure → Replace the radiator cap. Refer to "CHECKING THE RADIATOR" on page 6-3.
## FUEL SYSTEM

FUEL TANK	7-1
REMOVING THE FUEL HOSE	7-2
REMOVING THE FUEL TANK	7-2
REMOVING THE FUEL PUMP	7-2
CHECKING THE FUEL PUMP BODY	7-2
CHECKING THE FUEL PUMP OPERATION	7-2
CHECKING THE ROLLOVER VALVE	7-2
INSTALLING THE FUEL PUMP	7-3
INSTALLING THE FUEL TANK	7-3
INSTALLING THE FUEL HOSE	7-3
CHECKING THE FUEL PRESSURE	7-3
	•

THROTTLE BODY	7-5
REMOVING THE FUEL HOSE (INJECTOR SIDE)	7-8
CHECKING THE INJECTORS	7-8
CHECKING THE THROTTLE BODY	7-8
INSTALLING THE INJECTORS	7-8
INSTALLING THE FUEL HOSE (INJECTOR SIDE)	7-9
ADJUSTING THE THROTTLE POSITION SENSOR	7-9

# FUEL TANK

Removing	the fuel tank		
Implementation     Implementation       Implementation     Implementatio			
Order	Job/Parts to remove	Q'tv	Bemarks
	Storage box		Refer to "GENERAL CHASSIS" on page 4-1.
1	Fuel pump coupler	1	Disconnect.
2	Fuel hose connector cover	1	
3	Fuel hose	1	Disconnect.
4	Fuel tank overflow hose	1	
5	Fuel tank breather hose	2	
6	Rollover valve	1	
7	Fuel tank	1	
8	Fuel tank cap	1	
9	Filler cover	1	
10	Fuel pump bracket	1	
11	Fuel pump	1	
12	Fuel pump gasket	1	
12			For installation, reverse the removal proce-
			dure.

#### EAS59C1701 REMOVING THE FUEL HOSE

- 1. Remove:
  - Fuel hose connector cover "1"
- 2. Disconnect:
  - Fuel hose "2"

EWA15910

## **WARNING**

Cover fuel hose connections with a cloth when disconnecting them. Residual pressure in the fuel lines could cause fuel to spurt out when removing the hose.

### ECA59C1701

### NOTICE

- Be sure to disconnect the fuel hose by hand. Do not forcefully disconnect the hose with tools.
- Although the fuel has been removed from the fuel tank, be careful when removing the fuel hose, since there may be fuel remaining in it.
- Do not disconnect the fuel hose from the fuel hose connector. Disconnect the connector from the fuel pump.

## TIP\_

Before removing the hose, place a few rags in the area under where it will be removed.





### EAS26631

## **REMOVING THE FUEL TANK**

1. Extract the fuel in the fuel tank through the fuel tank cap with a pump.

- 2. Remove:
  - Fuel tank overflow hose
  - Fuel tank breather hoses
  - Rollover valve
- 3. Disconnect:
  - Fuel pump coupler
- 4. Remove:
  - Fuel tank

## EAS26640

## REMOVING THE FUEL PUMP

- 1. Remove:
  - Fuel pump bracket
  - Fuel pump
  - Fuel pump gasket

## ECA14720

## NOTICE

- Do not drop the fuel pump or give it a strong shock.
- Do not touch the base section of the fuel sender.

## EAS26670

## CHECKING THE FUEL PUMP BODY

- 1. Check:
  - Fuel pump body Obstruction → Clean. Cracks/damage → Replace the fuel pump assembly.

#### EAS26690 CHECKING THE FUEL PUMP OPERATION

- 1. Check:
  - Fuel pump operation Refer to "CHECKING THE FUEL PRES-SURE" on page 7-3.

## EAS59C1702

## CHECKING THE ROLLOVER VALVE

- 1. Check:
  - Rollover valve "1" Damage/faulty → Replace.

### TIP\_

- Check that air flows smoothly only in the direction of the arrow shown in the illustration.
- The rollover valve must be in an upright position when checking the airflow.



## EAS59C1703 INSTALLING THE FUEL PUMP

- 1. Install:
  - Fuel pump gasket New
  - Fuel pump
  - Fuel pump bracket



TIP

# 3.8 Nm (0.38 m·kgf, 2.8 ft·lbf)

- · Do not damage the installation surfaces of the fuel tank when installing the fuel pump.
- Always use a new fuel pump gasket.

Fuel pump bolt

- Install the fuel pump as shown in the illustration.
- Align projection "a" on the fuel pump with point "b" of the fuel tank.
- Tighten the fuel pump bolts in the proper tightening sequence as shown.



A. Forward

## EAS59C1708

## **INSTALLING THE FUEL TANK**

- 1. Install:
  - Fuel tank



Fuel tank nut 9 Nm (0.9 m·kgf, 6.5 ft·lbf) Fuel tank bolt

9 Nm (0.9 m·kgf, 6.5 ft·lbf)

- 2. Connect:
  - Fuel pump coupler
- 3. Install:
  - Fuel tank overflow hose
  - Fuel tank breather hoses
  - Rollover valve

#### EAS59C1704 **INSTALLING THE FUEL HOSE**

- 1. Connect:
  - Fuel hose
- 2. Install:
  - Fuel hose connector cover

#### ECA59C1702 NOTICE

## When installing the fuel hose, make sure that it is securely connected, and that the fuel hose connector cover is in the correct position, otherwise the fuel hose will not be properly installed.

## TIP

- Wipe up any fuel remaining in the recess "a" in the fuel pump with a dry rag "1".
- After installing the fuel hose connector cover, make sure that it is installed securely.



## EAS31950

## CHECKING THE FUEL PRESSURE

- 1. Check:
- Fuel pressure
- a. Remove the fuel hose connector cover "1" and disconnect the fuel hose "2" from the fuel pump.

### EWA15910

Cover fuel hose connections with a cloth when disconnecting them. Residual pressure in the fuel lines could cause fuel to spurt out when removing the hose.

7-3

## ECA59C17001

## NOTICE

- Be sure to disconnect the fuel hose by hand. Do not forcefully disconnect the hose with tools.
- Although the fuel has been removed from the fuel tank, be careful when removing the fuel hose, since there may be fuel remaining in it.
- Do not disconnect the fuel hose from the fuel hose connector. Disconnect the connector from the fuel pump.

### TIP\_

Before removing the hose, place a few rags in the area under where it will be removed.



b. Connect the pressure gauge "1" and fuel pressure adapter "2" to the fuel pump and the fuel hose "3".





- c. Start the engine.
- d. Measure the fuel pressure. Faulty  $\rightarrow$  Replace the fuel pump.



## Fuel line pressure (at idle) 220–300 kPa (2.20–3.00 kgf/ cm<sup>2</sup>, 31.3–42.7 psi)

- e. Set the main switch to "OFF".
- f. Remove the pressure gauge and fuel pressure adapter.

TIP\_

Before removing the special tools, place a few rags in the area under where they will be removed.

\*\*\*\*\*

### EAS26970 THROTTLE BODY



## THROTTLE BODY





#### EAS59C1705 REMOVING THE FUEL HOSE (INJECTOR SIDE)

- 1. Disconnect:
- Fuel hose (injector side)

## A WARNING

Cover fuel hose connections with a cloth when disconnecting them. Residual pressure in the fuel lines could cause fuel to spurt out when removing the hose.

### ECA17490 **NOTICE**

Be sure to disconnect the fuel hose by hand. Do not forcefully disconnect the hose with tools.

TIP\_

- To remove the fuel hose from the fuel rail, slide the fuel hose connector cover "1" on the end of the hose in the direction of the arrow shown, press the two buttons "2" on the sides of the connector, and then remove the hose.
- Before removing the hose, place a few rags in the area under where it will be removed.



- EAS26981 CHECKING THE INJECTORS
- 1. Check:
  - Injectors
     Obstruction → Replace and check the fuel pump/fuel supply system.

     Deposit → Replace.
     Damage → Replace.
- 2. Check:
  - Injector resistance Refer to "CHECKING THE FUEL INJEC-TORS" on page 8-141.

## EAS26990

## CHECKING THE THROTTLE BODY

- 1. Check:
  - Throttle body
    - Cracks/damage  $\rightarrow$  Replace.

- 2. Check:
- Fuel passages Obstructions → Clean.

## NOTICE

Do not adjust the stop screw "1".



## \*\*\*\*

- a. Wash the throttle body in a petroleumbased solvent.
  Do not use any caustic carburetor cleaning solution.
- b. Blow out all of the passages with compressed air.

\*\*\*\*

#### EAS31930 INSTALLING THE INJECTORS ECA59C1704 NOTICE

- Always use new gaskets, seals, and Orings.
- When installing the injectors, do not allow any foreign material to enter or adhere to the injectors, fuel rail, seals or O-rings.
- Be careful not to twist or pinch the Orings when installing the injectors.
- When installing the injector, install it at the same position as the removed cylinder.
- If an injector is subject to strong shocks or excessive force, replace it.
- If installing the original fuel rail and bolts, remove the white paint marks using a cleaning solvent. Otherwise, paint chips on the bolt seats could prevent the bolts from being tightened to the specified torque.
- 1. Install a new O-ring onto the end of each injector.
- 2. Install the injectors "1" to the fuel rail "2", making sure to install them in the correct direction.

3. Install a new seal onto the end of each injector.



4. Install the injector assembly to the intake manifold with the screws and new gaskets.



## Fuel rail screw 3.5 Nm (0.35 m·kgf, 2.5 ft·lbf)

5. Check the fuel pressure. Refer to "CHECKING THE FUEL PRES-SURE" on page 7-3.

### EAS59C1707

### **INSTALLING THE FUEL HOSE (INJECTOR** SIDE)

- 1. Connect:
  - Fuel hose (injector side)

### ECA59C1706

## NOTICE

When installing the fuel hose, make sure that it is securely connected, and that the fuel hose connector cover on the fuel hose is in the correct position, otherwise the fuel hose will not be properly installed.

### TIP.

- Install the fuel hose securely onto the fuel rail until a distinct "click" is heard.
- To install the fuel hose onto the fuel rail, slide the fuel hose connector cover "1" on the end of the hose in the direction of the arrow shown.
- It is prohibited to wear the cotton work gloves or equivalent coverings.



### EAS59C1706 ADJUSTING THE THROTTLE POSITION SENSOR

#### EWA59C1701

- Handle the throttle position sensor with special care.
- Never subject the throttle position sensor to strong shocks. If the throttle position sensor is dropped, replace it.

## TIP\_

Before adjusting the throttle position sensor, the engine idling speed should be properly adjusted.

- 1. Check:
  - Throttle position sensor **Refer to "CHECKING THE THROTTLE** POSITION SENSOR" on page 8-139.
- 2. Adjust:
  - Throttle position sensor angle

## \*\*\*\*\*

- a. Temporary tighten the throttle position sensor.
- b. Check that the throttle grip is fully closed.
- c. Connect the throttle position sensor to the wire harness.
- d. Set the main switch to "OFF" and set the engine stop switch to " $\bigcirc$ ".
- e. Simultaneously press and hold the left set and right set buttons "1", set the main switch to "ON", and continue to press the buttons for 8 seconds more.

## TIP

## "dIAG" appears on the odometer LCD.



- Diagnostic code number "d:01" is selected. f.
- g. Adjust the position of the throttle position sensor angle so that 14–20 can appear in the meter.
- h. After adjusting the throttle position sensor angle, tighten the throttle position sensor screws "2".



\*\*\*\*

## **ELECTRICAL SYSTEM**

IGNITION SYSTEM	8-1
CIRCUIT DIAGRAM	8-1
TROUBLESHOOTING	8-3
ELECTRIC STARTING SYSTEM	8-5
CIRCUIT DIAGRAM	8-5
STARTING CIRCUIT CUT-OFF SYSTEM OPERATION	
TROUBLESHOOTING	8-9
	0 1 1
	0 11-0
	۱۱-0 ۱۵ ۵
TROUBLESHOUTING	8-13
LIGHTING SYSTEM	8-15
CIRCUIT DIAGRAM	8-15
TROUBLESHOOTING	8-17
SIGNALING SYSTEM	8-10
	9-10. 8_10
	19-0
modelshooting	0-21
COOLING SYSTEM	8-25
CIRCUIT DIAGRAM	8-25
TROUBLESHOOTING	8-27
FUEL INJECTION SYSTEM	8-29
	8-29
FCU SELE-DIAGNOSTIC FUNCTION	8-31
	8-33
	8-34
	8-35
TBOUBLESHOOTING DETAILS	
DIAGNOSTIC CODE TABLE	8-68
FUEL PUMP SYSTEM	8-71
	8-71
TROUBLESHOOTING	8-73
IMMOBILIZER SYSTEM	8-75
CIRCUIT DIAGRAM	8-75
GENERAL INFORMATION	8-77
PART REPLACEMENT AND KEY CODE REGISTRATION	
	8-78
I ROUBLESHOOTING	8-81
SELF-DIAGNOSIS FAULT CODE INDICATION	8-82

ABS (ANTI-LOCK BRAKE SYSTEM)	8-85
CIRCUIT DIAGRAM	8-85
ABS COMPONENTS CHART	8-87
ABS COUPLER LOCATION CHART	8-89
MAINTENANCE OF THE ABS ECU	8-91
ABS TROUBLESHOOTING OUTLINE	8-91
BASIC INSTRUCTIONS FOR TROUBLESHOOTING	8-92
BASIC PROCESS FOR TROUBLESHOOTING	8-93
[A] CHECKING THE ABS WARNING LIGHT	8-94
[A-1] ONLY THE ABS WARNING LIGHT FAILS TO COME ON	8-94
[A-2] THE ABS WARNING LIGHT AND ALL OTHER	
	8-94
	8-95
[A-4] THE ABS WARNING LIGHT COMES ON	8-95
[B-1] THE MULTI-FUNCTION DISPLAY DUES NOT DISPLAY	0.00
	8-90
	0-90 0.07
	0-97 8_115
	0-115 8_115
	8-117
ELECTRICAL COMPONENTS	8-119
CHECKING THE SWITCHES	8-123
CHECKING THE BULBS AND BULB SOCKETS	8-126
CHECKING THE FUSES	8-127
CHECKING AND CHARGING THE BATTERY	8-127
CHECKING THE RELAYS	8-131
CHECKING THE TURN SIGNAL/HAZARD RELAY	8-132
CHECKING THE DIODE	8-133
CHECKING THE SPARK PLUG CAPS	8-134
CHECKING THE IGNITION COIL	8-134
CHECKING THE IGNITION SPARK GAP	8-135
CHECKING THE CRANKSHAFT POSITION SENSOR	8-135
	8-135
	8-136
	8-136
	8-137
	8-13/
	0 100
	8-138
	8-130
CHECKING THE THBOTTI E POSITION SENSOR	0 100
	8-139
CHECKING THE INTAKE AIR PRESSURE SENSOR	8-139
CHECKING THE INTAKE AIR PRESSURE SENSOR CHECKING THE INTAKE AIR TEMPERATURE SENSOR	8-139 8-140 8-140

## EAS27090

#### EAS27110 CIRCUIT DIAGRAM



- 1. Crankshaft position sensor
- 4. Frame ground
- 5. Joint
- 6. Main switch
- 8. Joint coupler
- 16.Ignition fuse
- 19.Battery
- 20.Negative lead
- 21.Main fuse
- 26.Right handlebar switch
- 27.Engine stop switch
- 38.Sidestand switch
- 39.ECU (engine control unit)
- 40.Ignition coil
- 41.Spark plug
- 49.Lean angle sensor

EAS27140 TROUBLESHOOTIN	NG	

The ignition system fails to operate (no spark or intermittent spark).

TIP\_

- Before troubleshooting, remove the following part(s):
- 1. Footboards
- 2. Front cowling assembly

1. Check the fuses. (Main and ignition) Refer to "CHECKING THE FUSES" on page 8-127.	NG→	Replace the fuse(s).
OK↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-127.	NG→	<ul> <li>Clean the battery terminals.</li> <li>Recharge or replace the battery.</li> </ul>
OK↓		
3. Check the spark plugs. Refer to "CHECKING THE SPARK PLUGS" on page 3-4.	NG→	Re-gap or replace the spark plugs.
OK↓		
4. Check the ignition spark gap. Refer to "CHECKING THE IGNI- TION SPARK GAP" on page 8-135.	OK→	Ignition system is OK.
NG↓		
5. Check the spark plug caps. Refer to "CHECKING THE SPARK PLUG CAPS" on page 8-134.	NG→	Replace the spark plug caps.
OK↓		
6. Check the ignition coil. Refer to "CHECKING THE IGNI- TION COIL" on page 8-134.	NG→	Replace the ignition coil.
OK↓		
<ol> <li>Check the crankshaft position sensor.</li> <li>Refer to "CHECKING THE CRANKSHAFT POSITION SEN- SOR" on page 8-135.</li> </ol>	NG→	Replace the crankshaft position sen- sor/stator assembly.

OK↓

## **IGNITION SYSTEM**

8. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the main switch/immobilizer unit.
OK↓	-	
9. Check the engine stop switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	The engine stop switch is faulty. Replace the right handlebar switch.
ОК↓	-	
10.Check the sidestand switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the sidestand switch.
OK↓	-	
11.Check the lean angle sensor. Refer to "CHECKING THE LEAN ANGLE SENSOR" on page 8-135.	NG→	Replace the lean angle sensor.
OK↓	1	
12.Check the entire ignition system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-1.	NG→	Properly connect or repair the ignition system's wiring.
OK↓	-	
Replace the ECU (engine control unit).		

## ELECTRIC STARTING SYSTEM

#### EAS27170 CIRCUIT DIAGRAM



- 4. Frame ground
- 5. Joint
- 6. Main switch
- 8. Joint coupler
- 14.Signaling system fuse
- 16.Ignition fuse
- 19.Battery
- 20.Negative lead
- 21.Main fuse
- 22.Starter relay
- 23.Starter motor
- 24.Starting circuit cut-off relay 2
- 25.Diode 1
- 26.Right handlebar switch
- 27.Engine stop switch
- 28.Start switch
- 30. Front brake light switch
- 33.Diode 2
- 34. Starting circuit cut-off relay 1
- 38.Sidestand switch
- 67.Left handlebar switch
- 72.Rear brake light switch

## EAS27180

## STARTING CIRCUIT CUT-OFF SYSTEM OPERATION

If the engine stop switch is set to " $\bigcirc$ " and the main switch is set to " $\bigcirc$ " (both switches are closed), the starter motor can only operate if at least one of the following conditions is met:

- The front brake lever is pulled to the handlebar (the front brake light switch is closed) and the sidestand is up (the sidestand switch is closed).
- The rear brake lever is pulled to the handlebar (the rear brake light switch is closed) and the sidestand is up (the sidestand switch is closed).

The starting circuit cut-off relays 1 and 2 prevents the starter motor from operating when neither of these conditions has been met. In this instance, the starting circuit cut-off relays 1 and 2 are open so current cannot reach the starter motor. When at least one of the above conditions has been met, the starting circuit cut-off relays 1 and 2 are closed and the engine can be started by pressing the start switch "(s)".



- 1. Battery
- 2. Main fuse
- 3. Main switch
- 4. Signaling system fuse
- 5. Ignition fuse
- 6. Engine stop switch
- 7. Diode 2
- 8. Starting circuit cut-off relay 1
- 9. Front brake light switch
- 10.Rear brake light switch
- 11.Sidestand switch
- 12.Starting circuit cut-off relay 2
- 13.Start switch
- 14.Diode 1
- 15.Starter relay
- 16.Starter motor

EAS27190 <b>TROUBLESHOOTING</b> The starter motor fails to turn.		
TIP		
<ul> <li>Before troubleshooting, remove the follo</li> <li>1. Front cowling assembly</li> <li>2. Storage box</li> <li>3. Fuel tank</li> </ul>	owing part(s):	
<ol> <li>Check the fuses. (Main, ignition and signaling system) Refer to "CHECKING THE FUSES" on page 8-127.</li> </ol>	NG→	Replace the fuse(s).
ОК↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-127.	NG→	<ul><li>Clean the battery terminals.</li><li>Recharge or replace the battery.</li></ul>
OK↓		
3. Check the starter motor operation. Refer to "CHECKING THE STARTER MOTOR OPERATION" on page 8-136.	ОК→	Starter motor is OK. Perform the elec- tric starting system troubleshooting, starting with step 5.
NG↓		
4. Check the starter motor. Refer to "CHECKING THE STARTER MOTOR" on page 5-37.	NG→	Repair or replace the starter motor.
ОК↓		
5. Check the diode 2. Refer to "CHECKING THE DIODE" on page 8-133.	NG→	Replace the diode 2.
OK↓		
<ol> <li>Check the starting circuit cut-off relay 1.</li> <li>Refer to "CHECKING THE RELAYS" on page 8-131.</li> </ol>	NG→	Replace the starting circuit cut-off relay 1.
OK↓		
<ul> <li>7. Check the starting circuit cut-off relay 2.</li> <li>Refer to "CHECKING THE RELAYS" on page 8-131.</li> </ul>	NG→	Replace the starting circuit cut-off relay 2.

OK↓

## **ELECTRIC STARTING SYSTEM**

	_	
8. Check the starter relay. Refer to "CHECKING THE RELAYS" on page 8-131.	NG→	Replace the starter relay.
OK↓	-	
9. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the main switch/immobilizer unit.
OK↓	-	
10.Check the engine stop switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	The engine stop switch is faulty. Replace the right handlebar switch.
OK↓	-	
11.Check the sidestand switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the sidestand switch.
OK↓	-	
12.Check the front brake light switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the front brake light switch.
OK↓	-	
13.Check the rear brake light switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the rear brake light switch.
OK↓	-	
14.Check the start switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	The start switch is faulty. Replace the right handlebar switch.
OK↓	-	
15.Check the entire starting system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-5.	NG→	Properly connect or repair the starting system's wiring.
OK↓	-	
The starting system circuit is OK.	]	

## CHARGING SYSTEM

#### EAS27210 CIRCUIT DIAGRAM



- 2. AC magneto
- 3. Rectifier/regulator
- Frame ground
   Joint
- 19.Battery
- 20.Negative lead
- 21.Main fuse

EAS27220 TROUBLESHOOTING The battery is not being charged.		
<ul> <li>Before troubleshooting, remove the follo</li> <li>1. Front cowling assembly</li> <li>2. Storage box</li> </ul>	owing part(s):	
1. Check the fuse. (Main) Refer to "CHECKING THE FUSES" on page 8-127.	NG→	Replace the fuse.
OK↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-127.	NG→	<ul><li>Clean the battery terminals.</li><li>Recharge or replace the battery.</li></ul>
OK↓	-	
3. Check the stator coil. Refer to "CHECKING THE STATOR COIL" on page 8-136.	NG→	Replace the crankshaft position sen- sor/stator assembly.
OK↓		
4. Check the rectifier/regulator. Refer to "CHECKING THE RECTI- FIER/REGULATOR" on page 8- 137.	NG→	Replace the rectifier/regulator.
ОК↓		
5. Check the entire charging system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-11.	NG→	Properly connect or repair the charg- ing system's wiring.
OK↓	<u>.</u>	
This circuit is OK.		

## LIGHTING SYSTEM

#### EAS27250 CIRCUIT DIAGRAM



- 4. Frame ground
- 5. Joint
- 6. Main switch
- 8. Joint coupler
- 9. Storage box light switch
- 10.Storage box light
- 13.Backup fuse
- 15.Headlight fuse
- 16.Ignition fuse
- 18.Parking lighting fuse
- 19.Battery
- 20.Negative lead
- 21.Main fuse
- 39.ECU (engine control unit)
- 63.License plate light
- 64.Tail/brake light
- 67.Left handlebar switch
- 68.Pass switch
- 69.Dimmer switch
- 76. Auxiliary light
- 77.Headlight relay
- 78.Headlight (low beam)
- 79.Headlight (high beam)
- 82.Meter assembly
- 86.High beam indicator light
- 91.Meter light
- 92.Multi-function meter

B. Wire harness

C. Headlight sub-wire harness

#### EAS27260 TROUBLESHOOTING

Any of the following fail to light: headlight, auxiliary light, high beam indicator light, taillight, license plate light, meter light or storage box light.

TIP\_

- Before troubleshooting, remove the following part(s):
- 1. Front cowling assembly
- 2. Mudguard

<ol> <li>Check the each bulbs and bulb sockets condition.</li> <li>Refer to "CHECKING THE BULBS AND BULB SOCKETS" on page 8- 126.</li> </ol>	NG→	Replace the bulb(s) and bulb socket(s).
ОК↓		
2. Check the fuses. (Main, headlight, ignition, parking lighting and backup) Refer to "CHECKING THE FUSES" on page 8-127.	NG→	Replace the fuse(s).
ОК↓		
<ol> <li>Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-127.</li> </ol>	NG→	<ul> <li>Clean the battery terminals.</li> <li>Recharge or replace the battery.</li> </ul>
ОК↓		
4. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the main switch/immobilizer unit.
OK↓		
5. Check the dimmer switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	The dimmer switch is faulty. Replace the left handlebar switch.
OK↓		
6. Check the pass switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	The pass switch is faulty. Replace the left handlebar switch.
ОК↓		
7. Check the headlight relay. Refer to "CHECKING THE RELAYS" on page 8-131.	NG→	Replace the headlight relay.

OK↓

## LIGHTING SYSTEM

8. Check the storage box light switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the storage box light switch.
OK↓		
<ol> <li>Check the entire lighting system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-15.</li> </ol>	NG→	Properly connect or repair the lighting system's wiring.
ОК↓		
Replace the ECU (engine control unit) or meter assembly.		

### EAS27270 SIGNALING SYSTEM

#### EAS27280 CIRCUIT DIAGRAM



4. Frame ground

5. Joint

- 6. Main switch
- 8. Joint coupler
- 13.Backup fuse
- 14. Signaling system fuse
- 16.Ignition fuse
- 18. Parking lighting fuse
- 19.Battery
- 20.Negative lead
- 21.Main fuse
- 26.Right handlebar switch
- 29.Hazard switch
- 30. Front brake light switch
- 37.Fuel sender
- 39.ECU (engine control unit)
- 50.Diagnostic tool coupler
- 51. Wheel sensor shield ground
- 52.ABS ECU (electronic control unit)
- 53. Front wheel sensor
- 62.Turn signal/hazard relay
- 64.Tail/brake light
- 65.Rear right turn signal light
- 66.Rear left turn signal light
- 67.Left handlebar switch
- 70.Horn switch
- 71.Turn signal switch
- 72.Rear brake light switch
- 73.Horn
- 74. Front right turn signal light
- 75. Front left turn signal light
- 81.ABS ECU fuse
- 82.Meter assembly
- 84.Left turn signal indicator light
- 85.Right turn signal indicator light
- 87.Speedometer
- 88.Tachometer
- 92.Multi-function meter
- 93.Ambient temperature sensor

B. Wire harness

C. Headlight sub-wire harness

EAS27290 TROUBLESHOOTING • Any of the following fail to light: turn signal light, brake light or an indicator light. • The horn fails to sound. • The fuel meter fails to operate. • The speedometer fails to operate. TIP\_ • Before troubleshooting, remove the following part(s): 1. Front cowling assembly 2. Storage box 1. Check the fuses.  $NG \rightarrow$ (Main, ignition, signaling system, ABS ECU, parking lighting and Replace the fuse(s). backup) Refer to "CHECKING THE FUSES" on page 8-127. OK↓ 2. Check the battery. NG→ Refer to "CHECKING AND Clean the battery terminals. CHARGING THE BATTERY" on Recharge or replace the battery. page 8-127. OK↑ 3. Check the main switch. NG→ Replace the main switch/immobilizer **Refer to "CHECKING THE** unit. SWITCHES" on page 8-123. OK↓ 4. Check the entire signaling system's  $NG \rightarrow$ Properly connect or repair the signalwirina. Refer to "CIRCUIT DIAGRAM" on ing system's wiring. page 8-19. OK↓ This circuit is OK. Checking the signaling system The horn fails to sound. 1. Check the horn switch. NG→ The horn switch is faulty. Replace the Refer to "CHECKING THE left handlebar switch. SWITCHES" on page 8-123. OK↓ 2. Check the horn.  $NG \rightarrow$ Refer to "CHECKING THE HORN" Replace the horn. on page 8-137.

OK↓
## SIGNALING SYSTEM

[	1	
<ol> <li>Check the entire signaling system's wiring.</li> <li>Refer to "CIRCUIT DIAGRAM" on page 8-19.</li> </ol>	NG→	Properly connect or repair the signal- ing system's wiring.
OK↓	J	
This circuit is OK.		
The tail/brake light fails to come on.	-	
1. Check the front brake light switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the front brake light switch.
OK↓	1	
2. Check the rear brake light switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the rear brake light switch.
OK↓	-	
3. Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-19.	NG→	Properly connect or repair the signal- ing system's wiring.
OK↓	J	
This circuit is OK.		
The turn signal light, turn signal indicator	r light or both fail t	o blink.
<ol> <li>Check the turn signal light bulb and socket.</li> <li>Refer to "CHECKING THE BULBS AND BULB SOCKETS" on page 8- 126.</li> </ol>	NG→	Replace the turn signal light bulb, socket or both.
OK↓	1	
2. Check the turn signal switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	The turn signal switch is faulty. Replace the left handlebar switch.
OK↓	_	
3. Check the hazard switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	The hazard switch is faulty. Replace the right handlebar switch.
OK↓	-	
4. Check the turn signal/hazard relay. Refer to "CHECKING THE RELAYS" on page 8-131.	NG→	Replace the turn signal/hazard relay.
OK↓		

## SIGNALING SYSTEM

<ol> <li>Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-19.</li> </ol>	NG→	Properly connect or repair the signal- ing system's wiring.
OK↓	1	
Replace the meter assembly.		
The fuel meter fails to operate.		
1. Check the fuel sender. Refer to "CHECKING THE FUEL SENDER" on page 8-138.	NG→	Replace the fuel pump assembly.
OK↓		
2. Check the entire signaling system's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-19.	NG→	Properly connect or repair the signal- ing system's wiring.
OK↓		
Replace the meter assembly.		
The speedometer/V-belt replacement ind	licator/oil change i	indicator fails to operate.
1. Check the front wheel sensor. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-21.	NG→	Replace the front wheel sensor.
OK↓	1	
2. Check the entire wheel sensor wir- ing. Refer to TIP.	NG→	Properly connect or repair the wheel sensor wiring.
OK↓		
Replace the hydraulic unit assembly, ECU (engine control unit) or meter assembly.		
TIP	<b>.</b>	
<ul> <li>Repair or replace if there is an open or sl</li> <li>Between front wheel sensor coupler an (White–White) (Black–Black)</li> <li>Between ABS ECU coupler and ECU (a) (White–White)</li> </ul>	hort circuit. d ABS ECU coup engine control uni	ler. t) coupler.

 Between ECU coupler and meter assembly coupler. (Yellow/blue–Yellow/blue)

# COOLING SYSTEM

#### EAS27310 CIRCUIT DIAGRAM



- 4. Frame ground
- 5. Joint
- 6. Main switch
- 8. Joint coupler
- 13.Backup fuse
- 16.Ignition fuse
- 17.Radiator fan fuse
- 19.Battery
- 20.Negative lead
- 21.Main fuse
- 39.ECU (engine control unit)
- 44.Coolant temperature sensor
- 50.Diagnostic tool coupler
- 60.Radiator fan motor relay
- 61.Radiator fan motor
- 82.Meter assembly
- 92.Multi-function meter

<ul> <li>• Before troubleshooting, remove the following part(s):</li> <li>1. Front cowling assembly</li> <li>2. Storage box</li> <li>3. Fuel tank</li> </ul>					
<ol> <li>Check the fuses. (Main, ignition, radiator fan and backup) Refer to "CHECKING THE FUSES" on page 8-127.</li> </ol>	NG→	Replace the fuse(s).			
OK↓					
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-127.	NG→	<ul><li>Clean the battery terminals.</li><li>Recharge or replace the battery.</li></ul>			
OK↓					
3. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the main switch/immobilizer unit.			
OK↓					
4. Check the radiator fan motor. Refer to "CHECKING THE RADIA- TOR FAN MOTOR" on page 8-138.	NG→	Replace the radiator fan motor.			
OK↓					
5. Check the radiator fan motor relay. Refer to "CHECKING THE RELAYS" on page 8-131.	NG→	Replace the radiator fan motor relay.			
OK↓					
<ol> <li>Check the coolant temperature sensor.</li> <li>Refer to "CHECKING THE COOL- ANT TEMPERATURE SENSOR" on page 8-139.</li> </ol>	NG→	Replace the coolant temperature sen- sor.			

OK↓

### **COOLING SYSTEM**

Check the entire cooling system's wiring.
 Refer to "CIRCUIT DIAGRAM" on page 8-25.

OK↓

Replace the ECU (engine control unit) or meter assembly.

 $\rm NG \rightarrow$ 

Properly connect or repair the cooling system's wiring.

## FUEL INJECTION SYSTEM

#### EAS27340 CIRCUIT DIAGRAM



- 1. Crankshaft position sensor 4. Frame ground 5. Joint 6. Main switch 8. Joint coupler 12. Fuel injection system fuse 13.Backup fuse 14. Signaling system fuse 15.Headlight fuse 16.Ignition fuse 19.Battery 20.Negative lead 21.Main fuse 26.Right handlebar switch 27. Engine stop switch 33.Diode 2 34.Starting circuit cut-off relay 1 35. Fuel injection system relay 38.Sidestand switch 39.ECU (engine control unit) 40.Ignition coil 41.Spark plug 42.Fuel injector #1 43. Fuel injector #2 44.Coolant temperature sensor 45.Intake air temperature sensor 46.Intake air pressure sensor 47.O<sub>2</sub> sensor 48.Throttle position sensor 49.Lean angle sensor 50.Diagnostic tool coupler 51.Wheel sensor shield ground 52.ABS ECU (electronic control unit) 53.Front wheel sensor 56.Grip warmer relay 60.Radiator fan motor relay 77.Headlight relay 81.ABS ECU fuse 82.Meter assembly 89.Engine trouble warning light
- 92.Multi-function meter
- A. OPTION
- B. Wire harness
- D. Throttle position sensor sub-wire harness
- E. Grip warmer sub-wire harness

#### EAS27351

#### ECU SELF-DIAGNOSTIC FUNCTION

The ECU is equipped with a self-diagnostic function in order to ensure that the fuel injection system is operating normally. If this function detects a malfunction in the system, it immediately operates the engine under substitute characteristics and illuminates the engine trouble warning light to alert the rider that a malfunction has occurred in the system. Once a malfunction has been detected, a fault code number is stored in the memory of the ECU.

- To inform the rider that the fuel injection system is not functioning, the engine trouble warning light flashes while the start switch is being pushed to start the engine.
- If a malfunction is detected in the system by the self-diagnostic function, the ECU provides an appropriate substitute characteristic operation, and alerts the rider of the detected malfunction by illuminating the engine trouble warning light.
- After the engine has been stopped, the lowest fault code number appears on the odometer LCD. This number remains stored in the memory of the ECU until it is deleted.

#### Engine trouble warning light indication and fuel injection system operation

Warning light indica- tion	ECU operation	Fuel injection opera- tion	Vehicle operation
Flashing*	Warning provided when unable to start engine	Operation stopped	Cannot be operated
Remains on	Malfunction detected	Operated with substi- tute characteristics in accordance with the description of the mal- function	Can or cannot be oper- ated depending on the fault code

\* The warning light flashes when any one of the following conditions is present and the start switch is pushed:

- 12:Crankshaft position sensor41:Lean angle sensor<br/>(open or short circuit)19:Sidestand switch<br/>(open circuit in the wire to the ECU)50:ECU internal malfunction<br/>(faulty ECU memory)
- 30: Lean angle sensor (latch up detected)

#### Checking the engine trouble warning light

The engine trouble warning light comes on for 1.4 seconds after the main switch has been set to "ON" and it comes on while the start switch is being pushed. If the warning light does not come on under these conditions, the warning light (LED) may be defective.



- a. Main switch "OFF"
- b. Main switch "ON"
- c. Engine trouble warning light off
- d. Engine trouble warning light on for 1.4 seconds

#### ECU detects an abnormal signal from a sensor

If the ECU detects an abnormal signal from a sensor while the vehicle is being driven, the ECU illuminates the engine trouble warning light and provides the engine with alternate operating instructions that are appropriate for the type of malfunction.

When an abnormal signal is received from a sensor, the ECU processes the specified values that are programmed for each sensor in order to provide the engine with alternate operating instructions that enable the engine to continue operating or stop operating, depending on the conditions.

#### EAS27402 TROUBLESHOOTING METHOD

# The engine operation is not normal and the engine trouble warning light comes on.

- 1. Check:
  - Fault code number

#### \*\*\*\*

- a. Check the fault code number displayed on the meter.
- b. Identify the faulty system with the fault code number.
- c. Identify the probable cause of the malfunction.

#### \*\*\*\*\*

2. Check and repair the probable cause of the malfunction.

Fault code No.	No fault code No.
Check and repair.	Check and repair.
Refer to "TROUBLE-	
SHOOTING	
DETAILS" on page 8-	
37.	
Monitor the operation	
of the sensors and	
actuators in the diag-	
nostic mode. Refer to	
"TROUBLESHOOT-	
ING DETAILS" on	
page 8-37.	

- Perform the reinstatement action for the fuel injection system.
   Refer to "Reinstatement method" in the appropriate table in "TROUBLESHOOTING DETAILS" on page 8-37.
- Set the main switch to "OFF", then to "ON" again, and then check that no fault code number is displayed.

#### TIP\_

If another fault code number is displayed, repeat steps (1) to (4) until no fault code number is displayed.

5. Erase the malfunction history in the diagnostic mode. Refer to "TROUBLESHOOT-ING DETAILS" on page 8-37.

#### TIP\_

Setting the main switch to "OFF" will not erase the malfunction history.

# The engine operation is not normal, but the engine trouble warning light does not come on.

 Check the operation of the following sensors and actuators in the diagnostic mode. Refer to "TROUBLESHOOTING DETAILS" on page 8-37.

d:01: Throttle position sensor (throttle angle)
d:03: Intake air pressure sensor
d:05: Intake air temperature sensor
d:06: Coolant temperature sensor
d:07: Front wheel sensor
d:08: Lean angle sensor
d:30: Ignition coil
d:36: Injector #1
d:37: Injector #2

If a malfunction is detected in the sensors or actuators, repair or replace all faulty parts.

If no malfunction is detected in the sensors and actuators, check and repair the inner parts of the engine.

#### EAS27431 DIAGNOSTIC MODE

Setting the diagnostic mode

- 1. Set the main switch to "OFF" and set the engine stop switch to " $\bigcirc$ ".
- 2. Disconnect the wire harness coupler from the fuel pump.
- 3. Simultaneously press and hold the left set button "1" and right set button "2", set the main switch to "ON", and continue to press the buttons for 8 seconds or more.



#### TIP.

- All displays on the meter disappear except the odometer displays.
- "dIAG" appears on the odometer LCD.
- 4. Press the left set button to select the CO adjustment mode "Co" or the diagnostic monitoring mode "dIAG".
- 5. After selecting "dIAG", simultaneously press the left set and right set buttons for 2 seconds or more to execute the selection.
- 6. Set the engine stop switch to " $\boxtimes$ ".
- 7. Select the diagnostic code number that applies to the item that was verified with the fault code number by pressing the left set and right set buttons.

#### TIP\_

The diagnostic code number appears on the clock LCD (d:01–d:70).

- To decrease the selected diagnostic code number, press the right set button. Press the right set button for 1 second or longer to automatically decrease the diagnostic code numbers.
- To increase the selected diagnostic code number, press the left set button. Press the left set button for 1 second or longer to automatically increase the diagnostic code numbers.



- 8. Verify the operation of the sensor or actuator.
  - Sensor operation
    - The data representing the operating conditions of the sensor appears on the odometer LCD.
  - Actuator operation
  - Set the engine stop switch to " $\bigcirc$ " to operate the actuator.

#### TIP\_

If the engine stop switch is set to " $\bigcirc$ ", set it to " $\bigotimes$ ", and then set it to " $\bigcirc$ " again.

9. Set the main switch to "OFF" to cancel the diagnostic mode.

#### EAS59C1803 YAMAHA DIAGNOSTIC TOOL

This model uses the Yamaha diagnostic tool to identify malfunctions.

For information about using the Yamaha diagnostic tool, refer to the operation manual that is included with the tool.

A
---

Yamaha diagnostic tool 90890-03215

Features of the Yamaha diagnostic tool

You can use the Yamaha diagnostic tool to identify malfunctions quicker than with conventional methods.

By connecting the adapter interface, which is connected to the USB port of a computer, to a vehicle's ECU using the communication cable, you can display information that is necessary for identifying malfunctions and for maintenance to display on the computer. The displayed information includes the sensor output data and information recorded in the ECU.

Functions of the Yamaha diagnostic tool

Fault diagnosis mode:	Error codes recorded on the ECU are read, and the con- tents are displayed.
Function diagnostic mode:	Check the operation of the output value of each sensor and actuator.
Inspection mode:	Determine whether each sensor or actuator is functioning properly.
CO adjustment mode:	Adjust the concentration of CO admissions during idling.
Monitoring mode:	Displays a graph of sensor output values for actual operat- ing conditions.
Logging mode:	Records and saves the sensor output value in actual driv- ing conditions.
View log:	Displays the logging data.
ECU rewrite:	If necessary, the ECU is rewritten using ECU rewrite data provided by Yamaha. Ignition timing adjustment, etc. cannot be changed from the vehicle's original state.

However, the diagnostic tool cannot be used to freely change the basic vehicle functions, such as adjusting the ignition timing.

Connecting the Yamaha diagnostic tool

Disconnect the coupler (Yellow/blue, Red/green, Black/white) "1", and then connect the Yamaha diagnostic tool to the coupler.



#### TIP\_

When the Yamaha diagnostic tool is connected to the vehicle, the operation of the multi-function meter and indicators will be different from the normal operation.

#### EAS27462

#### TROUBLESHOOTING DETAILS

This section describes the measures per fault code number displayed on the meter. Check and service the items or components that are the probable cause of the malfunction following the order given.

After the check and service of the malfunctioning part have been completed, reset the meter display according to the reinstatement method.

Fault code No.:

Fault code number displayed on the meter when the engine failed to work normally.

Diagnostic code No.:

Diagnostic code number to be used when the diagnostic mode is operated. Refer to "DIAGNOSTIC MODE" on page 8-34.

Fault	code No.	12			
ltem	em Crankshaft position sensor: no normal signals are received from crankshaft position sensor.			ignals are received from the	
Fail safe system Unable to		Unable to s	tart engine		
T all 3	ale system	Unable to d	Irive vehicle		
Diagn	ostic code No.	—			
Meter	display	—			
Proce	edure	<u> </u>	1		
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure	
1	Connection of crankshaft position sensor coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending,		Poor connection → Connect it securely, or repair/replace the wire harness.	Crank the engine, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
2	2 Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Crank the engine, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
3	Continuity of wire harness		Open or short circuit → Replace the wire harness. Black/yellow–Black/yellow Black/blue–Black/blue	Crank the engine, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
4	Sensor installation - Check the mountion for loose of mounting.	on status nting sec- r pinched	Incorrect installation $\rightarrow$ Reinstall or repair the sensor.	Crank the engine, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	

Fault	code No.	12	12		
Item		Crankshaft position sensor: no normal signals are received from the crankshaft position sensor.			
Eail-e	afa svetom	Unable to s	tart engine		
r all-50	ale system	Unable to d	Irive vehicle		
Diagn	ostic code No.	—			
Meter	display	—			
Procedure		—			
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure	
5	Crankshaft positi malfunction	on sensor	Sensor inspection procedure Refer to "CHECKING THE CRANKSHAFT POSITION SENSOR" on page 8-135. Replace if defective.	Crank the engine, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
6	ECU malfunction		Replace the ECU.		

Fault	code No.	13			
ltem		Intake air pressure sensor: open or short circuit detected. (no nor- mal signals are received from the intake air pressure sensor.)			
Fail-s	afa system	Able to star	rt engine		
i all-3	ale system	Able to driv	ve vehicle		
Diagn	ostic code No.	d:03			
Meter	display	Displays th	e intake air pressure.		
Proce	Procedure Set the engine stop switch to " $\bigcirc$ ", and then operate the throttle while pushing the start switch " $\circledast$ ". (If the display value change the performance is OK.)			then operate the throttle ne display value changes,	
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure	
1 Connection of intake air pres- sure sensor coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking)		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
2 Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		

Fault	code No.	13			
Item	iem Intake air pressure sensor: open or short circuit detected. (no n mal signals are received from the intake air pressure sensor.)			rt circuit detected. (no nor- a air pressure sensor.)	
Fail a	ofo ovotom	Able to star	rt engine		
raii-sa	ale system	Able to driv	ve vehicle		
Diagn	ostic code No.	d:03			
Meter	<sup>-</sup> display	Displays th	e intake air pressure.		
Proce	Procedure Set the engine stop switch to " $\bigcirc$ ", and then operate the thrott while pushing the start switch " $\textcircled{s}$ ". (If the display value chang the performance is OK.)			then operate the throttle ne display value changes,	
Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure		
3	Continuity of wire	e harness	Open or short circuit → Replace the wire harness. Black/blue–Black/blue Pink/white–Pink/white Blue–Blue	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
4	4 Sensor installation status Check the mounting section for loose or pinched mount- ing.		Incorrect installation $\rightarrow$ Reinstallation $\rightarrow$ Reinstall or repair the sensor.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	

Fault code No.	ult code No. 13			
Item	Intake air p mal signals	te air pressure sensor: open or short circuit detected. (no nor- signals are received from the intake air pressure sensor.)		
Fail aafa ayatam	Able to star	rt engine		
Fail-sale system	Able to driv	ve vehicle		
Diagnostic code No.	d:03			
Meter display	<b>Displays</b> th	e intake air pressure.		
Procedure	Set the eng while pushi the perform	ine stop switch to " $\bigcirc$ ", and t ing the start switch " $\circledast$ ". (If the nance is OK.)	then operate the throttle ne display value changes,	
Item/compon probable o	ents and cause	Check or maintenance job	Sensor inspection proce- dure	
<ul> <li>5 Intake air pressur malfunction</li> <li>6 ECU malfunction</li> </ul>	'e sensor	Check in the diagnostic mode (Code No. d:03). When engine is stopped: Atmospheric pressure at the current altitude and weather conditions is indicated. 0 m (0 ft) above sea level: Approx. 101 kPa (757.6 mmHg, 29.8 inHg) 1000 m (3300 ft) above sea level: Approx. 90 kPa (675.1 mmHg, 26.6 inHg) 2000 m (6700 ft) above sea level: Approx. 80 kPa (600.0 mmHg, 23.6 inHg) 3000 m (9800 ft) above sea level: Approx. 70 kPa (525.0 mmHg, 20.7 inHg) When engine is cranking: Make sure that the indication value changes. Incorrect indication $\rightarrow$ Sensor malfunction $\rightarrow$ Replace the intake air pressure sensor. Sensor inspection procedure Refer to "CHECKING THE INTAKE AIR PRESSURE SENSOR" on page 8-140. Replace the ECU.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. → Recovered. Fault code indicated. → Check the next step.	

If fault codes 13 and 14 are indicated simultaneously, take the actions specified for fault code 13 first.

Fault	code No.	14			
Intake air p Item detached h plied to the			ressure sensor: hose system ose). Intake system malfunct intake air pressure sensor ir	n malfunction (clogged or ion (the pressure is not sup- n a stable condition).	
Fail-s	afe system	Able to star	rt engine		
r an o	ale oyotom	Able to driv	ve vehicle		
Diagn	ostic code No.	d:03			
Meter	display	Displays th	e intake air pressure.		
Procedure t		Set the engine stop switch to " $\bigcirc$ ", and then operate the throttle while pushing the start switch " $\circledast$ ". (If the display value changes, the performance is OK.)			
	Item/compor probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure	
1	The intake air pressure sen- sor hose is damaged, discon- nected, clogged, twisted or bent.		Repair or replace the sensor hose.	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	

Fault	code No.	14				
ltem		Intake air p detached h plied to the	Intake air pressure sensor: hose system malfunction (clogged or detached hose). Intake system malfunction (the pressure is not supplied to the intake air pressure sensor in a stable condition).			
Fail-safe system		Able to sta	rt engine			
		Able to driv	ve vehicle			
Diagn	ostic code No.	d:03				
Meter	display	Displays th	e intake air pressure.			
Proce	dure	Set the engine stop switch to " $\bigcirc$ ", and then operate the throttle while pushing the start switch " $\circledast$ ". (If the display value changes, the performance is OK.)				
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
2	Intake air pressu malfunction	re sensor	Check in the diagnostic mode (Code No. d:03). When engine is stopped: Atmospheric pressure at the current altitude and weather conditions is indicated. 0 m (0 ft) above sea level: Approx. 101 kPa (757.6 mmHg, 29.8 inHg) 1000 m (3300 ft) above sea level: Approx. 90 kPa (675.1 mmHg, 26.6 inHg) 2000 m (6700 ft) above sea level: Approx. 80 kPa (600.0 mmHg, 23.6 inHg) 3000 m (9800 ft) above sea level: Approx. 70 kPa (525.0 mmHg, 20.7 inHg) When engine is cranking: Make sure that the indication value changes. The value does not change when engine is cranking. → Replace the intake air pres- sure sensor. Sensor inspection procedure Refer to "CHECKING THE INTAKE AIR PRESSURE SENSOR" on page 8-140.			

If fault codes 13 and 14 are indicated simultaneously, take the actions specified for fault code 13 first.

Fault code No.		15				
Item		Throttle position sensor: open or short circuit detected. (no normal signals are received from the throttle position sensor.)				
Fail-safe system		Under certa	Under certain conditions			
r un 3	ale system	Under certa	ain conditions			
Diagn	nostic code No.	d:01				
Meter	<sup>-</sup> display	Throttle po • 14–20 (ful • 97–107 (fu	Throttle position sensor • 14–20 (fully closed position) • 97–107 (fully open position)			
Proce	edure	<ul> <li>Check with</li> <li>Check with</li> </ul>	th throttle valves fully closed. th throttle valves fully open.			
	Item/compor probable	nents and cause	Check or maintenance job	Sensor inspection proce- dure		
1	Connection of th tion sensor coup Check the connect coupler is secure Disconnect the connect the conne	rottle posi- ler ection of the e. oupler, and for bending,	Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	Connection of throttle posi- tion sensor sub-wire harness coupler Check the connection of the coupler is secure. Disconnect the coupler and check each pin (for bending, wear or locking)		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
4	Continuity of wire harness		Open or short circuit → Replace the wire harness. Black/blue–Black/blue Yellow–Yellow Blue–Blue	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
5	Sensor installation	on status	Check for loose mounting, pinched mounting, or hard mounting. Make sure that the mounting position is correct. Refer to "ADJUSTING THE THROTTLE POSITION SEN- SOR" on page 7-9.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		

Fault	code No.	15				
Item		Throttle posignals are	le position sensor: open or short circuit detected. (no normal s are received from the throttle position sensor.)			
Fail-sa	afe system	Under certa	ain conditions			
		Under certa	ain conditions			
Diagn	ostic code No.	d:01				
Meter	display	<ul> <li>Throttle positive</li> <li>14–20 (full</li> <li>97–107 (full</li> </ul>	sition sensor Ily closed posit ully open posit	tion) ion)		
Proce	dure	Check wit     Check wit	<ul> <li>Check with throttle valves fully closed.</li> <li>Check with throttle valves fully open.</li> </ul>			
	Item/compon probable	ents and cause	Check or ma	intenance job	Sensor inspection proce- dure	
6	Supply voltage of throttle position sensor lead		Check the sup Black/blue-Yel Refer to "CHE0 THROTTLE P0 SOR" on page	ply voltage. low CKING THE OSITION SEN- 8-139.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered.	
			Line discon- nection points Disconnec- tion of ground lead	Output volt- age 5 V	Fault code indicated. → Check the next step.	
			Disconnec- tion of output line Disconnec- tion of power supply line	0 V 0 V		
7	Throttle position sensor mal- function ECU malfunction		Check in the di (Code No. d:0 <sup>-1</sup> When throttle i A value of 14– When throttle i value of 97–10 If the indication range $\rightarrow$ Repla position senso	agnostic mode 1). is fully closed: 20 is indicated. 20 is indicated. is fully open: A 07 is indicated. In is outside of ace the throttle r.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
8	ECU malfunction		Replace the E	CU.		

If fault codes 15 and 16 are indicated simultaneously, take the actions specified for fault code 15 first.

Fault code No.		16				
ltem		Throttle pos (signal fron	Throttle position sensor: stuck throttle position sensor detected. (signal from throttle position sensor will not change.)			
Fail-e	afe system	Able to star	rt engine			
1 all-5	ale system	Able to driv	ve vehicle			
Diagn	nostic code No.	d:01				
Meter	<sup>-</sup> display	Throttle position sensor • 14–20 (fully closed position) • 97–107 (fully open position)				
Proce	edure	<ul> <li>Check wit</li> <li>Check wit</li> </ul>	h throttle valves fully closed. h throttle valves fully open.			
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure		
1	Sensor installation status		Check for loose mounting, pinched mounting, or hard mounting. Make sure that the mounting position is correct. Refer to "ADJUSTING THE THROTTLE POSITION SEN- SOR" on page 7-9.	Place the main switch to the ON position, and then open and close the throttle. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
2	Throttle position sensor mal- function		Check in the diagnostic mode (Code No. d:01). When throttle is fully closed: A value of 14–20 is indicated. When throttle is fully open: A value of 97–107 is indicated. If the indication is outside of range $\rightarrow$ Replace the throttle position sensor.	Place the main switch to the ON position, and then open and close the throttle. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	ECU malfunction		Replace the ECU.			

• If fault codes 15 and 16 are indicated simultaneously, take the actions specified for fault code 15 first.

• If fault codes 16 and 37 are indicated simultaneously, take the actions specified for fault code 16 first.

Fault code No.		19	19			
Item		Sidestand switch: a break or disconnection of the light green lead of the ECU is detected. (no normal signals are received from the side-stand switch.)				
	of a sustain	Unable to s	tart engine			
Fall-sa	ate system	Unable to d	rive vehicle			
Diagn	ostic code No.	d:20				
Meter	display	Sidestand s ON (sides OFF (side	Sidestand switch <ul> <li>ON (sidestand retracted)</li> <li>OFE (sidestand extended)</li> </ul>			
Proce	dure	Extend and	retract the sidestand.			
	Item/compor probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
1	Connection of sid switch coupler Check the connect coupler is secure Disconnect the c check each pin ( wear, or locking)	destand ection of the e. oupler, and for bending,	Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication when the sidestand is retracted and extended. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication when the sidestand is retracted and extended. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	Continuity of wire harness		Open or short circuit → Replace the wire harness. Light green–Light green Black–Black	Place the main switch to the ON position, and check the fault code indication when the sidestand is retracted and extended. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
4	Sidestand switch	malfunction	Check in the diagnostic mode (Code No. d:20). Sidestand retracted: ON indi- cation Sidestand extended: OFF indication Indication is incorrect. $\rightarrow$ Replace the sidestand switch.	Place the main switch to the ON position, and check the fault code indication when the sidestand is retracted and extended. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
5	ECU malfunctior	1	Replace the ECU.			

Fault code No.		21				
Item		Coolant temperature sensor: open or short circuit detected. (no nor- mal signals are received from the coolant temperature sensor.)				
Fail-safe system		Able to start engine				
		Able to driv	ve vehicle			
Diagn	ostic code No.	d:06				
Meter	display	Displays th	e coolant temperature.			
Proce	dure	Compare tr display valu	Compare the actually measured coolant temperature with the meter display value.			
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
1	Connection of coolant tem- perature sensor coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending,		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear or locking)		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	Continuity of wire harness		Open or short circuit → Replace the wire harness Black/blue–Black/blue Green/red–Green/red	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
4	Installation status of coolant temperature sensor Check the mounting section for a loose or pinched mount- ing.		Make sure that the mounting position is correct.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
5	Coolant temperature sensor malfunction		Check in the diagnostic mode (Code No. d:06). During cold starting: A tem- perature close to the ambient temperature is indicated. Indication is incorrect. $\rightarrow$ Replace the coolant tempera- ture sensor. Sensor inspection procedure. Refer to "CHECKING THE COOLANT TEMPERATURE SENSOR" on page 8-139.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		

Fault	code No.	21			
Item		Coolant temperature sensor: open or short circuit detected. (no nor- mal signals are received from the coolant temperature sensor.)			
Fail-e	afa svetam	Able to star	rt engine		
rail-sale system		Able to drive vehicle			
Diagn	ostic code No.	d:06			
Meter	display	Displays th	e coolant temperature.		
Procedure Compare display v		Compare th display valu	ne actually measured coolant ue.	temperature with the meter	
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure	
6	ECU malfunction		Replace the ECU.		

Work in a complete cold-engine condition.

Fault	code No.	22	22			
Item		Intake air te normal sigr	Intake air temperature sensor: open or short circuit detected. (no normal signals are received from the intake air temperature sensor.)			
Fail-e	afa svetam	Able to star	rt engine			
1 all-50	ale system	Able to driv	ve vehicle			
Diagn	ostic code No.	d:05				
Meter	display	Displays th	e intake air temperature.			
Proce	dure	Compare the actually measured intake air temperature with the meter display value.				
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
1	Connection of intake air tem- perature sensor coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	Continuity of wire	harness	Open or short circuit → Replace the wire harness. Black/blue–Black/blue Brown/white–Brown/white	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		

Fault	code No.	22			
Item		Intake air temperature sensor: open or short circuit detected. (no normal signals are received from the intake air temperature sensor.)			
Failer	afa svetom	Able to star	rt engine		
1 all-50	ale system	Able to driv	ve vehicle		
Diagn	ostic code No.	d:05			
Meter	display	Displays th	e intake air temperature.		
Proce	dure	Compare the actually measured intake air temperature with the meter display value.			
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure	
4	Installation status of intake air temperature sensor Check the mounting section for a loose or pinched mount- ing.		Make sure that the mounting position is correct.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
5	Intake air temperature sensor malfunction		Check in the diagnostic mode (Code No. d:05). Sensor inspection procedure Refer to "CHECKING THE INTAKE AIR TEMPERATURE SENSOR" on page 8-140. During cold starting: A tem- perature close to the ambient temperature is indicated. Indication is incorrect. $\rightarrow$ Replace the intake air tem- perature sensor.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
6	ECU malfunction		Replace the ECU		

Work in a complete cold-engine condition.

Fault code No.		24				
Item Fail-safe system		O <sub>2</sub> sensor:	Not activated. (no normal sig	nals are received from the		
		O <sub>2</sub> sensor.)	1			
		Able to start engine				
raii-5	ale system	Able to drive vehicle				
Diagn	ostic code No.		_			
Meter	display	—				
Proce	dure	—				
	Item/compon probable (	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
1	O <sub>2</sub> sensor installation status		Check the sensor for a loose mounting or a pinch	Either start and warm up the engine, and then racing it, or reset it with diagnostic code No. d:63. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
2	Connection of O <sub>2</sub> sensor coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Either start and warm up the engine, and then racing it, or reset it with diagnostic code No. d:63. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Either start and warm up the engine, and then racing it, or reset it with diagnostic code No. d:63. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
4	Continuity of wire harness		Open or short circuit → Con- nect it securely, or repair/ replace the wire harness. Black/blue–Black/blue Gray/green–Gray/green Red/blue–Red/blue Black–Black	Either start and warm up the engine, and then racing it, or reset it with diagnostic code No. d:63. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
5	Check the fuel pr	essure.	Refer to "CHECKING THE FUEL PRESSURE" on page 7-3.	Either start and warm up the engine, and then racing it, or reset it with diagnostic code No. d:63. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		

<u> </u>						
Fault code No.		24				
lt		O <sub>2</sub> sensor: Not activated. (no normal signals are received from the				
Item		O <sub>2</sub> sensor.)				
Fail-e	afa svetam	Able to star	rt engine			
1 all-50	ale system	Able to driv	ve vehicle			
Diagn	ostic code No.	—				
Meter	display	—				
Proce	dure	—				
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure		
6	O <sub>2</sub> sensor malfunction		Check the $O_2$ sensor for an abnormality. Refer to "ENGINE REMOVAL" on page 5-3. $O_2$ sensor malfunction $\rightarrow$ Replace the $O_2$ sensor.	Either start and warm up the engine, and then racing it, or reset it with diagnostic code No. d:63. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
7	ECU malfunction		Replace the ECU.			

Fault code No.		30				
Item		Latch up detected. No normal signals are received from the lean angle sensor.				
Fail-e	afo evetom	Unable to s	tart engine			
1 all-5	ale system	Unable to d	Irive vehicle			
Diagr	nostic code No.	d:08				
Meter display		Lean angle sensor output voltage • 0.4–1.4 (upright) • 3.7–4.4 (overturned)				
Proce	edure	Remove the lean angle sensor and incline it more than 45 degrees.				
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure		
1	Turnover of vehic	le	Raise the vehicle to the upright position	Rotate the main switch to the OFF position first, and then rotate it to the ON position again. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step		

Fault code No.		30				
		Latch up detected.				
Item		No normal signals are received from the lean angle sensor.				
Fail a	ofo ovotom	Unable to s	tart engine			
raii-s	ale system	Unable to d	Irive vehicle			
Diagn	ostic code No.	d:08				
Meter display		Lean angle sensor output voltage • 0.4–1.4 (upright) • 3.7–4.4 (overturned)				
Proce	dure	Remove the	e lean angle sensor and incli	ne it more than 45 degrees.		
	Item/compor probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
2	Sensor installation status		Check for a loose mounting, pinched mounting, or sensor mounting direction (up or down). Make sure that the mounting position is correct.	Rotate the main switch to the OFF position first, and then rotate it to the ON position again. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	Lean angle sensor malfunc- tion		Check in the diagnostic mode (Code No. d:08). Sensor inspection procedure Refer to "CHECKING THE LEAN ANGLE SENSOR" on page 8-135. In vertical position: 0.4-1.4 V When turned over: 3.7-4.4 V Indication is incorrect. $\rightarrow$ Replace the lean angle sen- sor.	Rotate the main switch to the OFF position first, and then rotate it to the ON position again. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
4	ECU malfunction		Replace the ECU.			

Fault code No.		33				
ltem		Ignition coil: open or short circuit detected in the primary lead of the ignition coil. (no normal signals are received from the ignition system.)				
Fail-s	afe svstem	Unable to s	tart engine			
		Unable to d	rive vehicle			
Diagn	ostic code No.	d:30				
Actua	ition	Actuates th Illuminates	the engine trouble warning li	ne-second intervals. ight.		
Proce	edure	Check that • Connect a	a spark is generated five time an ignition checker.	es.		
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
1	Connection of ignition coil connectors Check the connection of the connectors is secure. Disconnect the connectors, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely or replace the wire harness.	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely or replace the wire harness.	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	Continuity of wire harness		Open or short circuit → Replace the wire harness. Orange–Orange	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
4	Ignition coil installation status Check the mounting section for a loose or pinched mount- ing.		Make sure that the mounting position is correct.	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		

Fault code No.		33				
Item		Ignition coil: open or short circuit detected in the primary lead of the ignition coil. (no normal signals are received from the ignition sys-				
		Unable to s	tart engine			
Fail-sa	afe system	Unable to d	Irive vehicle			
Diagn	ostic code No.	d:30				
Actua	tion	Actuates the ignition coil five times at one-second intervals. Illuminates the engine trouble warning light.				
Procedure		Check that a spark is generated five times. <ul> <li>Connect an ignition checker.</li> </ul>				
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
5	Ignition coil malfunction (Check the continuity of pri- mary coil.)		Ignition coil inspection method Refer to "CHECKING THE IGNITION COIL" on page 8- 134.	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
6	6 ECU malfunction		Check in the diagnostic mode (Code No. d:30). If not ignited, replace the defective ECU.			

Fault code No.		37				
Item		Engine spe	Engine speed is high when the engine is idling.			
		Able to star	rt engine			
ra11-5	ale system	Able to driv	ve vehicle			
Diagn	ostic code No.	—				
Meter	<sup>-</sup> display	—				
Proce	edure	—				
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure		
1	Incorrect front wh	neel sensor	Check the front wheel sensor. Check in the diagnostic mode (Code No. d:07). Front wheel stop: The pulse integrated value should be constant. Rotate the front wheel a few turns manually and enter the speed pulse: The pulse inte- grated value will be added. Indication is incorrect. $\rightarrow$ Refer to Fault code No. 42	Start and idle the engine for approximately 10 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		

		1			
Fault code No.		37			
Item		Engine spe	ed is high when the engine is	s idling.	
Fail-s	afa svetam	Able to star	rt engine		
i all-30	are system	Able to driv	ve vehicle		
Diagn	ostic code No.	—			
Meter	display	—			
Proce	dure	—			
	Item/components probable cause		Check or maintenance job	Sensor inspection proce- dure	
2	Throttle valve does not fully close.		<ul> <li>Check the throttle body. Refer to "THROTTLE BODY" on page 7-5.</li> <li>Check the throttle cables. Refer to "CHECKING THE THROTTLE GRIP" on page 3-32.</li> </ul>	Start and idle the engine for approximately 10 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
3	Stuck fast idle plunger detected.		<ul> <li>Check the throttle body. Refer to "THROTTLE BODY" on page 7-5.</li> </ul>	Start and idle the engine for several minutes. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
4	ECU malfunction		Replace the ECU.		

TIP\_

• Do not remove the fast idle plunger.

If fault codes 16 and 37 are indicated simultaneously, take the actions specified for fault code 16 first.

• If fault codes 37 and 42 are indicated simultaneously, take the actions specified for fault code 42 first.

• If fault codes 37 and 46 are indicated simultaneously, take the actions specified for fault code 46 first.

Fault code No.		41				
ltem		Lean angle sensor: open or short circuit detected. (no normal sig- nals are received from the lean angle sensor.)				
Fail-e	afa svetam	Unable to s	tart engine			
1 all-50	ale system	Unable to d	lrive vehicle			
Diagn	ostic code No.	d:08				
Meter	display	Lean angle • 0.4–1.4 (u • 3.7–4.4 (o	Lean angle sensor output voltage • 0.4–1.4 (upright) • 3.7–4.4 (overturned)			
Proce	dure	Remove the	e lean angle sensor and inclir	ne it more than 45 degrees.		
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
1	Connection of lea sensor coupler Check the conne coupler is secure Disconnect the c check each pin (t wear, or locking).	an angle ection of the e. oupler, and for bending,	Poor connection → Connect it securely, or repair/replace the wire harness.	Rotate the main switch to the OFF position first, and then rotate it to the ON position again. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the harness.	Rotate the main switch to the OFF position first, and then rotate it to the ON position again. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	Continuity of wire harness		Open or short circuit → Replace the wire harness. Black/blue–Black/blue Yellow/green–Yellow/green Blue–Blue	Rotate the main switch to the OFF position first, and then rotate it to the ON position again. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		

Fault code No.		41			
ltem		Lean angle sensor: open or short circuit detected. (no normal sig- nals are received from the lean angle sensor.)			
	ofo overland	Unable to s	tart engine	-	
Fall-S	ate system	Unable to d	rive vehicle		
Diagn	ostic code No.	d:08			
Meter display		Lean angle sensor output voltage • 0.4–1.4 (upright) • 3.7–4.4 (overturned)			
Proce	dure	Remove the	e lean angle sensor and inclir	ne it more than 45 degrees.	
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure	
4	Lean angle sense	or malfunc-	Check in the diagnostic mode (Code No. d:08). Sensor inspection procedure Refer to "CHECKING THE LEAN ANGLE SENSOR" on page 8-135. In vertical position: 0.4-1.4 V When turned over: 3.7-4.4 V Indication is incorrect. $\rightarrow$ Replace the lean angle sen- sor.	Rotate the main switch to the OFF position first, and then rotate it to the ON position again. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
5	ECU malfunction		Replace the ECU.		

Fault code No.		42				
Item		No normal	No normal signals are received from the front wheel sensor.			
Failer	ofo system	Able to star	rt engine			
ra11-50	ale system	Able to driv	ve vehicle			
Diagn	ostic code No.	d:07				
Meter	display	Vehicle spe	ed pulses: 0–999			
Procedure		Check that The numbe stopped.	Check that the number increases when the front wheel is rotated. The number is cumulative and does not reset each time the wheel is stopped.			
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure		
1	Connection of front wheel sensor (meter) coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the "ON" position and then rotate the front wheel a few turns manually to enter the speed pulse. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
Fault code No.		42				
------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--	
Item		No normal signals are received from the front wheel sensor.				
Fail-safe system		Able to start engine				
		Able to driv	Able to drive vehicle			
Diagn	ostic code No.	d:07				
Meter	display	Vehicle spe	ed pulses: 0–999			
Proce	dure	Check that the number increases when the front wheel is rotated. The number is cumulative and does not reset each time the wheel is stopped.				
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
2	Connection of wi ABS ECU couple Check the conne coupler is secure Disconnect the c check each pin (f wear, or locking).	re harness er ction of the e. oupler, and for bending,	Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the "ON" position and then rotate the front wheel a few turns manually to enter the speed pulse. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the "ON" position and then rotate the front wheel a few turns manually to enter the speed pulse. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
4	Continuity of wire	e harness	<ul> <li>Open or short circuit →</li> <li>Replace the wire harness.</li> <li>Between front wheel sensor coupler and ABS ECU coupler.</li> <li>(White–White)</li> <li>(Black–Black)</li> <li>Between ABS ECU coupler and ECU coupler.</li> <li>(White–White)</li> </ul>	Place the main switch to the "ON" position and then rotate the front wheel a few turns manually to enter the speed pulse. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		

Fault code No.		42				
Item		No normal a	No normal signals are received from the front wheel sensor.			
Foil of	ofo ovotom	Able to star	rt engine			
Fail-safe system		Able to driv	ve vehicle			
Diagn	ostic code No.	d:07				
Meter	display	Vehicle spe	ed pulses: 0–999			
Procedure		Check that the number increases when the front wheel is rotated. The number is cumulative and does not reset each time the wheel is stopped.				
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure		
5	Front wheel sensor malfunc- tion		Check the front wheel sensor. Check in the diagnostic mode (Code No. d:07). Front wheel stop: The pulse integrated value should be constant. Rotate the front wheel a few turns manually and enter the speed pulse: The pulse inte- grated value will be added. Indication is incorrect. → Refer to "MAINTENANCE OF THE FRONT WHEEL SEN- SOR AND SENSOR ROTOR" on page 4-21	Place the main switch to the "ON" position and then rotate the front wheel a few turns manually to enter the speed pulse. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
6	ECU or ABS ECI	U malfunc-	Replace the ECU or ABS ECU.			

## TIP\_\_\_\_\_

If fault codes 37 and 42 are indicated simultaneously, take the actions specified for fault code 42 first.

Fault code No.		43				
Item		Fuel system and fuel pu	Fuel system voltage: incorrect voltage supplied to the fuel injector			
Foil oofo ovetem		Able to star	rt engine			
Fail-s	ate system	Able to driv	ve vehicle			
Diagr	ostic code No.	d:09, d:50				
	Meter display	Fuel system Approximation	n voltage (battery voltage) tely 12.0			
d:09	Procedure	Set the eng measured b ally measured	Set the engine stop switch to " $\bigcirc$ ", and then compare the actually measured battery voltage with the meter display value. (If the actually measured battery voltage is low, recharge the battery.)			
d:50	Actuation	Actuates th intervals. Illuminates	e fuel injection system relay the engine trouble warning li	five times at one-second ight.		
	Procedure	Check that listening fo	the fuel injection system rela r the operating sound.	y is actuated five times by		
	Item/compor probable	nents and cause	Check or maintenance job	Sensor inspection proce- dure		
1	Connection of fuel injection system relay coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
3	Continuity of wire harness between the battery, main fuse, fuel injection system fuse, fuel injection system relay and ECU		Open or short circuit → Replace the wire harness. Red–Red Red/blue–Red/blue	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
4	Fuel injection sys malfunction	stem relay	Check in the diagnostic mode (Code No. d:50). No operation sound of fuel injection system relay is heard. $\rightarrow$ Replace the fuel injection system relay.	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		

Fault	code No.	43				
Item Fue and		Fuel systen and fuel pu	Fuel system voltage: incorrect voltage supplied to the fuel injector and fuel pump.			
Eail-e	afa system	Able to star	rt engine			
ra11-5	ale system	Able to driv	ve vehicle			
Diagn	ostic code No.	d:09, d:50				
	Meter display	Fuel system Approximat	n voltage (battery voltage) tely 12.0			
d:09	Procedure	Set the engine stop switch to " $\bigcirc$ ", and then compare the actually measured battery voltage with the meter display value. (If the actually measured battery voltage is low, recharge the battery.)				
d:50	Actuation	Actuates th intervals. Illuminates	Actuates the fuel injection system relay five times at one-second intervals. Illuminates the engine trouble warning light.			
	Procedure	Check that listening fo	the fuel injection system rela r the operating sound.	y is actuated five times by		
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure		
5	Fuel injection system relay malfunction		Check in the diagnostic mode (Code No. d:09) Fuel-related voltage: 3 V or less $\rightarrow$ Replace the fuel injection system relay.	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.		
6	ECU malfunction		Replace the ECU.			

Fault	code No.	44			
Item		Error is detected while reading or writing on EEPROM (CO adjust- ment value).			
Fail-e	afa svetam	Under certa	ain conditions		
raii-50	ale system	Under certa	ain conditions		
Diagn	ostic code No.	d:60			
Meter display		<ul> <li>EEPROM fault code display</li> <li>00 (no history)</li> <li>01 or 02: Cylinder fault code number (history exists) If both cylinders are defective, the display alternates every two seconds.</li> </ul>			
Proce	dure	—			
Item/componen probable cau		ents and cause	Check or maintenance job	Sensor inspection proce- dure	
1	Locate the malfu	nction.	Check in the diagnostic mode (Code No. d:60) 00 indication: Check number 4. 01 indication: Check number 2		

Fault code No.		44			
Item		Error is detected while reading or writing on EEPROM (CO adjust- ment value).			
Fail-sa	afe system	Under certa	ain conditions ain conditions		
Diagn	ostic code No.	d:60			
Meter display Me		EEPROM fa • 00 (no his • 01 or 02: ( If both cyl seconds.	PROM fault code display 0 (no history) 1 or 02: Cylinder fault code number (history exists) both cylinders are defective, the display alternates every two econds.		
Proce	dure	—			
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure	
2	"01" is indicated in Diagnostic mode (Code No. d:60) EEPROM data error for adjustment of CO concentra- tion of cylinder #1		Change the CO concentra- tion of cylinder #1, and rewrite in EEPROM. Refer to "ADJUSTING THE EXHAUST GAS VOLUME" on page 3-11. After this adjustment is made, the main switch is set to OFF.	Place the main switch to the ON position. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Return to Step 1 to carry out the check again. If the condi- tion persists, proceed to Step 4.	
3	"02" is indicated in Diagnostic mode (Code No. d:60) EEPROM data error for adjustment of CO concentra- tion of cylinder #2		Change the CO concentra- tion of cylinder #2, and rewrite in EEPROM. Refer to "ADJUSTING THE EXHAUST GAS VOLUME" on page 3-11. After this adjustment is made, the main switch is set to OFF.	Place the main switch to the ON position. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Return to Step 1 to carry out the check again. If the condi- tion persists, proceed to Step 4.	
4	ECU malfunction		Replace the ECU		

Fault code No. 46				
Item		Incorrect vo	oltage is supplied to the ECU	•
Foil o	ofo ovotom	Able to star	rt engine	
raii-s	ale system	Able to driv	ve vehicle	
Diagn	nostic code No.	—		
Meter	<sup>,</sup> display	—		
Proce	edure	—		
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure
1	Charging system malfunction		Check the charging system. Refer to "CHARGING SYS- TEM" on page 8-11. Check the rectifier/regulator, AC magneto and wire har- ness. $\rightarrow$ Replace if defective.	Start and idle the engine for approximately 5 seconds. Then, check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Recheck.

## TIP \_\_\_\_\_

If fault codes 37 and 46 are indicated simultaneously, take the actions specified for fault code 46 first.

Fault	code No.	50			
Item		Faulty ECU memory. (When this malfunction is detected in the ECU, the fault code number might not appear on the meter.)			
Faile	afa svetom	Unable to s	tart engine		
1 all-5	ale system	Unable to drive vehicle			
Diagnostic code No. –		—			
Meter	display	_			
Proce	dure	—			
	Item/components and probable cause		Check or maintenance job	Sensor inspection proce- dure	
1	ECU malfunction		Replace the ECU.	Place the main switch to the ON position. Then, check that no fault code indicated.	

Fault code No.		Er-1			
Item		ECU internal malfunction (output signal error): no signals are received from the ECU.			
Fail-cafe system		Able to star	rt engine (Unable if ECU Failu	ıre)	
T un 3		Able to driv	ve vehicle (Unable if ECU Fail	ure)	
Diagn	ostic code No.	<u> </u>			
Meter	display	<u> </u>			
Proce	dure	<u> </u>			
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure	
1	Connection of meter coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending,		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
3	Connection of diagnostic tool coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending,		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
4	Continuity of wire harness		Open or short circuit → Con- nect it securely, or repair/ replace the wire harness. Yellow/blue–Yellow/blue	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
5	Abnormal meter tion	unit opera-	Replace the meter assembly.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
6	ECU malfunction		Replace the ECU.		

Fault code No.		Er-2			
Item		ECU internal malfunction (output signal error): no signals are received from the ECU within the specified duration.			
Fail-s	afo system	Able to sta	rt engine		
T all-5	ale system	Able to driv	ve vehicle		
Diagn	ostic code No.	—			
Meter	display	—			
Proce	dure	—			
	Item/compon probable o	ents and cause	Check or maintenance job	Sensor inspection proce- dure	
1	Connection of meter coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending,		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
3	Connection of diagnostic tool coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending,		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
4	Continuity of wire harness		Open or short circuit → Con- nect it securely, or repair/ replace the wire harness. Yellow/blue–Yellow/blue	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
5	Abnormal meter tion	unit opera-	Replace the meter assembly.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
6	ECU malfunction		Replace the ECU.		

Fault code No.		Er-3			
Item		ECU internal malfunction (output signal error): data from the ECU cannot be received correctly.			
Foil o		Able to star	rt engine		
rall-sa	ale system	Able to driv	/e vehicle		
Diagn	ostic code No.	—			
Meter	display	—			
Proce	dure	—			
	Item/compon probable	ents and cause	Check or maintenance job	Sensor inspection proce- dure	
1	Connection of meter coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending,		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
3	Connection of diagnostic tool coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending,		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
4	Continuity of wire harness		Open or short circuit → Con- nect it securely, or repair/ replace the wire harness. Yellow/blue-Yellow/blue	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
5	Abnormal meter tion	unit opera-	Replace the meter assembly.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
6	ECU malfunction		Replace the ECU.		

Fault code No.		Er-4			
Item		ECU internal malfunction (input signal error): non-registered data has been received from the meter.			
Fail-s	afe system	Able to sta	rt engine		
T all 3	ale system	Able to driv	ve vehicle		
Diagn	ostic code No.	—			
Meter	display	—			
Proce	dure	—			
	Item/compon probable o	ents and cause	Check or maintenance job	Sensor inspection proce- dure	
1	Connection of meter coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending, wear, or locking).		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
2	Connection of wire harness ECU coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending,		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
3	Connection of diagnostic tool coupler Check the connection of the coupler is secure. Disconnect the coupler, and check each pin (for bending,		Poor connection → Connect it securely, or repair/replace the wire harness.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
4	Continuity of wire harness		Open or short circuit → Con- nect it securely, or repair/ replace the wire harness. Yellow/blue–Yellow/blue	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
5	Abnormal meter tion	unit opera-	Replace the meter assembly.	Place the main switch to the ON position, and check the fault code indication. No fault code indicated. $\rightarrow$ Recovered. Fault code indicated. $\rightarrow$ Check the next step.	
6	ECU malfunction		Replace the ECU.		

#### EAS30660 DIAGNOSTIC CODE TABLE

TIP\_

The following tables contain information about diagnostic code numbers that do not have a corresponding fault code number. (These items are not listed in "TROUBLESHOOTING DETAILS".)

Diag- nostic code No.	Item	Meter display/Actuation	Procedure
d:36	Fuel injector #1	Actuates the fuel injector #1 five times at one-second intervals. Illuminates the engine trou- ble warning light.	Check the operating sound of the fuel injector #1 five times. ECA59C1801 <b>NOTICE</b> Disconnect the fuel pump coupler.
d:37	Fuel injector #2	Actuates the fuel injector #2 five times at one-second intervals. Illuminates the engine trou- ble warning light.	Check the operating sound of the fuel injector #2 five times. ECA59C1801 <b>NOTICE</b> Disconnect the fuel pump coupler.
d:51	Radiator fan motor relay	Actuates the radiator fan motor relay for five cycles of five seconds. (ON 2 sec- onds, OFF 3 seconds) Illuminates the engine trou- ble warning light.	Check the operating sound of the radiator fan motor relay five times.
d:52	Headlight relay	Actuates the headlight relay for five cycles of five seconds. (ON 2 seconds, OFF 3 sec- onds) Illuminates the engine trou- ble warning light.	Check the operating sound of the headlight relay five times.
d:57	Grip warmer relay	Actuates the grip warmer relay. Illuminates the engine trou- ble warning light. (The light is off when the relay is off, and the light is on when the relay is on.)	Touch the grip warmer to check the temperature change.

## FUEL INJECTION SYSTEM

Diag- nostic code No.	Item	Meter display/Actuation	Procedure
d:61	Malfunction history code display		
	No history	00	
	History exists	<ul> <li>Fault code Nos. 12–50</li> <li>(If more than one code number is detected, the dis- play alternates every two seconds to show all the detected code numbers.</li> <li>When all code numbers are shown, the display repeats the same process.)</li> </ul>	
d:62	Malfunction history code erasure		
	No history	00	
	History exists	• Displays the total number of malfunctions, including the current malfunction, that have occurred since the history was last erased. (For example, if there have been three malfunctions, "03" is displayed.)	To erase the history, set the engine stop switch from " $\bigotimes$ " to " $\bigcirc$ ".
d:63	Malfunction code reinstate- ment (for fault code No. 24)		
	<ul> <li>No malfunction code</li> </ul>	00	—
	Malfunction code exists	Fault code No. 24	To reinstate, set the engine stop switch from " $\bigotimes$ " to " $\bigcirc$ ".
d:70	Control number	0–254 [-]	—

Set the main switch to "OFF" to cancel the diagnostic mode.

TIP\_

Information about each diagnostic code No. is organized in this manual as follows:

• If a diagnostic code No. has a corresponding fault code No., the information is shown in TROU-

BLESHOOTING DETAILS. (Refer to "TROUBLESHOOTING DETAILS" on page 8-37)

• If a diagnostic code No. does not have a corresponding fault code No., the information is shown in DIAGNOSTIC CODE TABLE. (Refer to "DIAGNOSTIC CODE TABLE" on page 8-68)

# FUEL PUMP SYSTEM

#### EAS27560 CIRCUIT DIAGRAM



- 4. Frame ground
- 5. Joint
- 6. Main switch
- 8. Joint coupler
- 12. Fuel injection system fuse
- 16.Ignition fuse
- 19.Battery
- 20.Negative lead
- 21.Main fuse
- 26.Right handlebar switch
- 27.Engine stop switch
- 35. Fuel injection system relay
- 36.Fuel pump
- 39.ECU (engine control unit)

EAS27570 TROUBLESHOOTING If the fuel pump fails to operate.		
<ul> <li>TIP</li></ul>	owing part(s):	
<ol> <li>Check the fuses. (Main, ignition and fuel injection system) Refer to "CHECKING THE FUSES" on page 8-127.</li> </ol>	NG→	Replace the fuse(s).
OK↓		
2. Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-127.	NG→	<ul><li>Clean the battery terminals.</li><li>Recharge or replace the battery.</li></ul>
OK↓		
3. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the main switch/immobilizer unit.
OK↓		
4. Check the engine stop switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	$NG \rightarrow$	The engine stop switch is faulty. Replace the right handlebar switch.
OK↓		
<ol> <li>Check the fuel injection system relay.</li> <li>Refer to "CHECKING THE RELAYS" on page 8-131.</li> </ol>	NG→	Replace the fuel injection system relay.
OK↓		
6. Check the fuel pump. Refer to "CHECKING THE FUEL PRESSURE" on page 7-3.	NG→	Replace the fuel pump assembly.
OK↓		
<ol> <li>Check the entire fuel pump system's wiring.</li> <li>Refer to "CIRCUIT DIAGRAM" on page 8-71.</li> </ol>	NG→	Properly connect or repair the fuel pump system's wiring.
OK↓		
Replace the ECU (engine control unit).		

#### EAS27650 CIRCUIT DIAGRAM



- 4. Frame ground
- 5. Joint
- 6. Main switch
- 7. Immobilizer unit
- 8. Joint coupler
- 13.Backup fuse
- 16.Ignition fuse
- 19.Battery
- 20.Negative lead
- 21.Main fuse
- 39.ECU (engine control unit)
- 50.Diagnostic tool coupler
- 82.Meter assembly
- 83.Immobilizer system indicator light
- 92.Multi-function meter

## GENERAL INFORMATION

This vehicle is equipped with an immobilizer system to help prevent theft by re-registering codes in the standard keys. This system consists of the following:

- A code re-registering key (with a red bow)
- Two standard keys (with a black bow) that can be re-registered with new codes
- A transponder (installed in the red key bow)
- An immobilizer unit
- The ECU
- An immobilizer system indicator light

The key with the red bow is used to register codes in each standard key. Do not use the key with the red bow for driving. It should only be used for re-registering new codes in the standard keys. The immobilizer system cannot be operated with a new key until the key registered with a code. If you lose the code re-registering key, the ECU and main switch (equipped with the immobilizer unit) need to be replaced.

Therefore, always use a standard key for driving. (Refer to NOTICE below.)

### TIP.

Each standard key is registered during production, therefore re-registering at purchase is not necessary.

## ECA14971

### NOTICE

- DO NOT LOSE THE CODE RE-REGISTERING KEY! If the code re-registering key is lost, registering new codes in the standard keys is impossible. The standard keys can still be used to start the vehicle. However, if code re-registering is required (e.g., if a new standard key is made or all keys are lost) the entire immobilizer system must be replaced. Therefore, it is highly recommended to use either standard key for driving, and to keep the code re-registering key in a safe place.
- Do not submerse the keys in water.
- Do not expose the keys to excessively high temperatures.
- Do not place the keys close to magnets (this includes, but is not limited to, products such as speakers, etc.).
- Do not place heavy items on the keys.
- Do not grind the keys or alter their shape.
- Do not disassemble the key bows.
- Do not put two keys of any immobilizer system on the same key ring.
- Keep the standard keys as well as other immobilizer system keys away from the code reregistering key.
- Keep other immobilizer system keys away from the main switch as they may cause signal interference.

## PART REPLACEMENT AND KEY CODE REGISTRATION REQUIREMENTS

In the course of use, you may encounter the following cases where replacement of parts and registration of code re-registering/standard keys are required.

### TIP\_

Each standard key is registered during production, therefore re-registering at purchase is not necessary.

	Parts to be replaced					
	Main switch/immo- bilizer unit		Standard	EQU	Acces-	Key registration
	Main switch	Immobi- lizer unit	key	200	and key	
Standard key is lost						New standard key
All keys have been lost (including code re-registering key)			$\checkmark$			Code re-registering key and standard keys
ECU is defective						Code re-registering key and standard keys
Immobilizer unit is defective		$\checkmark$				Code re-registering key and standard keys
Main switch is defec- tive			$\checkmark$		$\checkmark$	Code re-registering key and standard keys
Accessory lock* is defective						Not required

\* Accessory locks mean the seat lock and fuel tank cap.

## Code re-registering key registration:

When the immobilizer unit or ECU is replaced, the code re-registering key must be registered to the unit.

To register a code re-registering key:

1. Set the main switch to "ON" with the code re-registering key.

TIP.

Check that the immobilizer system indicator light comes on for one second, then goes off. When the immobilizer system indicator light goes off, the code re-registering key has been registered.

2. Check that the engine can be started.

3. Register the standard key, following the instructions in the section below.

## Standby mode:

To enable the immobilizer system, set the ignition key to "OFF". 30 seconds later, the indicator light will start flashing continuously in the standby flashing mode pattern for up to 24 hours. After that time, the indicator light will stop flashing, but the immobilizer system is still enabled. **Standby mode** 



## Standard key registration:

Standard key registration is required when a standard key is lost and needs to be replaced, or when the code re-registering key is re-registered after the immobilizer unit or ECU are replaced.

TIP\_

Do not start the engine with a standard key that has not been registered. If the main switch is set to "ON" with a standard key that has not been registered, the immobilizer system indicator light flashes to indicate fault code "52". (Refer to "SELF-DIAGNOSIS FAULT CODE INDICATION" on page 8-82).

- 1. Check that the immobilizer system indicator light signals the standby mode.
- 2. Using the code re-registering key, set the main switch to "ON", then "OFF", and then remove the key within 5 seconds.
- 3. Insert the first standard key to be registered into the main switch, then set the key to "ON" within 5 seconds to activate the key registration mode.

TIP\_

The existing standard key code is erased from the memory when the key registration mode is activated. When the key registration mode is activated, the immobilizer system indicator light flashes rapidly.

4. While the indicator light is flashing, set the main switch to "OFF", remove the key, and within 5 seconds, insert the second standard key to be registered into the main switch.

TIP\_

If he immobilizer system indicator light stops flashing 5 seconds after the first standard key is registered, the registration mode is deactivated. If this occurs, the second standard key cannot be registered, and steps 2 to 4 need to be repeated to register both standard keys.

5. Set the main switch to "ON".

TIP\_

When the indicator light goes off, the registration is complete.

6. Check that the engine can be started with the two registered standard keys.

Standard key registration



- a. Main switch "ON"
- b. Main switch "OFF"
- c. LED on
- d. LED off
- e. Less than 5.0 s
- f. Code re-registering key
- g. First standard key
- h. Second standard key

- i. Registration mode
- A. Registration of the second standard key is complete.
- B. Immobilizer system indicator light stops flashing when the registration of the second standard key is complete.

## Voiding the standard key code:

If a standard key has been lost, it is possible to disable its use by re-registering the remaining standard key. Standard key registration erases the stored standard key code from the memory, thus disabling the lost standard key. To re-register, refer to "Standard key registration". **Standard key code voiding method** 



- a. Main switch "ON"
- b. Main switch "OFF"
- c. LED on
- d. LED off
- e. Less than 5.0 s
- f. Code re-registering key
- g. Remaining standard key
- h. Registration mode
- A. If the immobilizer system indicator light stops flashing 5 seconds after the first standard key is registered, the second standard key cannot be registered.

#### EAS27701 TROUBLESHOOTING

When the main switch is set to "ON", the immobilizer system indicator light does not come on nor flashes.

1. Check the fuses. (Main, ignition and backup) Refer to "CHECKING THE FUSES" on page 8-127.	NG→	Replace the fuse(s).
ОК↓	_	
<ol> <li>Check the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-127.</li> </ol>	NG→	<ul><li>Clean the battery terminals.</li><li>Recharge or replace the battery.</li></ul>
OK↓		
3. Check the main switch. Refer to "CHECKING THE SWITCHES" on page 8-123.	NG→	Replace the main switch/immobilizer unit.
OK↓	1	
4. Check the entire immobilizer sys- tem's wiring. Refer to "CIRCUIT DIAGRAM" on page 8-75.	NG→	Properly connect or repair the immobi- lizer system's wiring.
OK↓		
<ul> <li>Check the condition of the each immobilizer system circuits.</li> <li>Refer to "SELF-DIAGNOSIS FAULT CODE INDICATION" on page 8-82.</li> </ul>		

## SELF-DIAGNOSIS FAULT CODE INDICATION

When a system malfunction occurs, the fault code number is indicated in the LCD display of the meter assembly and the immobilizer system indicator light flashes at the same time. The pattern of flashing also shows the fault code.

Fault code	Part	Symptom	Cause	Action
51	IMMOBILIZER UNIT	Code cannot be transmitted between the key and the immobilizer unit.	<ol> <li>Radio wave interference caused by objects around the keys and antennas.</li> <li>Immobilizer unit malfunction.</li> <li>Key malfunction.</li> </ol>	<ol> <li>Keep magnets, metal objects, and other immo- bilizer system keys away from the keys and antennas.</li> <li>Replace the main switch/ immobilizer unit.</li> <li>Replace the key.</li> </ol>
52	IMMOBILIZER UNIT	Codes between the key and immobilizer unit do not match.	<ol> <li>Signal received from other transponder (failed to recognize code after ten con- secutive attempts).</li> <li>Signal received from unregistered stan- dard key.</li> </ol>	<ol> <li>Place the immobilizer unit at least 50 mm (1.97 in) away from the transponder of other vehicles.</li> <li>Register the standard key.</li> </ol>
53	IMMOBILIZER UNIT	Codes cannot be transmitted between the ECU (engine control unit) and the immobilizer unit.	<ul> <li>Noise interference or disconnected lead/cable.</li> <li>1. Interference due to radio wave noise.</li> <li>2. Disconnected communication harness.</li> <li>3. Immobilizer unit malfunction.</li> <li>4. ECU (engine control unit) malfunction.</li> </ul>	<ol> <li>Check the wire harness and con- nector.</li> <li>Replace the main switch/ immobilizer unit.</li> <li>Replace the ECU (engine control unit).</li> </ol>

## **IMMOBILIZER SYSTEM**

Fault				
code	Part	Symptom	Cause	Action
54	IMMOBILIZER UNIT	Codes transmitted between the ECU (engine control unit) and the immobilizer unit do not match.	<ul> <li>Noise interference or disconnected lead/cable.</li> <li>1. Interference due to radio wave noise.</li> <li>2. Disconnected communication harness.</li> <li>3. Immobilizer unit malfunction.</li> <li>4. ECU (engine control unit) failure. (The ECU (engine control unit) failure. control unit) or immobilizer unit was replaced with a used unit from another vehicle.)</li> </ul>	<ol> <li>Register the code re-register- ing key.</li> <li>Check the wire harness and con- nector.</li> <li>Replace the main switch/ immobilizer unit.</li> <li>Replace the ECU (engine control unit).</li> </ol>
55	IMMOBILIZER UNIT	Key code registra- tion malfunction.	Same standard key was attempted to be regis- tered two consecutive times.	Register another standard key.
56	ECU (engine control unit)	Unidentified code is received.	Noise interference or dis- connected lead/cable.	<ol> <li>Check the wire harness and con- nector.</li> <li>Replace the main switch/ immobilizer unit.</li> <li>Replace the ECU (engine control unit).</li> </ol>

## Immobilizer system indicator light fault code indication

Units of 10: Cycles of on for 1 second and off for 1.5 seconds. Units of 1: Cycles of on for 0.5 second and off for 0.5 second. Example: fault code 52



a. Light on

b. Light off

## **IMMOBILIZER SYSTEM**

# ABS (ANTI-LOCK BRAKE SYSTEM)

#### EAS27730 CIRCUIT DIAGRAM



4. Frame ground 5. Joint 6. Main switch 8. Joint coupler 13.Backup fuse 14.Signaling system fuse 16.Ignition fuse 19.Battery 20.Negative lead 21.Main fuse 22.Starter relay 24.Starting circuit cut-off relay 2 25.Diode 1 26.Right handlebar switch 27. Engine stop switch 28.Start switch 30. Front brake light switch 31.ABS motor fuse 32.ABS solenoid fuse 33.Diode 2 34.Starting circuit cut-off relay 1 39.ECU (engine control unit) 50.Diagnostic tool coupler 51.Wheel sensor shield ground 52.ABS ECU (electronic control unit) 53.Front wheel sensor 54.Rear wheel sensor 55.ABS test coupler 64.Tail/brake light 67.Left handlebar switch 72.Rear brake light switch 81.ABS ECU fuse 82.Meter assembly 90.ABS warning light 92.Multi-function meter

EAS27740 ABS COMPONENTS CHART



- 1. Hydraulic unit assembly (ABS ECU)
- 2. Fuse box (right)
- 3. Fuse box (left)
- 4. ABS warning light
- 5. ABS test coupler
- 6. Rear wheel sensor rotor
- 7. Rear wheel sensor
- 8. Front wheel sensor
- 9. Front wheel sensor rotor

#### EAS27750 ABS COUPLER LOCATION CHART



- 1. Front wheel sensor coupler
- 2. Meter assembly coupler
- 3. ABS test coupler
- 4. Rear wheel sensor coupler
- 5. ABS ECU coupler

#### EAS27770 MAINTENANCE OF THE ABS ECU

## Checking the ABS ECU

- 1. Check:
  - Terminals "1" of the ABS ECU Cracks/damages → Replace the hydraulic unit assembly and the brake pipes that are connected to the assembly as a set.
  - Terminals "2" of the ABS ECU coupler Connection defective, contaminated, come-off → Correct or clean.

#### TIP\_

If the ABS ECU coupler is clogged with mud or dirt, clean with compressed air.



#### EAS27790

## ABS TROUBLESHOOTING OUTLINE

This section describes the troubleshooting for the ABS in detail. Read this service manual carefully and make sure you fully understand the information provided before repairing any malfunctions or performing service.

The ABS ECU (electronic control unit) has a self-diagnosis function. When failures occur in the system, the ABS warning light on the meter assembly indicates a malfunction.

The following troubleshooting describes the problem identification and service method according to the indications by the multi-function display. For troubleshooting items other than the following items, follow the normal service method.

EWA59C2801

## **WARNING**

When maintenance or checks have been performed on components related to the ABS, be sure to perform a final check before delivering the vehicle to the customer. (Refer to "[C-3] FINAL CHECK" on page 8-117.)

## ABS operation when the ABS warning light comes on

- 1. The ABS warning light remains on  $\rightarrow$  ABS operates as a normal brake system.
  - A malfunction was detected using the ABS self-diagnosis function.
  - The ABS self-diagnosis test is not completed.
     The self-diagnosis test begins when the vehicle starts up for the first time after the main switch was set to "ON", and is completed when the vehicle is operated at a speed of about 10 km/h
- (6.3 mi/h). (Refer to "ABS warning light" on page 1-17.)
  2. The ABS warning light comes on when the engine is started, and goes off when the vehicle is operated (at a speed of about 10 km/h [6.2 mi/h]; refer to "ABS warning light" on page 1.17.)
- operated (at a speed of about 10 km/h [6.3 mi/h]: refer to "ABS warning light" on page 1-17.)  $\rightarrow$  ABS operation is normal.
  - The ABS warning light comes on while the start switch is being pushed.
- 3. The ABS warning light flashes  $\rightarrow$  ABS operation is normal.
  - Refer to "BASIC INSTRUCTIONS FOR TROUBLESHOOTING" on page 8-92.

## Self-diagnosis and servicing

The ABS ECU has a self-diagnosis function. By utilizing this function, quick problem identification and service are possible. Previous malfunctions can be checked since the ABS ECU also stores the malfunction history.

The multi-function display indicates all the fault codes recorded in the ABS ECU.

Note all of the indicated fault codes if fault codes are stored in the memory. When the service is finished, check the normal operation of the vehicle, and then delete the fault code(s). (Refer to "[C-3] FINAL CHECK" on page 8-117.) By deleting the fault codes stored in the ABS ECU memory, it is possible to pursue the cause correctly if another malfunction occurs.

#### TIP\_

The ABS performs a self-diagnosis test for a few seconds each time the vehicle starts up for the first time after the main switch was set to "ON". During this test, a "clicking" noise can be heard from front side of the vehicle, and if the front brake lever or rear brake lever are even slightly applied, a vibration can be felt at the levers, but these do not indicate a malfunction.

### Self-diagnosis using the ABS ECU

The ABS ECU performs a static check of the entire system when the main switch is set to "ON". It also checks for malfunctions while the vehicle is ridden. Since all malfunctions are recorded after they are detected, it is possible to check the recorded malfunction data by utilizing the multi-function display when the ABS ECU has entered the self-diagnosis mode.

## Special precautions for handling and servicing a vehicle equipped with ABS

ECA59C2801

NOTICE

Care should be taken not to damage components by subjecting them to shocks or pulling on them with too much force since the ABS components are precisely adjusted.

- The ABS ECU and hydraulic unit are united assemblies and cannot be disassembled.
- The malfunction history is stored in the memory of the ABS ECU. Delete the fault codes when the service is finished. (This is because the past fault codes will be displayed again if another malfunction occurs.)

## EAS27800

#### BASIC INSTRUCTIONS FOR TROUBLESHOOTING EWA59C2802

## **WARNING**

Perform the troubleshooting [A] → [B] → [C] in order. Be sure to follow the order since a wrong diagnosis could result if the steps are followed in a different order or omitted.
 Use sufficiently charged regular batteries only.

• Use sufficiently charged regular batteries only.

[A] Malfunction check using the ABS warning light

[B] Determining the cause and location of the malfunction from the recorded fault code by using the test coupler adapter

Determine the cause of the malfunction from the condition and place where the malfunction occurred.

[C] Servicing the ABS

Execute the final check after disassembly and assembly.



#### EAS27810 BASIC PROCESS FOR TROUBLESHOOTING
## EWA59C2803

A WARNING

When maintenance or checks have been performed on components related to the ABS, be sure to perform a final check before delivering the vehicle to the customer. (Refer to "[C-3] FINAL CHECK" on page 8-117.)

## EAS27830

## [A] CHECKING THE ABS WARNING LIGHT

Set the main switch to "ON". (Do not start the engine.)

- 1. The ABS warning light does not come on.
  - Only the ABS warning light fails to come on. [A-1]
  - The ABS warning light and all other indicator lights fail to come on. [A-2]
- 2. The ABS warning light flashes. [A-3]
- 3. The ABS warning light comes on. [A-4]

## EAS59C2801

## [A-1] ONLY THE ABS WARNING LIGHT FAILS TO COME ON

- 1. Check for a short circuit to the ground between the White/Red terminal of the ABS ECU coupler and White/Red terminal of the meter assembly.
  - If there is short circuit to the ground, the wire harness is defective. Properly repair or replace the defective harness.
- 2. Disconnect the ABS ECU coupler and check that the ABS warning light comes on when the main switch is set to "ON".
  - If the ABS warning light does not come on, the meter assembly circuit (including the ABS warning light [LED]) is defective. Replace the meter assembly.
  - If the ABS warning light comes on, the ABS ECU is defective. Replace the hydraulic unit assembly.

## EAS59C2802

## [A-2] THE ABS WARNING LIGHT AND ALL OTHER INDICATOR LIGHTS FAIL TO COME ON

- 1. Main switch
  - Check the main switch for continuity. Refer to "CHECKING THE SWITCHES" on page 8-123.
  - If there is no continuity, replace the main switch/immobilizer unit.
- 2. Battery
  - Check the condition of the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-127.
  - If the battery is defective, clean the battery terminals and recharge it, or replace the battery.
- 3. Main fuse
  - Check the fuse for continuity.
    - Refer to "CHECKING THE FUSES" on page 8-127.
  - If the main fuse is blown, replace the fuse.
- 4. Circuit
  - Check the meter assembly circuit.
    - Refer to "CIRCUIT DIAGRAM" on page 8-85.
  - If the meter assembly circuit is open, properly repair or replace the wire harness.

## EAS59C2803

## [A-3] THE ABS WARNING LIGHT FLASHES

- 1. Checking the test coupler adapter
  - Check if the test coupler adapter is connected to the ABS test coupler.
  - If the test coupler adapter is connected, disconnect it, install the protective cap onto the ABS test coupler and then start over from the beginning.
- 2. If the test coupler adapter is not connected
  - Check whether the T/C terminal (sky blue) of the ABS test coupler is short-circuited to the ground when the test coupler adapter is removed.
  - If the T/C terminal is short-circuited to the ground, the wire harness is defective. Properly repair or replace the wire harness.
  - If the T/C terminal is not short-circuited to the ground, check the internal circuit of the meter assembly.
    - Set the main switch to "OFF".
    - Disconnect the ABS ECU coupler.
    - Set the main switch to "ON", and then check the ABS warning light.
    - If the ABS warning light flashes, the internal circuit of the meter assembly is defective. Replace the meter assembly.
    - If the ABS warning light comes on, the ABS ECU is defective. Replace the hydraulic unit assembly.

#### EAS59C2804 [A-4] THE ABS WARNING LIGHT COMES ON

Set the main switch to "OFF".

Remove the protective cap from the ABS test coupler "1", and then connect the test coupler adapter "2" to the coupler. The T/C terminal (sky blue) is now grounded.

Set the main switch to "ON", and then check the multi-function meter.



- 1. The multi-function display does not display the fault code "1". [B-1]
- 2. The fault code "1" is displayed on the multi-function display (example: fault code ABS\_11). [B-3]



#### EAS59C2805 [B-1] THE MULTI-FUNCTION DISPLAY DOES NOT DISPLAY THE FAULT CODE

- 1. A malfunction that keeps the ABS warning light on is detected. [B-2]
- 2. The ABS warning light flashes every 0.5 second for more than 6 seconds.
- No malfunction is detected.

The ABS warning light flashes every 0.5 second if a fault code for a past malfunction is not stored in the memory of the ABS ECU. The ABS warning light flashes quicker if a fault code is displayed on the multi-function display. If no fault code is displayed, make sure that the customer understands the possible conditions that may cause the ABS warning light to come on or flash even if the system is normal.

## TIP\_

- The ABS fault codes will not be displayed if a fault code for the fuel injection system is displayed on the multi-function display. To display the ABS fault codes, delete the fuel injection system fault codes, and then start the check again.
- The test coupler adapter must be connected to the ABS test coupler to display the fault codes. If the adapter is not connected, the ABS warning light will come on or flash, but no fault codes will be displayed.

## EAS59C2806

## [B-2] THE ABS WARNING LIGHT REMAINS ON

- 1. The battery voltage is low.
  - Check the condition of the battery. Refer to "CHECKING AND CHARGING THE BATTERY" on page 8-127.
  - If the battery voltage is low, clean the battery terminals and recharge it, or replace the battery.
- 2. ABS ECU fuse
  - Check the ABS ECU fuse for continuity. Refer to "CHECKING THE FUSES" on page 8-127.
  - If the ABS ECU fuse is blown, replace the fuse.
- 3. ABS ECU coupler
  - Check that the ABS ECU coupler is connected properly.
  - Connect the couplers properly if necessary.
- 4. There is a break in the wire harness between the main switch and the ABS ECU or between the ABS ECU and the ground.
  - Check for continuity between the Brown/Blue terminal of the main switch coupler and Brown/ Blue terminal of the ABS ECU fuse.
  - Check for continuity between the Brown/White terminal of the ABS ECU fuse and the Brown/ White terminal of the ABS ECU coupler.
  - If there is no continuity, the wire harness is defective. Properly repair or replace the wire harness.
  - Check for continuity between the Black/White terminal of the ABS ECU coupler and the ground.
  - If there is no continuity, the wire harness is defective. Properly repair or replace the wire harness.
- 5. There is a break in the wire harness between the ABS ECU and the meter assembly (ABS warning light).
  - Check for continuity between the White/Red terminal of the ABS ECU coupler and the White/ Red terminal of the meter assembly coupler.
  - If there is no continuity, the wire harness is defective. Properly repair or replace the defective harness.

- 6. The meter assembly circuit is defective.
  - Disconnect the ABS ECU coupler.
  - The White/Red terminal of the ABS ECU coupler is short-circuited to the ground.
  - Set the main switch to "ON", and then check the ABS warning light.
  - If the ABS warning light is on, the internal circuit of the meter assembly is defective. Replace the meter assembly.
  - If the ABS warning light does not come on, the ABS ECU is defective. Replace the hydraulic unit assembly.
- 7. The hydraulic unit assembly is defective.

## EAS59C2807

## [B-3] DIAGNOSIS USING THE FAULT CODES

After turning the main switch to "OFF", connect the test coupler adapter to the ABS test coupler, and then set the main switch to "ON".

Information for the fault codes from the ABS ECU is contained in the following table. Refer to this table for troubleshooting.

TIP.

Record all of the fault codes displayed and inspect the check points.

## Fault code table

Fault code No.	Symptom	Check point
ABS_11* ABS_25*	Front wheel sensor signal is not received properly.	<ul> <li>Installation of the front wheel sensor</li> <li>Front wheel</li> <li>Front wheel sensor housing</li> <li>Front wheel sensor rotor</li> </ul>
ABS_12	Rear wheel sensor signal is not received properly.	<ul> <li>Installation of the rear wheel sensor</li> <li>Rear wheel</li> <li>Rear wheel sensor housing</li> <li>Rear wheel sensor rotor</li> </ul>
ABS_13 ABS_26	Incorrect signal from the front wheel sensor is detected.	<ul> <li>Installation of the front wheel sensor</li> <li>Front wheel</li> <li>Front wheel sensor housing</li> <li>Front wheel sensor rotor</li> <li>Hydraulic unit assembly</li> </ul>
ABS_14 ABS_27	Incorrect signal from the rear wheel sensor is detected.	<ul> <li>Installation of the rear wheel sensor</li> <li>Rear wheel</li> <li>Rear wheel sensor housing</li> <li>Rear wheel sensor rotor</li> <li>Hydraulic unit assembly</li> </ul>
ABS_15	No continuity in the front wheel sensor circuit.	<ul> <li>Continuity of the front wheel sensor circuit</li> <li>Wire harness (ABS circuit)</li> <li>Connection of the front wheel sensor coupler and ABS ECU coupler</li> <li>Front wheel sensor</li> </ul>
ABS_16	No continuity in the rear wheel sensor circuit.	<ul> <li>Continuity of the rear wheel sensor circuit</li> <li>Wire harness (ABS circuit)</li> <li>Connection of the rear wheel sensor coupler and ABS ECU coupler</li> <li>Rear wheel sensor</li> </ul>

Fault code No.	Symptom	Check point
ABS_17 ABS_45	Missing pulses detected in the front wheel sensor signal.	<ul><li>Front wheel sensor rotor</li><li>Front wheel sensor housing</li><li>Front wheel</li></ul>
ABS_18 ABS_46	Missing pulses detected in the rear wheel sensor signal.	<ul><li>Rear wheel sensor rotor</li><li>Rear wheel sensor housing</li><li>Rear wheel</li></ul>
ABS_21	Hydraulic unit solenoid circuit is open or short-circuited.	<ul> <li>Hydraulic unit assembly</li> </ul>
ABS_22	Start switch signal is not received prop- erly (start switch circuit or start switch monitor circuit).	<ul> <li>Wire harness</li> <li>Connection of the starting circuit cut-off relay couplers and ABS ECU coupler.</li> </ul>
ABS_24	Brake light signal is not received prop- erly while vehicle is traveling (brake light circuit, or front or rear brake light switch circuit).	<ul> <li>Brake light bulbs</li> <li>Wire harness (brake light circuit)</li> <li>Brake light system couplers and connectors</li> </ul>
ABS_31	Solenoid relay is defective. Power is not supplied to the solenoid relay.	<ul> <li>ABS solenoid fuse</li> <li>Wire harness (battery and ABS ECU circuit)</li> <li>Connection of the ABS ECU coupler</li> <li>Hydraulic unit assembly</li> </ul>
ABS_32	Hydraulic unit solenoid relay is short- circuited.	Hydraulic unit assembly
ABS_33	ABS motor is defective. Power is not supplied to the ABS motor.	<ul> <li>Battery voltage</li> <li>ABS motor fuse</li> <li>Wire harness (ABS circuit)</li> <li>Connection of the ABS ECU coupler and starter relay coupler</li> <li>Hydraulic unit assembly</li> </ul>
ABS_34	Hydraulic unit ABS motor relay is short- circuited.	Hydraulic unit assembly
ABS_41	Front wheel will not recover from the locking tendency even though the sig- nal is continuously transmitted from the ABS ECU to release the hydraulic pres- sure.	<ul> <li>Brake dragging</li> <li>Brake fluid</li> <li>Hydraulic unit operation tests</li> <li>Front wheel brake lines</li> <li>Hydraulic unit assembly</li> </ul>
ABS_42 ABS_47	Rear wheel will not recover from the locking tendency even though the sig- nal is continuously transmitted from the ABS ECU to release the hydraulic pres- sure.	<ul> <li>Brake dragging</li> <li>Brake fluid</li> <li>Hydraulic unit operation tests</li> <li>Rear wheel brake lines</li> <li>Hydraulic unit assembly</li> </ul>
ABS_43	Incorrect signal from the front wheel sensor is detected.	<ul> <li>Installation of the front wheel sensor</li> <li>Front wheel sensor housing</li> <li>Front wheel sensor rotor</li> </ul>
ABS_44	Incorrect signal from the rear wheel sensor is detected.	<ul> <li>Installation of the rear wheel sensor</li> <li>Rear wheel sensor housing</li> <li>Rear wheel sensor rotor</li> </ul>
ABS_51 ABS_52	Power voltage is too high.	<ul> <li>Battery voltage</li> <li>Battery terminal</li> <li>Refer to "CHARGING SYSTEM" on page 8- 11.</li> </ul>

Fault code No.	Symptom	Check point
ABS_53	Power voltage is too low.	<ul> <li>Battery voltage</li> <li>Connection of the ABS ECU coupler</li> <li>Wire harness</li> <li>Refer to "CHARGING SYSTEM" on page 8- 11.</li> </ul>
ABS_54	Power voltage is too low.	<ul> <li>Battery voltage</li> <li>Connection of the ABS ECU coupler and starter relay coupler</li> <li>Wire harness</li> <li>Refer to "CHARGING SYSTEM" on page 8- 11.</li> </ul>
ABS_56	Hydraulic unit sensor power monitor cir- cuit is abnormal.	Hydraulic unit assembly
ABS_63	Front wheel sensor power is abnormal.	<ul><li>Front wheel sensor lead</li><li>Wire harness</li><li>Hydraulic unit assembly</li></ul>
ABS_64	Rear wheel sensor power is abnormal.	<ul><li>Rear wheel sensor lead</li><li>Wire harness</li><li>Hydraulic unit assembly</li></ul>

\* A fault code is indicated if the rear wheel rotates for longer than about 20 seconds (fault code No. ABS\_11) or for longer than about 2 seconds (fault code No. ABS\_25) with the front wheel stopped (e.g., when the vehicle is on the suitable stand).

#### TIP\_

Fault codes Nos. ABS\_15 (front wheel) and ABS\_16 (rear wheel) are indicated if a defective connection is detected in the front or rear wheel sensor when the vehicle is not being ridden.

Fault co	ode No. ABS_11 ABS_25 Symptom		Symptom	Front wheel sensor signal is not received prop- erly.
Order	Item/components and probable cause			Check or maintenance job
1	Installed condition of wheel sensor.			Check for looseness. Repair or replace the wheel sensor if necessary.
2	Installed condition of wheel bear- ings, axle, sensor housing, and sensor rotor.			Check the components for looseness, distortion, and bends. Refer to "CHECKING THE FRONT WHEEL" on page 4-20.
3	Foreign material inside sensor housing.		e sensor	Check the interior of the sensor housing and the sur- face of the sensor rotor for foreign material, such as metal particles. Clean the sensor housing and sensor rotor if necessary. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-21.

Fault c	code No. ABS_11 ABS_25 Symptom		Symptom	Front wheel sensor signal is not received properly.
Order	Item/components and probable cause			Check or maintenance job
4	Defective sensor rotor.			Check the surface of the sensor rotor for damage. Replace the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-21.

TIP\_\_\_\_\_

With front wheel stopped, rear wheel was rotated for longer than about 20 seconds (fault code No. ABS\_11) or for longer than about 2 seconds (fault code No. ABS\_25).

Fault c	Fault code No. ABS_12 Symptom		Symptom	Rear wheel sensor signal is not received properly.
Order	Item/components and probable cause			Check or maintenance job
1	Installed condition of wheel sensor.			Check for looseness. Repair or replace the wheel sensor if necessary.
2	Installed condition of wheel bear- ings, axle, sensor housing, and sensor rotor.			Check the components for looseness, distortion, and bends. Refer to "CHECKING THE REAR WHEEL" on page 4-32.
3	Foreign material inside sensor housing.			Check the interior of the sensor housing and the sur- face of the sensor rotor for foreign material, such as metal particles. Clean the sensor housing and sensor rotor if necessary. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-33.
4	Defective sensor rotor.			Check the surface of the sensor rotor for damage. Replace the sensor rotor if there is visible damage. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-33.

Fault co	t code No. ABS_13 ABS_26 Symptom		Symptom	Incorrect signal from the front wheel sensor is detected.
Order	Item/components and probable cause			Check or maintenance job
1	Installed condition of wheel sensor.			Check for looseness. Repair or replace the wheel sensor if necessary.
2	Installed condition of wheel bear- ings, axle, sensor housing, and sensor rotor.			Check the components for looseness, distortion, and bends. Refer to "CHECKING THE FRONT WHEEL" on page 4-20.
3	Foreign housing	material insid ı.	e sensor	Check the interior of the sensor housing and the sur- face of the sensor rotor for foreign material, such as metal particles. Clean the sensor housing and sensor rotor if necessary. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-21.

Fault c	ode No.	ABS_13 ABS_26	Symptom	Incorrect signal from the front wheel sensor is detected.
Order	Item/components and probable cause			Check or maintenance job
4	Defective sensor rotor.			Check the surface of the sensor rotor for damage. If there is visible damage, replace the sensor rotor. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-21.
5	Hydraulic unit assembly internal malfunction.		bly internal	Replace the hydraulic unit assembly.

TIP\_\_\_\_\_

Vehicle possibly ridden on uneven roads.

Fault c	Fault code No. ABS_14 ABS_27 Symptom		Symptom	Incorrect signal from the rear wheel sensor is detected.
Order	ltem/co cause	omponents an	d probable	Check or maintenance job
1	Installed	d condition of v	wheel sensor.	Check for looseness. Repair or replace the wheel sensor if necessary.
2	Installed condition of wheel bear- ings, axle, sensor housing, and sensor rotor.			Check the components for looseness, distortion, and bends. Refer to "CHECKING THE REAR WHEEL" on page 4-32.
3	Foreign material inside sensor housing.			Check the interior of the sensor housing and the sur- face of the sensor rotor for foreign material, such as metal particles. Clean the sensor housing and sensor rotor if necessary. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-33.
4	Defective sensor rotor.			Check the surface of the sensor rotor for damage. If there is visible damage, replace the sensor rotor. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-33.
5	Hydraul malfunc	lic unit assemb tion.	bly internal	Replace the hydraulic unit assembly.

## TIP\_\_\_\_\_

Vehicle possibly ridden on uneven roads.

Fault c	ode No. ABS_15 Symptom	No continuity in the front wheel sensor circuit.
Order	Item/components and probable cause	Check or maintenance job
1	Connections <ul> <li>Front wheel sensor coupler</li> <li>ABS ECU coupler</li> </ul>	<ul> <li>Check the coupler for any pins that may be pulled out.</li> <li>Check the locking condition of the coupler.</li> <li>If there is a malfunction, repair it and connect the coupler securely.</li> </ul>
		Set the main switch to "OFF" before disconnecting or connecting a coupler.
2	Wire harness continuity.	<ul> <li>Check for continuity between the white terminal "1" and the white terminal "3" and between the black terminal "2" and the black terminal "4".</li> <li>If there is no continuity, the wire harness is defective. Properly repair or replace the wire harness.</li> <li>Check that there is no continuity between the ground and the white terminal "1" or white terminal "3" and between the ground and the black terminal "3" and between the ground and the black terminal "2" or black terminal "4".</li> <li>If there is continuity, the wire harness is defective. Properly repair or replace the wire harness.</li> <li>Check that there is no continuity between the white terminal "1" and the black terminal "2" and between the terminal "1" and the black terminal "2" and between the white terminal "3" and the black terminal "2".</li> <li>If there is continuity, the wire harness is defective. Properly repair or replace the wire harness.</li> <li>Check that there is no continuity between the white terminal "3" and the black terminal "2".</li> <li>If there is continuity, the wire harness is defective. Properly repair or replace the wire harness.</li> <li>ABS ECU</li> <li>Front wheel sensor</li> </ul>
3	Defective wheel sensor.	If the above items were performed and no malfunc- tions were found, connect the ABS ECU coupler and front wheel sensor coupler, and then delete the fault codes. If fault code No. ABS_15 could not be deleted, the front wheel sensor is defective. Replace the front wheel sensor. <b>TIP</b> Before deleting the fault codes, record all of the fault codes and perform the related checks and mainte- nance.

Fault c	ode No. ABS_16 Symptom	No continuity in the rear wheel sensor circuit.
Order	Item/components and probable cause	Check or maintenance job
1	Connections <ul> <li>Rear wheel sensor coupler</li> <li>ABS ECU coupler</li> </ul>	<ul> <li>Check the coupler for any pins that may be pulled out.</li> <li>Check the locking condition of the coupler.</li> <li>If there is a malfunction, repair it and connect the coupler securely.</li> <li>TIP</li></ul>
		Set the main switch to "OFF" before disconnecting or connecting a coupler.
2	Wire harness continuity.	<ul> <li>Check for continuity between the white terminal "1" and the white terminal "3" and between the black terminal "2" and the black terminal "4".</li> <li>If there is no continuity, the wire harness is defective. Properly repair or replace the wire harness.</li> <li>Check that there is no continuity between the ground and the white terminal "1" or white terminal "3" and between the ground and the black terminal "3" and between the ground and the black terminal "2" or black terminal "4".</li> <li>If there is continuity, the wire harness is defective. Properly repair or replace the wire harness.</li> <li>Check that there is no continuity between the white terminal "1" and the black terminal "2" and between the white terminal "1" and the black terminal "2" and between the white terminal "1" and the black terminal "2" and between the white terminal "3" and the black terminal "4".</li> <li>If there is continuity, the wire harness is defective. Properly repair or replace the wire harness.</li> <li>Check that there is no continuity between the white terminal "1" and the black terminal "2" and between the white terminal "3" and the black terminal "4".</li> <li>If there is continuity, the wire harness is defective. Properly repair or replace the wire harness.</li> <li>S. ABS ECU</li> <li>5. ABS ECU</li> <li>6. Rear wheel sensor</li> </ul>
3	Defective wheel sensor.	If the above items were performed and no malfunc- tions were found, connect the ABS ECU coupler and rear wheel sensor coupler, and then delete the fault codes. If fault code No. ABS_16 could not be deleted, the rear wheel sensor is defective. Replace the rear wheel sensor. <b>TIP</b> Before deleting the fault codes, record all of the fault codes and perform the related checks and mainte- nance.

Fault c	ode No.	ABS_17 ABS_45	Symptom	Missing pulses detected in the front wheel sensor signal.
Order	Item/co cause	omponents ar	nd probable	Check or maintenance job
1	Installed condition of wheel bear- ings, axle, sensor housing, and sensor rotor.			Check the components for looseness, distortion, and bends. Refer to "CHECKING THE FRONT WHEEL" on page 4-20.
2	Foreign material inside sensor housing.			Check the interior of the sensor housing and the sur- face of the sensor rotor for foreign material, such as metal particles. Clean the sensor housing and sensor rotor if necessary. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-21.
3	Defectiv	e sensor roto	r.	<ul><li>Check the surface of the sensor rotor for damage.</li><li>If there is visible damage, replace the sensor rotor.</li></ul>

Fault code No.		ABS_18 ABS_46	Symptom	Missing pulses detected in the rear wheel sensor signal.
Order	Item/components and probable cause			Check or maintenance job
1	Installed condition of wheel bear- ings, axle, sensor housing, and sensor rotor.			Check the components for looseness, distortion, and bends. Refer to "CHECKING THE REAR WHEEL" on page 4-32.
2	Foreign material inside sensor housing.			Check the interior of the sensor housing and the sur- face of the sensor rotor for foreign material, such as metal particles. Clean the sensor housing and sensor rotor if necessary. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-33.
3	Defectiv	e sensor rotor	r.	<ul><li>Check the surface of the sensor rotor for damage.</li><li>If there is visible damage, replace the sensor rotor.</li></ul>

Fault code No. ABS_21 Symp		Symptom	Hydraulic unit solenoid circuit is open or short- circuited.	
Order	Item/components and probable cause			Check or maintenance job
1	Open or short circuit in solenoid circuit.			Replace the hydraulic unit assembly.

Fault code No.		ABS_22	Symptom	Start switch signal is not received properly (start switch circuit or start switch monitor circuit).
Order	rder Item/components and probable cause			Check or maintenance job
1	Engine startability.			Check the electric starting system. Refer to "ELECTRIC STARTING SYSTEM" on page 8-5.

Fault c	Fault code No. ABS_22 Symptom		Symptom	Start switch signal is not received properly (start switch circuit or start switch monitor circuit).
Order	Item/co cause	omponents ar	id probable	Check or maintenance job
2	Connections • Starter relay coupler • ABS ECU coupler • Right handlebar switch coupler		r tch coupler	<ul> <li>Check the coupler for any pins that may be pulled out.</li> <li>Check the locking condition of the coupler.</li> <li>If there is a malfunction, repair it and connect the coupler securely.</li> <li>TIP</li> <li>Set the main switch to "OFF" before disconnecting or connecting a coupler.</li> </ul>
3	Open or short circuit in wire har- ness.		n wire har-	<ul> <li>Repair or replace if there is an open or short circuit.</li> <li>Between ABS ECU coupler and starter relay coupler. (Blue/white–Blue/white)</li> <li>Between ABS ECU coupler and right handlebar switch (start switch) coupler. (Green/white–Green/white)</li> </ul>

Fault c	ode No.	ABS_24	Symptom	Brake light signal is not received properly while vehicle is traveling (brake light circuit, or front or rear brake light switch circuit).
Order	ltem/co cause	mponents an	id probable	Check or maintenance job
1	Brake light operation. <ul> <li>Defective tail/brake light</li> </ul>			<ul> <li>Check the tail/brake light. Repair or replace the tail/ brake light if necessary.</li> <li>Refer to "CHECKING THE BULBS AND BULB SOCKETS" on page 8-126.</li> </ul>
2	<ul> <li>Connections</li> <li>ABS ECU coupler</li> <li>Front brake light switch connectors</li> <li>Rear brake light switch connectors</li> </ul>			<ul> <li>Check the coupler for any pins that may be pulled out.</li> <li>Check the locking condition of the coupler.</li> <li>If there is a malfunction, repair it and connect the coupler securely.</li> <li>TIP</li> <li>Set the main switch to "OFF" before disconnecting or</li> </ul>
				connecting a coupler.
3	Open or short circuit in wire har- ness.			<ul> <li>Repair or replace if there is an open or short circuit.</li> <li>Between rear brake light switch connector and ABS ECU coupler. (Green/yellow–Green/yellow)</li> <li>Between front brake light switch connector and ABS ECU coupler. (Green/yellow–Green/yellow)</li> </ul>
4	Water in	nside switch.		Use compressed air to blow out the water.

Fault c	ode No.	ABS 31	Symptom	Solenoid relay is defective.
	Item/components and probable		- , 1	Power is not supplied to the solenoid relay.
Order	Order Item/components and probable cause			Check or maintenance job
1	Battery voltage			Recharge or replace the battery. Refer to "CHECKING AND CHARGING THE BAT- TERY" on page 8-127.
2	Blown ABS solenoid fuse.			Check the ABS solenoid fuse. If the ABS solenoid fuse is blown, replace the fuse and check the wire harness. Refer to "CHECKING THE FUSES" on page 8-127.
3	Connections <ul> <li>ABS ECU coupler</li> </ul>			<ul> <li>Check the coupler for any pins that may be pulled out.</li> <li>Check the locking condition of the coupler.</li> <li>If there is a malfunction, repair it and connect the coupler securely.</li> <li>TIP</li> <li>Set the main switch to "OFF" before disconnecting or connecting a coupler.</li> </ul>
4	Open or short circuit in wire har- ness.			<ul> <li>Repair or replace if there is an open or short circuit.</li> <li>Between ABS ECU coupler and ABS solenoid fuse. (Red–Red)</li> <li>Between ABS ECU coupler and ground. (Black–Black)</li> </ul>
5	Hydraul malfund	ic unit assemb tion.	bly internal	Replace the hydraulic unit assembly.

Fault code No. ABS_32 Symptom		Symptom	Hydraulic unit solenoid relay is short-circuited.	
Order	Item/components and probable cause			Check or maintenance job
1	Short circuit in solenoid relay.			Replace the hydraulic unit assembly.
2	Hydraulic unit assembly internal malfunction.			Replace the hydraulic unit assembly.

Fault c	Fault code No. ABS		Symptom	ABS motor is defective. Power is not supplied to the ABS motor.
Order	Item/components and probable cause			Check or maintenance job
1	Battery voltage			Recharge or replace the battery. Refer to "CHECKING AND CHARGING THE BAT- TERY" on page 8-127.
2	Blown ABS motor fuse.			Check the ABS motor fuse. If the ABS motor fuse is blown, replace the fuse and check the wire harness. Refer to "CHECKING THE FUSES" on page 8-127.

Fault code No. A		ABS_33	Symptom	ABS motor is defective. Power is not supplied to the ABS motor.
Order	Item/co cause	mponents an	id probable	Check or maintenance job
3	Connections • ABS ECU coupler • Starter relay coupler		r	<ul> <li>Check the coupler for any pins that may be pulled out.</li> <li>Check the locking condition of the coupler.</li> <li>If there is a malfunction, repair it and connect the coupler securely.</li> <li>TIP</li> <li>Set the main switch to "OFF" before disconnecting or connecting a coupler.</li> </ul>
4	Open or short circuit in wire har- ness.		n wire har-	<ul> <li>Repair or replace if there is an open or short circuit.</li> <li>Between ABS ECU coupler and ABS motor fuse. (Red/blue–Red/blue)</li> <li>Between ABS ECU coupler and ground. (Black/white–Black/white)</li> </ul>
5	Hydraul malfunc	lic unit assemb	oly internal	Replace the hydraulic unit assembly.

Fault code No. ABS_34 Symptom		Symptom	Hydraulic unit ABS motor relay is short-circuited.	
Order	Order Item/components and probable cause			Check or maintenance job
1	Short circuit in ABS motor relay.		otor relay.	Replace the hydraulic unit assembly.

Fault c	ode No.	ABS_41	Symptom	Front wheel will not recover from wheel lock even though the signal is continuously transmitted from the ABS ECU and the hydraulic pressure has been released (when the battery voltage is normal).
Order	Item/components and probable cause			Check or maintenance job
1	Rotation of wheel			<ul> <li>Check that there is no brake disc drag on the front wheel and make sure that it rotates smoothly.</li> <li>Check the front wheel axle for loose bearings and bends, and the brake discs for distortion.</li> <li>Refer to "CHECKING THE FRONT BRAKE DISCS" on page 4-42.</li> </ul>
2	Brake master cylinder and brake caliper			<ul> <li>Check that the brake fluid pressure is correctly transmitted to the brake calipers when the front brake lever is operated and that the pressure decreases when the lever is released.</li> </ul>
3	Brake fluid			<ul> <li>Visually check the brake fluid in the brake master cylinder reservoir for water, foreign materials, solidification, and contamination.</li> <li>Check for air in the brake lines.</li> </ul>

Fault c	ode No.	ABS_41	Symptom	Front wheel will not recover from wheel lock even though the signal is continuously transmitted from the ABS ECU and the hydraulic pressure has been released (when the battery voltage is normal).
Order	ltem/co cause	mponents ar	nd probable	Check or maintenance job
4	Brake lines			Check the brake lines for kinks and deterioration.     EWA59C2804     WARNING
				Only use genuine Yamaha parts. Using other brake pipes, hoses and union bolts may close the brake lines.
				• Check that the connections of the brake lines from the brake master cylinder to the hydraulic unit and from the hydraulic unit to the front brake calipers are correct.
				See WARNING and TIP.
5	Hydraul	ic unit asseml	oly	If the malfunction is not corrected after checking items (1) to (4), replace the hydraulic unit assembly. Be sure to connect the brake pipes and coupler cor- rectly and securely. Check the hydraulic unit opera- tion. Refer to "HYDRAULIC UNIT OPERATION TESTS" on page 4-72.

EWA59C2805

**WARNING** 

The front brakes will not function properly if the connections are reversed.

Front brake hose (hydraulic unit to front brake hose joint) "1": to the front brake calipers
Front brake hose (front brake master cylinder to hydraulic unit) "2": from the front brake

master cylinder

TIP\_

- If the brake pipe inlet and outlet connections are incorrect on the hydraulic unit, the front brake lever will be pulled to its full-stroke position without responding, and then it will be pushed back slowly without pulsating when the final check on page "[C-3] FINAL CHECK" on page 8-117 is performed.
- If the front and rear brake pipe connections are reversed on the hydraulic unit, the pulsating action in the front brake lever and rear brake lever will be performed in the reverse order when the final check on page "[C-3] FINAL CHECK" on page 8-117 is performed.

Fault c	Fault code No. ABS_42 ABS_47 Symptom		Symptom	Rear wheel will not recover from wheel lock even though the signal is continuously transmitted from the ABS ECU and the hydraulic pressure has been released.
Order	Item/co cause	mponents an	nd probable	Check or maintenance job
1	Rotation	n of wheel		<ul> <li>Check that there is no brake disc drag on the rear wheel and make sure that it rotates smoothly.</li> <li>Check for brake disc distortion. Refer to "CHECKING THE REAR BRAKE DISC" on page 4-58.</li> </ul>
2	Brake n caliper	naster cylinder	r and brake	• Check that the brake fluid pressure is correctly transmitted to the brake caliper when the rear brake lever is operated and that the pressure decreases when the lever is released.
3	Brake fl	uid		<ul> <li>Visually check the brake fluid in the brake master cylinder reservoir for water, foreign materials, solidification, and contamination.</li> <li>Check for air in the brake lines.</li> </ul>
4	Brake lines			<ul> <li>Check the brake lines for kinks and deterioration (particularly between the hydraulic unit and the rear brake caliper).</li> <li>EWA59C2804</li> <li>WARNING</li> </ul>
				Only use genuine Yamaha parts. Using other brake pipes, hoses and union bolts may close the brake lines.
				• Check that the connections of the brake lines from the brake master cylinder to the hydraulic unit are correct.
				See WARNING and TIP.
5	Hydraulic unit assembly		oly	If the malfunction is not corrected after checking items (1) to (4), replace the hydraulic unit assembly. Be sure to connect the brake hose, brake pipe, and coupler correctly and securely. Check the hydraulic unit operation. Refer to "HYDRAULIC UNIT OPERATION TESTS" on page 4-72.

## EWA59C2806

## 

The rear brake will not function properly if the connections are reversed.

- Rear brake hose (rear brake master cylinder to hydraulic unit) "1": from the rear brake master cylinder
- Rear brake pipe/joint assembly (hydraulic unit to rear brake hose) "2": to the rear brake caliper

## TIP\_

- If the brake pipe inlet and outlet connections are reversed on the hydraulic unit, the rear brake lever will be pulled to its full-stroke position without responding, and then it will be pushed back slowly without pulsating when the final check on page "[C-3] FINAL CHECK" on page 8-117 is performed.
- If the front and rear brake pipe connections are reversed on the hydraulic unit, the pulsating action in the front brake lever and rear brake lever will be performed in the reverse order when the final check on page "[C-3] FINAL CHECK" on page 8-117 is performed.

Fault c	ode No.	ABS_43	Symptom	Incorrect signal from the front wheel sensor is detected.
Order	ltem/co cause	mponents an	d probable	Check or maintenance job
1	Installed	d condition of v	wheel sensor.	Check for looseness. Repair or replace the wheel sensor if necessary.
2	Installed condition of wheel bear- ings, axle, sensor housing, and sensor rotor.			Check the components for looseness, distortion, and bends. Refer to "CHECKING THE FRONT WHEEL" on page 4-20.
3	Foreign material inside sensor housing.			Check the interior of the sensor housing and the sur- face of the sensor rotor for foreign material, such as metal particles. Clean the sensor housing and sensor rotor if necessary. Refer to "MAINTENANCE OF THE FRONT WHEEL SENSOR AND SENSOR ROTOR" on page 4-21.
4	Defectiv	e sensor rotor	<b>.</b>	<ul><li>Check the surface of the sensor rotor for damage.</li><li>If there is visible damage, replace the sensor rotor.</li></ul>

Fault c	ode No.	ABS_44	Symptom	Incorrect signal from the rear wheel sensor is detected.
Order	ltem/co cause	mponents an	d probable	Check or maintenance job
1	Installed condition of wheel sensor.			Check for looseness. Repair or replace the wheel sensor if necessary.
2	Installed condition of wheel bear- ings, axle, sensor housing, and sensor rotor.			Check the components for looseness, distortion, and bends. Refer to "CHECKING THE REAR WHEEL" on page 4-32.
3	Foreign material inside sensor housing.			Check the interior of the sensor housing and the sur- face of the sensor rotor for foreign material, such as metal particles. Clean the sensor housing and sensor rotor if necessary. Refer to "MAINTENANCE OF THE REAR WHEEL SENSOR AND SENSOR ROTOR" on page 4-33.

Fault code No.		ABS_44	Symptom	Incorrect signal from the rear wheel sensor is detected.
Order	Item/components and probable cause		d probable	Check or maintenance job
4	Defective sensor rotor.			<ul><li>Check the surface of the sensor rotor for damage.</li><li>If there is visible damage, replace the sensor rotor.</li></ul>

Fault code No.		ABS_51 ABS_52	Symptom	Power voltage is too high.
Order	Item/components and probable cause			Check or maintenance job
1	Battery voltage			Replace the battery. Refer to "CHECKING AND CHARGING THE BAT- TERY" on page 8-127.
2	Disconnected battery terminal (fault code No. ABS_52).			Check the connection. Replace or reconnect the ter- minal if necessary.
3	Charging system			Check the charging system. Refer to "CHARGING SYSTEM" on page 8-11.

Fault c	Fault code No. ABS_53 Symptom			Power voltage is too low.
Order	Order Item/components and probable cause			Check or maintenance job
1	1 Battery voltage			Recharge or replace the battery. Refer to "CHECKING AND CHARGING THE BAT- TERY" on page 8-127.
2 Connections • ABS ECU coupler			<ul> <li>Check the coupler for any pins that may be pulled out.</li> <li>Check the locking condition of the coupler.</li> <li>If there is a malfunction, repair it and connect the coupler securely.</li> </ul>	
				Set the main switch to "OFF" before disconnecting or connecting a coupler.
3	Open o ness.	r short circuit i	n wire har-	<ul> <li>Repair or replace if there is an open or short circuit.</li> <li>Between ABS ECU coupler and ABS ECU fuse. (Brown/white–Brown/white)</li> </ul>
4	Chargir	Charging system		Check the charging system. Refer to "CHARGING SYSTEM" on page 8-11.

Fault code No. ABS_54 Symptom		Symptom	Power voltage is too low.	
Order	rder Item/components and probable cause			Check or maintenance job
1	Battery voltage			Recharge or replace the battery. Refer to "CHECKING AND CHARGING THE BAT- TERY" on page 8-127.

Fault c	ode No. ABS_54 Symptom	Power voltage is too low.
Order	Item/components and probable cause	Check or maintenance job
2	Connections • ABS ECU coupler • Starter relay coupler	<ul> <li>Check the coupler for any pins that may be pulled out.</li> <li>Check the locking condition of the coupler.</li> <li>If there is a malfunction, repair it and connect the coupler securely.</li> <li>TIP</li></ul>
		connecting a coupler.
3	Open or short circuit in wire har- ness.	<ul> <li>Repair or replace if there is an open or short circuit.</li> <li>Between ABS ECU coupler and ABS ECU fuse. (Brown/white–Brown/white)</li> <li>Between ABS ECU coupler and ABS solenoid fuse. (Red–Red)</li> <li>Between ABS ECU coupler and ABS motor fuse. (Red/blue–Red/blue)</li> </ul>
4	Charging system	Check the charging system. Refer to "CHARGING SYSTEM" on page 8-11.

Fault code No.		ABS_56	Symptom	Hydraulic unit sensor power monitor circuit is abnormal.
Order	Order Item/components and probable cause		nd probable	Check or maintenance job
1	Defective internal monitor circuit (sensor power).			Replace the hydraulic unit assembly.

Fault c	Fault code No. ABS_63 Symptom		Symptom	Front wheel sensor power is abnormal.
Order	ltem/co cause	mponents an	id probable	Check or maintenance job
1	Short circuit in wire harness.			<ul> <li>Check that there is no short circuit between the white terminal "1" and the black terminal "2".</li> <li>Check that there is no short circuit between the frame ground and the black terminal "2".</li> <li>If there is a short circuit, the wire harness is defective. Properly repair or replace the wire harness.</li> </ul>
				TIP
				Disconnect the ABS ECU coupler before checking the wire harness.

Fault co	ode No. ABS_63	Symptom	Front wheel sensor power is abnormal.
Order	Item/components an cause	d probable	Check or maintenance job
2	Short circuit in front wi	heel sensor	<ul> <li>Check that there is no short circuit between the white terminal "3" and the gray terminal "4".</li> <li>Check that there is no short circuit between the frame ground and the white terminal "3".</li> <li>If there is a short circuit, the front wheel sensor is defective. Properly repair or replace the front wheel sensor.</li> </ul>
			5. ABS ECU 6. Front wheel sensor
3	Hydraulic unit internal	malfunction.	Replace the hydraulic unit assembly.

Fault co	Fault code No. ABS_64 Symptom		Symptom	Rear wheel sensor power is abnormal.
Order	ltem/co cause	mponents an	d probable	Check or maintenance job
1	Short circuit in wire harness.		arness.	<ul> <li>Check that there is no short circuit between the white terminal "1" and the black terminal "2".</li> <li>Check that there is no short circuit between the frame ground and the black terminal "2".</li> <li>If there is a short circuit, the wire harness is defective. Properly repair or replace the wire harness.</li> </ul>
				TIP
				Disconnect the ABS ECU coupler before checking the wire harness.

Fault code No. ABS_64 Symptom			Rear wheel sensor power is abnormal.	
Order	Item/components an cause	nd probable	Check or maintenance job	
2	Short circuit in rear wheel sensor lead.		<ul> <li>Check that there is no short circuit between the white terminal "3" and the gray terminal "4".</li> <li>Check that there is no short circuit between the frame ground and the white terminal "3".</li> <li>If there is a short circuit, the rear wheel sensor is defective. Properly repair or replace the rear wheel sensor.</li> </ul>	
			5. ABS ECU 6. Bear wheel sensor	
3	Hydraulic unit interna	I malfunction.	Replace the hydraulic unit assembly.	

#### EAS59C2808 [C-1] DELETING THE FAULT CODES ECA59C2802

## NOTICE

Since the fault codes remain in the memory of the ABS ECU until they are deleted, always delete the fault codes after the service has been completed.

1. Connect the test coupler adapter "1" to the ABS test coupler "2".



- Set the main switch to "ON". Fault codes will be displayed in the multifunction display.
- 3. Set the engine stop switch "1" to " $\boxtimes$ ".

## ECA59C2803

## NOTICE

If the start switch is pushed without setting the engine stop switch to " $\bigotimes$ ", the starter motor gears or other parts may be damaged.

4. Without operating the brake lever, push the start switch "2" at least 10 times in 4 seconds to delete the fault codes.



- 5. The multi-function display switches to the odometer display and the ABS warning light flashes in 0.5 second-intervals while the fault codes are being deleted.
- 6. Set the main switch to "OFF".

7. Set the main switch to "ON" again.

### TIP\_

If fault codes are still displayed in the multifunction display, the malfunctions have not been repaired. Diagnose the malfunctions using the fault codes.

- 8. Set the main switch to "OFF".
- Disconnect the test coupler adapter from the ABS test coupler, and then install the protective cap onto the ABS test coupler. Deleting the fault codes is now finished.

## TIP.

Do not forget to install the protective cap onto the ABS test coupler.

## EAS59C2809

## [C-2] DELETE FUNCTION TEST

- 1. Place the vehicle on the centerstand.
- 2. Set the main switch to "OFF".
- 3. Connect the test coupler adapter to the ABS test coupler.
- 4. Set the main switch to "ON".
- 5. Check:
  - ABS ECU voltage Lower than 12.8 V → Charge or replace the battery.

#### Battery voltage Higher than 12.8 V

## \*\*\*\*\*

a. Connect the digital circuit tester (DC 20 V) to the ABS ECU coupler.



- Positive tester probe  $\rightarrow$
- Brown/white "1"
- Negative tester probe  $\rightarrow$
- Black "2"



b. Measure the ABS ECU voltage.

## \*\*\*\*

- 6. Check:
  - ABS-ECU-to-start-switch-lead continuity No continuity → Replace or repair the wire harness.



## Continuity is all right.

## \*\*\*\*

a. Connect the digital circuit tester to the ABS ECU coupler and right handlebar switch coupler.

Digital circuit tester 90890-03189 Model 88 Multimeter with tachometer YU-A1927

- Positive tester probe  $\rightarrow$
- Green/white "1" (ABS ECU)
- Negative tester probe  $\rightarrow$
- Green/white "2" (right handlebar switch)



b. Check for continuity between the ABS ECU and the start switch lead.

## \*\*\*\*\*

- 7. Check:
  - ABS ECU voltage Out of specification → Replace the right handlebar switch.



Start switch "ON": less than 1 V Start switch "OFF": more than 12 V

- \*\*\*\*
- a. Connect the digital circuit tester (DC 12 V) to the ABS ECU coupler.



Digital circuit tester 90890-03189 Model 88 Multimeter with tachometer YU-A1927

- Positive tester probe  $\rightarrow$
- Green/white "1"
- Negative tester probe  $\rightarrow$ 
  - Black "2"



- b. Push the start switch.
- c. Measure the ABS ECU voltage.

## 

8. If the above-mentioned checks are within specification, replace the hydraulic unit assembly.

#### EAS59C2810 [C-3] FINAL CHECK

## Checking procedures

- 1. Check the brake fluid level in the brake master cylinder reservoir. Refer to "CHECKING THE BRAKE FLUID LEVEL" on page 3-14.
- 2. Check the wheel sensor housings and wheel sensors for proper installation. Refer to "INSTALLING THE FRONT WHEEL (DISCS)" on page 4-24.
- Perform hydraulic unit operation test 1 or 2. Refer to "HYDRAULIC UNIT OPERATION TESTS" on page 4-72.
- 4. Delete the fault codes. Refer to "[C-1] DELETING THE FAULT CODES" on page 8-115.
- Checking the ABS warning light.
   Ensure that the ABS warning light goes off by walking the vehicle at a speed of faster than 7 km/ h (4.4 mi/h) or performing a trial run.

## EAS27973 ELECTRICAL COMPONENTS



- 1. Hydraulic unit assembly
- 2. Fuse box (left)
- 3. Rear brake light switch
- 4. Battery
- 5. Fuel injection system relay
- 6. Starting circuit cut-off relay 1
- 7. Starting circuit cut-off relay 2
- 8. Main fuse
- 9. Starter relay
- 10.Diode 2
- 11.Diode 1
- 12.Rectifier/regulator
- 13.Ignition coil
- 14.Horn
- 15.Radiator fan motor relay
- 16.Headlight relay
- 17.Turn signal/hazard relay
- 18.Lean angle sensor
- 19.Diode 3
- 20.Fuse box (right)
- 21. Front brake light switch
- 22.ECU (engine control unit)



- 1. Main switch/immobilizer unit
- 2. Intake air pressure sensor
- 3. Coolant temperature sensor
- 4. Fuel pump
- 5. Rear wheel sensor
- 6. O<sub>2</sub> sensor
- 7. Crankshaft position sensor
- 8. Stator coil
- 9. Sidestand switch
- 10.Radiator fan
- 11.Front wheel sensor
- 12.Throttle position sensor
- 13.Intake air temperature sensor
- 14.Ambient temperature sensor

## EAS27981 CHECKING THE SWITCHES



- 1. Pass switch
- 2. Dimmer switch
- 3. Horn switch
- 4. Turn signal switch
- 5. Rear brake light switch
- 6. Engine stop switch
- 7. Start switch
- 8. Hazard switch
- 9. Front brake light switch
- 10.Sidestand switch
- 11.Main switch
- 12. Storage box light switch

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

## NOTICE

Never insert the tester probes into the coupler terminal slots "a". Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

TIP

- Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.
- When checking for continuity, switch back and forth between the switch positions a few times.



The switches and their terminal connections are illustrated as in the following example of the main switch.

The switch positions "a" are shown in the far left column and the switch lead colors "b" are shown in the top row.

The continuity (i. e., a closed circuit) between switch terminals at a given switch position is indicated by " $\bigcirc$ — $\bigcirc$ ".

There is continuity between red, brown/blue and brown/red when the switch is set to "ON".

There is continuity between red and brown/red when the switch is set to "P€".



#### EAS27990 CHECKING THE BULBS AND BULB SOCK-ETS

## TIP\_

Do not check any of the lights that use LEDs.

Check each bulb and bulb socket for damage or wear, proper connections, and also for continuity between the terminals.

Damage/wear  $\rightarrow$  Repair or replace the bulb, bulb socket or both.

Improperly connected  $\rightarrow$  Properly connect. No continuity  $\rightarrow$  Repair or replace the bulb, bulb socket or both.

## Types of bulbs

The bulbs used on this vehicle are shown in the illustration.

- Bulbs "a" are used for the headlights. The bulb and socket can be removed as a set by turning the bulb socket counterclockwise.
- Bulbs "b" are used for turn signal lights and can be removed from the socket by pushing and turning the bulb counterclockwise.
- Bulbs "c" are used for auxiliary, license plate and storage box lights and can be removed from their respective socket by carefully pulling them out.



## Checking the condition of the bulbs

The following procedure applies to all of the bulbs.

- 1. Remove:
- Bulb
- EWA4B51012

## A WARNING

Since the headlight bulbs get extremely hot, keep flammable products and your hands away from them until they have cooled down.

ECA4B51010 **NOTICE** 

• Be sure to hold the socket firmly when removing the bulb. Never pull the lead, otherwise it may be pulled out of the terminal in the coupler.

- Avoid touching the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the life of the bulb, and the luminous flux will be adversely affected. If the headlight bulb gets soiled, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.
- 2. Check:
  - Bulb (for continuity) (with the pocket tester) No continuity → Replace.



## TIP.

Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.

## \*\*\*\*

- a. Connect the positive tester probe to terminal "1" and the negative tester probe to terminal "2", and check the continuity.
- b. If reading indicate no continuity, replace the bulb.

## \*\*\*\*\*



## Checking the condition of the bulb sockets

The following procedure applies to all of the bulb sockets.

- 1. Check:
  - Bulb socket (for continuity) (with the pocket tester) No continuity → Replace.



## TIP\_

Check each bulb socket for continuity in the same manner as described in the bulb section, however, note the following.

## \*\*\*\*

- a. Install a good bulb into the bulb socket.
- b. Connect the pocket tester probes to the respective leads of the bulb socket.
- c. Check the bulb socket for continuity. If any of the readings indicate no continuity, replace the bulb socket.

## \*\*\*\*\*

#### EAS28000

## **CHECKING THE FUSES**

The following procedure applies to all of the fuses.

ECA13680 **NOTICE** 

To avoid a short circuit, always set the main switch to "OFF" when checking or replacing a fuse.

- Remove:

   Front cover Refer to "GENERAL CHASSIS" on page 4-1.
- 2. Check:
  - Fuse

## \*\*\*\*

a. Connect the pocket tester to the fuse and check the continuity.

## TIP.

Set the pocket tester selector to " $\Omega \times 1$ ".

Pocket tester 90890-03112 Analog pocket tester YU-03112-C

b. If the pocket tester indicates " $\infty$ ", replace the fuse.

## \*\*\*\*\*

- 3. Replace:
  - Blown fuse

## \*\*\*\*

- a. Set the main switch to "OFF".
- b. Install a new fuse of the correct amperage rating.
- c. Set on the switches to verify if the electrical circuit is operational.

d. If the fuse immediately blows again, check the electrical circuit.

Fuses	Amperage rating	Q'ty
Main	40 A	1
Headlight	20 A	1
Signaling system	15 A	1
Ignition	7.5 A	1
Radiator fan	15 A	1
Parking lighting	10 A	1
Fuel injection system	7.5 A	1
ABS motor	30 A	1
ABS control unit	5 A	1
ABS solenoid	20 A	1
Backup	7.5 A	1
Spare	40 A	1
Spare	30 A	1
Spare	20 A	1
Spare	15 A	1
Spare	10 A	1
Spare	7.5 A	1
Spare	5 A	1

## EWA13310

## 

Never use a fuse with an amperage rating other than that specified. Improvising or using a fuse with the wrong amperage rating may cause extensive damage to the electrical system, cause the lighting and ignition systems to malfunction and could possibly cause a fire.

## \*\*\*\*\*

- 4. Install:
  - Front cover Refer to "GENERAL CHASSIS" on page 4-1.

EAS28031

## CHECKING AND CHARGING THE BATTERY EWA13290

## **WARNING**

Batteries generate explosive hydrogen gas and contain electrolyte which is made of poisonous and highly caustic sulfuric acid. Therefore, always follow these preventive measures:

- Wear protective eye gear when handling or working near batteries.
- Charge batteries in a well-ventilated area.

- Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes).
- DO NOT SMOKE when charging or handling batteries.
- KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.

FIRST AID IN CASE OF BODILY CONTACT: EXTERNAL

- Skin Wash with water.
- Eyes Flush with water for 15 minutes and get immediate medical attention.
   INTERNAL
- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.

#### ECA13661 **NOTICE**

- This is a VRLA (Valve Regulated Lead Acid) battery. Never remove the sealing caps because the balance between cells will not be maintained and battery performance will deteriorate.
- Charging time, charging amperage and charging voltage for a VRLA (Valve Regulated Lead Acid) battery are different from those of conventional batteries. The VRLA (Valve Regulated Lead Acid) battery should be charged according to the appropriate charging method. If the battery is overcharged, the electrolyte level will drop considerably. Therefore, take special care when charging the battery.

## TIP.

Since VRLA (Valve Regulated Lead Acid) batteries are sealed, it is not possible to check the charge state of the battery by measuring the specific gravity of the electrolyte. Therefore, the charge of the battery has to be checked by measuring the voltage at the battery terminals.

- 1. Remove:
  - Front left storage box Refer to "GENERAL CHASSIS" on page 4-1.
- 2. Disconnect:
  - Battery leads
     (from the battery terminals)

## ECA13640

# First, disconnect the battery negative lead "1", and then battery positive lead "2".



- 3. Remove:
  - Battery Refer to "GENERAL CHASSIS" on page 4-1.
- 4. Check:
  - Battery charge

## \*\*\*\*

a. Connect a pocket tester to the battery terminals.

• Positive tester probe  $\rightarrow$ 

- positive battery terminal
- Negative tester probe  $\rightarrow$
- negative battery terminal

## TIP.

- The charge state of a VRLA (Valve Regulated Lead Acid) battery can be checked by measuring its open-circuit voltage (i.e., the voltage when the positive battery terminal is disconnected).
- No charging is necessary when the open-circuit voltage equals or exceeds 12.8 V.
- b. Check the charge of the battery, as shown in the charts and the following example.

## Example

Open-circuit voltage = 12.0 VCharging time = 6.5 hoursCharge of the battery = 20-30%



- A. Open-circuit voltage (V)
- B. Charging time (hours)
- C. Relationship between the open-circuit voltage and the charging time at 20 °C (68 °F)
- D. These values vary with the temperature, the condition of the battery plates, and the electrolyte level.



- A. Open-circuit voltage (V)
- B. Charging condition of the battery (%)
- C. Ambient temperature 20 °C (68 °F)

## \*\*\*\*\*

- 5. Charge:
  - Battery

(refer to the appropriate charging method)

## EWA13300

Do not quick charge a battery.

#### ECA13671 **NOTICE**

- Do not use a high-rate battery charger since it forces a high-amperage current into the battery quickly and can cause battery overheating and battery plate damage.
- If it is impossible to regulate the charging current on the battery charger, be careful not to overcharge the battery.
- When charging a battery, be sure to remove it from the vehicle. (If charging has to be done with the battery mounted

on the vehicle, disconnect the battery negative lead from the battery terminal.)

- To reduce the chance of sparks, do not plug in the battery charger until the battery charger leads are connected to the battery.
- Before removing the battery charger lead clips from the battery terminals, be sure to turn off the battery charger.
- Make sure the battery charger lead clips are in full contact with the battery terminal and that they are not shorted. A corroded battery charger lead clip may generate heat in the contact area and a weak clip spring may cause sparks.
- If the battery becomes hot to the touch at any time during the charging process, disconnect the battery charger and let the battery cool before reconnecting it. Hot batteries can explode!
- As shown in the following illustration, the open-circuit voltage of a VRLA (Valve Regulated Lead Acid) battery stabilizes about 30 minutes after charging has been completed. Therefore, wait 30 minutes after charging is completed before measuring the open-circuit voltage.



- A. Open-circuit voltage (V)
- B. Time (minutes)
- C. Charging
- D. Ambient temperature 20 °C (68 °F)
- E. Check the open-circuit voltage.

## \*\*\*\*

# Charging method using a variable-current (voltage) charger

a. Measure the open-circuit voltage prior to charging.

TIP\_

Voltage should be measured 30 minutes after the engine is stopped.
b. Connect a charger and ammeter to the battery and start charging.

#### TIP\_

Set the charging voltage to 16-17 V. If the setting is lower, charging will be insufficient. If too high, the battery will be over-charged.

c. Make sure that the current is higher than the standard charging current written on the battery.

#### TIP\_

If the current is lower than the standard charging current written on the battery, set the charging voltage adjust dial at 20-24 V and monitor the amperage for 3-5 minutes to check the battery.

- Standard charging current is reached Batterv is good.
- Standard charging current is not reached Replace the battery.
- d. Adjust the voltage so that the current is at the standard charging level.
- e. Set the time according to the charging time suitable for the open-circuit voltage.
- f. If charging requires more than 5 hours, it is advisable to check the charging current after a lapse of 5 hours. If there is any change in the amperage, readjust the voltage to obtain the standard charging current.
- g. Measure the battery open-circuit voltage after leaving the battery unused for more than 30 minutes.

12.8 V or more --- Charging is complete. 12.7 V or less --- Recharging is required. Under 12.0 V --- Replace the battery.

#### . . . . . . . . . . . . . . . . . . . .

## Charging method using a constant voltage charger

a. Measure the open-circuit voltage prior to charging.

TIP.

Voltage should be measured 30 minutes after the engine is stopped.

b. Connect a charger and ammeter to the battery and start charging.

c. Make sure that the current is higher than the standard charging current written on the battery.

#### TIP

If the current is lower than the standard charging current written on the battery, this type of battery charger cannot charge the VRLA (Valve Regulated Lead Acid) battery. A variable voltage charger is recommended.

d. Charge the battery until the battery's charging voltage is 15 V.

#### TIP\_

Set the charging time at 20 hours (maximum).

e. Measure the battery open-circuit voltage after leaving the battery unused for more than 30 minutes.

12.8 V or more --- Charging is complete. 12.7 V or less --- Recharging is required. Under 12.0 V --- Replace the battery.

#### .....

- 6. Install: Battery Refer to "GENERAL CHASSIS" on page 4-1.
- 7. Connect:
  - Battery leads (to the battery terminals)

#### ECA13630 NOTICE

First, connect the battery positive lead "1", and then the battery negative lead "2".



- 8. Check:
  - Battery terminals Dirt  $\rightarrow$  Clean with a wire brush. Loose connection  $\rightarrow$  Connect properly.
- 9. Lubricate:
  - · Battery terminals

# ----1

#### Recommended lubricant Dielectric grease

10. Install:

• Front left storage box Refer to "GENERAL CHASSIS" on page 4-1.

## EAS28040

## CHECKING THE RELAYS

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, replace the relay.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- 1. Disconnect the relay from the wire harness.
- Connect the pocket tester (Ω × 1) and battery (12 V) to the relay terminal as shown. Check the relay operation. Out of specification → Replace.

## Starting circuit cut-off relay 1



- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe

#### Result Continuity (between "3" and "4")

## Starting circuit cut-off relay 2



- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe



Continuity (between "3" and "4")

Starter relay



- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe

# Result Conti

Continuity (between "3" and "4")

## Headlight relay



- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe



## Radiator fan motor relay



- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe

## Result

Continuity (between "3" and "4")

## Fuel injection system relay



- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe



#### Result Continuity (between "3" and "4")

## Grip warmer relay (OPTION)



- 1. Positive battery terminal
- 2. Negative battery terminal
- 3. Positive tester probe
- 4. Negative tester probe

# O II Res

## Result

Continuity

(between "3" and "4")

#### EAS4B51020 CHECKING THE TURN SIGNAL/HAZARD RELAY

- 1. Check:
  - Turn signal/hazard relay input voltage Out of specification → The wiring circuit from the main switch to the turn signal/ hazard relay coupler is faulty and must be repaired.

Turn signal/hazard relay input voltage DC 12 V

## **ELECTRICAL COMPONENTS**

#### \*\*\*\*

a. Connect the pocket tester (DC 20 V) to the turn signal/hazard relay terminal as shown.

Pocket tester 90890-03112 Analog pocket tester YU-03112-C

 Positive tester probe → Blue "1"
 Negative tester probe → Ground



- b. Set the main switch to "ON".
- c. Measure the turn signal/hazard relay input voltage.

#### \*\*\*\*\*

- 2. Check:
  - Turn signal/hazard relay output voltage Out of specification → Replace.



Turn signal/hazard relay output voltage DC 12 V

\*\*\*\*

a. Connect the pocket tester (DC 20 V) to the turn signal/hazard relay terminal as shown.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

• Positive tester probe  $\rightarrow$ 

- Brown/white "1"
- Negative tester probe → Ground



- b. Set the main switch to "ON".
- c. Measure the turn signal/hazard relay output voltage.

\*\*\*\*\*

#### EAS28050 CHECKING THE DIODE

- 1. Check:
  - Diode 2
     Out of specification → Benl
    - Out of specification  $\rightarrow$  Replace.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

## TIP.

0

The pocket tester or the analog pocket tester reading are shown in the following table.

#### Continuity





- \*\*\*\*
- Disconnect the diode 2 from the wire harness.
- b. Connect the pocket tester ( $\Omega \times 1$ ) to the diode 2 terminals as shown.

- c. Check the diode 2 for continuity.
- d. Check the diode 2 for no continuity.

#### TIP\_

When you switch the positive and negative tester probes, the readings in the above chart will be reversed.

#### \*\*\*\*\*

#### EAS28070

## CHECKING THE SPARK PLUG CAPS

The following procedure applies to all of the spark plug caps.

- 1. Check:
  - Spark plug cap resistance Out of specification → Replace.



Resistance 7.5–12.5 kΩ

\*\*\*\*\*

- a. Remove the spark plug cap from the spark plug lead.
- b. Connect the pocket tester ( $\Omega \times 1k$ ) to the spark plug cap as shown.

Pocket tester 90890-03112 Analog pocket tester YU-03112-C



c. Measure the spark plug cap resistance.

\*\*\*\*\*

#### EAS28080

## CHECKING THE IGNITION COIL

- 1. Check:
  - Primary coil resistance
    - Out of specification  $\rightarrow$  Replace.



Primary coil resistance 1.87–2.53  $\Omega$ 

#### \*\*\*\*

- a. Disconnect the ignition coil connectors from the ignition coil terminals.
- b. Connect the pocket tester ( $\Omega \times 1$ ) to the ignition coil as shown.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

• Positive tester probe  $\rightarrow$ 

- Red/black "1"
- Negative tester probe → Orange "2"



c. Measure the primary coil resistance.

#### \*\*\*\*\*

- 2. Check:
  - Secondary coil resistance Out of specification → Replace.



- a. Disconnect the spark plug cap from the ignition coil.
- b. Connect the pocket tester ( $\Omega \times 1k$ ) to the ignition coil as shown.

Pi A

#### Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- Positive tester probe  $\rightarrow$
- Spark plug lead "1"
- Negative tester probe → Spark plug lead "2"



c. Measure the secondary coil resistance.

## \*\*\*\*\*

#### EAS28930

## CHECKING THE IGNITION SPARK GAP

- 1. Check:
  - Ignition spark gap

Out of specification  $\rightarrow$  Perform the ignition system troubleshooting, starting with step 5.

Refer to "TROUBLESHOOTING" on page 8-3.



## Minimum ignition spark gap 6.0 mm (0.24 in)

TIP

If the ignition spark gap is within specification, the ignition system circuit is operating normally.

#### \*\*\*\*

- a. Disconnect the spark plug cap from the spark plug.
- b. Connect the ignition checker "1" as shown.



Ignition checker 90890-06754 Oppama pet-4000 spark checker YM-34487

- c. Set the main switch to "ON" and the engine stop switch to " $\bigcirc$ ".
- d. Measure the ignition spark gap "a".



2. Spark plug cap

 e. Crank the engine by pushing the start switch "(s)" and gradually increase the spark gap until a misfire occurs.

\*\*\*\*\*

### EAS28120

# CHECKING THE CRANKSHAFT POSITION SENSOR

- 1. Disconnect:
  - Crankshaft position sensor coupler (from the wire harness)
- 2. Check:
  - Crankshaft position sensor resistance Out of specification → Replace the crankshaft position sensor/stator assembly.

Crankshaft position sensor resistance 248–372 Ω

\*\*\*\*

a. Connect the pocket tester ( $\Omega \times 100$ ) to the crankshaft position sensor coupler as shown.

Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- Positive tester probe  $\rightarrow$
- Gray "1"
- Negative tester probe  $\rightarrow$
- Black "2"



b. Measure the crankshaft position sensor resistance.

\*\*\*\*\*

CHECKING THE LEAN ANGLE SENSOR

- 1. Remove:
  - Lean angle sensor (from the bracket.)

8-135

- 2. Check:
  - Lean angle sensor output voltage Out of specification → Replace.

# 

Lean angle sensor output voltage Less than 45°: 0.4–1.4 V

More than 45°: 3.7–4.4 V

\*\*\*\*

- Connect the test harness-lean angle sensor (6P) "1" to the lean angle sensor and wire harness as shown.
- b. Connect the pocket tester (DC 20 V) to the test harness-lean angle sensor (6P).

Pocket tester
 90890-03112
 Analog pocket tester
 YU-03112-C
 Test harness- lean angle sensor
 (6P)
 90890-03209
 YU-03209

- Positive tester probe → Yellow/green (wire harness color)
- Negative tester probe → Black/blue (wire harness color)



- c. Set the main switch to "ON".
- d. When turn the lean angle sensor to  $45^{\circ}$ .
- e. Measure the lean angle sensor output voltage.

\*\*\*\*\*

#### EAS28940 CHECKING THE STARTER MOTOR OPERA-TION

1. Check:

Starter motor operation
 Does not operate → Perform the electric
 starting system troubleshooting, starting
 with step 4.

 Befer to "TBOUBLESHOOTING" on page

Refer to "TROUBLESHOOTING" on page 8-9.

## \*\*\*\*\*

a. Connect the positive battery terminal "1" and starter motor lead "2" with a jumper lead "3".

# EWA13810

- A wire that is used as a jumper lead must have at least the same capacity of the battery lead, otherwise the jumper lead may burn.
- This check is likely to produce sparks, therefore, make sure no flammable gas or fluid is in the vicinity.



b. Check the starter motor operation.

#### \*\*\*\*\*

#### EAS28150 CHECKING THE STATOR COIL

- 1. Disconnect:
  - Stator coil coupler
    - (from the wire harness)
- 2. Check:
  - Stator coil resistance Out of specification → Replace the crankshaft position sensor/stator assembly.



**Stator coil resistance** 0.224–0.336 Ω

\*\*\*\*

a. Connect the digital circuit tester ( $\Omega \times 1$ ) to the stator coil coupler as shown.

# ELECTRICAL COMPONENTS



**Digital circuit tester** 90890-03189 Model 88 Multimeter with tachometer YU-A1927

- Positive tester probe  $\rightarrow$ White "1"
- Negative tester probe  $\rightarrow$ White "2"
- Positive tester probe  $\rightarrow$ White "1"
- Negative tester probe  $\rightarrow$ White "3"
- Positive tester probe  $\rightarrow$ White "2"
- Negative tester probe → White "3"



b. Measure the stator coil resistance.

## 

#### EAS28170

## CHECKING THE RECTIFIER/REGULATOR

- 1. Check:
  - · Battery charging voltage Out of specification  $\rightarrow$  Check the stator coil condition. If the stator coil does not have a problem, replace the rectifier/regulator.

**Refer to "CHECKING THE STATOR** COIL" on page 8-136.



#### **Battery charging voltage** above 14 V at 5000 r/min

a. Set the engine tachometer to the spark plug lead of cylinder #1.

b. Connect the pocket tester (AC 20 V) to the battery terminal as shown.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- Positive tester probe  $\rightarrow$ Battery positive terminal "1"
- Negative tester probe  $\rightarrow$
- Battery negative terminal "2"



- c. Start the engine and let it run at approximately 5000 r/min.
- d. Measure the rectifier/regulator input voltage.

#### 

#### EAS28180 **CHECKING THE HORN**

- 1. Check:
  - Horn resistance
    - Out of specification  $\rightarrow$  Replace.



**Coil resistance** 

- **1.06–1.11** Ω
- \*\*\*\*\*
- a. Disconnect the horn leads from the horn terminals.
- b. Connect the digital circuit tester to the horn terminals.



**Digital circuit tester** 90890-03189 Model 88 Multimeter with tachometer YU-A1927

- Positive tester probe  $\rightarrow$
- Horn terminal "1"
- Negative tester probe  $\rightarrow$ Horn terminal "2"



c. Measure the horn resistance.

## \*\*\*\*\*

- 2. Check:
  - Horn sound Faulty sound  $\rightarrow$  Replace.

#### EAS28230 CHECKING THE FUEL SENDER

- 1. Remove:
  - Fuel pump (from the fuel tank) Refer to "FUEL TANK" on page 7-1.
- 2. Check:
  - Fuel sender resistance Out of specification  $\rightarrow$  Replace the fuel pump.



Sender unit resistance (full) **4.0–10.0** Ω Sender unit resistance (empty) 93.0–100.0 Ω

## . . . . . . . . . . . . . . . . .

a. Connect the pocket tester ( $\Omega \times 1$ ) to the fuel pump terminals as shown.

> Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- Positive tester probe  $\rightarrow$ Green "1"
- Negative tester probe  $\rightarrow$
- Black "2"



b. Move the fuel sender float to empty fuel tank position "3" and full fuel tank position "4" level position.



c. Measure the fuel sender resistance.

#### \*\*\*\*\*

- 3. Install:
  - Fuel pump Refer to "FUEL TANK" on page 7-1.

## EAS59C1802

## CHECKING THE FUEL METER/FUEL LEVEL WARNING LIGHT

This model is equipped with a self-diagnosis device for the fuel level detection circuit.

- 1. Check:
  - Fuel meter/fuel level warning light "1" (Set the main switch to "ON".) Fuel meter/fuel level warning light comes on for a few seconds, then goes off  $\rightarrow$ Fuel meter/fuel level warning light is OK. Fuel meter/fuel level warning light does not come on  $\rightarrow$  Replace the meter assembly.

Fuel meter/fuel level warning light flashes eight times, then goes off for 3 seconds in a repeated cycle (malfunction detected in fuel sender)  $\rightarrow$  Replace the fuel pump assembly.



#### EAS28250 CHECKING THE RADIATOR FAN MOTOR 1. Check:

 Radiator fan motor Faulty/rough movement  $\rightarrow$  Replace.

#### \*\*\*\*

- a. Disconnect the radiator fan motor coupler from the wire harness.
- b. Connect the battery (DC 12 V) as shown.
- Positive battery terminal  $\rightarrow$
- Blue "1"
- Negative battery terminal  $\rightarrow$
- Black "2"



c. Measure the radiator fan motor movement.

## .....

## EAS28260

# CHECKING THE COOLANT TEMPERATURE SENSOR

- 1. Remove:
- Coolant temperature sensor Refer to "THERMOSTAT" on page 6-7. EWA14130

## WARNING

- Handle the coolant temperature sensor with special care.
- Never subject the coolant temperature sensor to strong shocks. If the coolant temperature sensor is dropped, replace it.
- 2. Check:
  - Coolant temperature sensor resistance Out of specification → Replace.



Coolant temperature sensor resistance 2.32–2.59 kΩ at 20 °C (68 °F) 310.0–326.0 Ω at 80 °C (176 °F)

510.0-520.0 \$2 at 60 C (170 T)

- \*\*\*\*
- a. Connect the pocket tester ( $\Omega \times 100/ \times 1k$ ) to the coolant temperature sensor terminals as shown.

Pocket tester 90890-03112 Analog pocket tester YU-03112-C b. Immerse the coolant temperature sensor "1" in a container filled with coolant "2".

## TIP\_

Make sure the coolant temperature sensor terminals do not get wet.

c. Place a thermometer "3" in the coolant.



- d. Heat the coolant or let it cool down to the specified temperature.
- e. Measure the coolant temperature sensor resistance.

## \*\*\*\*

- 3. Install:
  - Coolant temperature sensor



Coolant temperature sensor 18 Nm (1.8 m·kgf, 13 ft·lbf)

# CHECKING THE THROTTLE POSITION SENSOR

- 1. Remove:
  - Throttle position sensor (from the throttle body)
- 2. Check:
  - Throttle position sensor

\*\*\*\*\*

a. Connect the pocket tester ( $\Omega \times 1 \text{ k}$ ) to the throttle position sensor as shown.

#### Pocket tester 90890-03112 Analog pocket tester YU-03112-C

 Positive tester probe → Blue "1"

- Negative tester probe → Black/blue "2"
- b. Measure the throttle position sensor maximum resistance.
   Out of specification → Replace the throttle position sensor.



#### Throttle position sensor maximum resistance 2.64–6.16 kΩ

c. Connect the pocket tester ( $\Omega \times 1$  k) to the throttle position sensor as shown.

 Positive tester probe → Yellow "3"

 Negative tester probe → Black/blue "2"



d. While slowly turning the throttle position sensor shaft, check that the throttle position sensor resistance is within the specified range.

The resistance does not change or it changes abruptly  $\rightarrow$  Replace the throttle position sensor.



Throttle position sensor resistance  $0-6.16 \text{ k}\Omega$ 

\*\*\*\*\*

- 3. Install:
  - Throttle position sensor

#### TIP\_\_\_

When installing the throttle position sensor, adjust its angle properly. Refer to "ADJUST-ING THE THROTTLE POSITION SENSOR" on page 7-9.

# CHECKING THE INTAKE AIR PRESSURE SENSOR

- 1. Check:
  - Intake air pressure sensor output voltage Out of specification → Replace.

Intake air pressure output voltage 3.57-3.71 V at 101.32 kPa

#### \*\*\*\*

a. Connect the test harness S- pressure sensor (3P) "1" to the intake air pressure sensor and wire harness as shown.

# ECA16730

Pay attention to the installing direction of the test harness S- pressure sensor (3P) coupler "a".

b. Connect the digital circuit tester (DCV) to the test harness S- pressure sensor (3P).



Digital circuit tester 90890-03189 Model 88 Multimeter with tachometer YU-A1927 Test harness S- pressure sensor (3P) 90890-03207 YU-03207

- Positive tester probe  $\rightarrow$
- Pink/white (wire harness color)
- Negative tester probe  $\rightarrow$
- Black/blue (wire harness color)



- c. Set the main switch to "ON".
- d. Measure the intake air pressure sensor output voltage.

#### \*\*\*\*\*

## CHECKING THE INTAKE AIR TEMPERA-TURE SENSOR

- 1. Remove:
- Intake air temperature sensor (from the air filter case.)
  EWA14110

## 

• Handle the intake air temperature sensor with special care.

# • Never subject the intake air temperature sensor to strong shocks. If the intake air temperature sensor is dropped, replace it.

- 2. Check:
  - Intake air temperature sensor resistance Out of specification → Replace.



a. Connect the pocket tester ( $\Omega \times 1$ k/  $\times 100$ ) to the intake air temperature sensor terminal as shown.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

b. Immerse the intake air temperature sensor "1" in a container filled with water "2".

#### TIP.

Make sure that the intake air temperature sensor terminals do not get wet.

c. Place a thermometer "3" in the water.



- d. Heat the water or let it cool down to the specified temperatures.
- e. Measure the intake air temperature sensor resistance.

# 3. Install:

• Intake air temperature sensor



#### EAS59C1801 CHECKING THE FUEL INJECTORS

- 1. Check:
  - Fuel injector resistance Out of specification → Replace the fuel injector.



### \*\*\*\*

- a. Disconnect the fuel injector coupler from wire harness.
- b. Connect the pocket tester ( $\Omega \times 1$ ) to the fuel injector coupler.



Pocket tester 90890-03112 Analog pocket tester YU-03112-C

- Positive tester probe  $\rightarrow$
- Injector terminal "1"
- Negative tester probe → Injector terminal "2"



\*\*\*\*\*

c. Measure the fuel injector resistance.

8-141

TROUBLESHOOTING	9-1
GENERAL INFORMATION	9-1
STARTING FAILURE/HARD STARTING	9-1
POOR ENGINE IDLING SPEED PERFORMANCE	9-1
POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE	9-2
FAULTY CLUTCH	9-2
OVERHEATING	9-2
OVERCOOLING	9-3
POOR BRAKING PERFORMANCE	9-3
FAULTY FRONT FORK LEGS	9-3
UNSTABLE HANDLING	9-3
FAULTY LIGHTING OR SIGNALING SYSTEM	9-4
TROUBLESHOOTING AT THE ABS WARNING LIGHT	9-4

EAS28460

## GENERAL INFORMATION

#### TIP\_

The following guide for troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to basic troubleshooting. Refer to the relative procedure in this manual for checks, adjustments, and replacement of parts.

#### EAS30420

## STARTING FAILURE/HARD STARTING

## Engine

- 1. Cylinder(s) and cylinder head
  - Loose spark plug
  - Loose cylinder head or cylinder
  - Damaged cylinder head gasket
  - Damaged cylinder gasket
  - Worn or damaged cylinder
  - Incorrect valve clearance
  - Improperly sealed valve
  - Incorrect valve-to-valve-seat contact
  - Incorrect valve timing
  - Faulty valve spring
  - Seized valve
- 2. Piston(s) and piston ring(s)
  - · Improperly installed piston ring
  - Damaged, worn or fatigued piston ring
  - Seized piston ring
  - Seized or damaged piston
- 3. Air filter
  - Improperly installed air filter
  - Clogged air filter element
- 4. Crankcase and crankshaft
  - Improperly assembled crankcase
    - Seized crankshaft

## **Fuel system**

- 1. Fuel tank
  - Empty fuel tank
  - Clogged rollover valve
  - Clogged fuel tank breather hose
  - Deteriorated or contaminated fuel
  - Clogged or damaged fuel hose
- 2. Fuel pump
  - Faulty fuel pump
  - Faulty fuel injection system relay
  - Damaged vacuum hose
  - Improperly routed hose

- 3. Throttle body
  - Deteriorated or contaminated fuel
  - Sucked-in air

## Electrical system

- 1. Battery
  - Discharged battery
  - Faulty battery
- 2. Fuse(s)
  - Blown, damaged or incorrect fuse
  - Improperly installed fuse
- 3. Spark plug(s)
  - Incorrect spark plug gap
  - Incorrect spark plug heat range
  - Fouled spark plug
  - Worn or damaged electrode
  - Worn or damaged insulator
  - · Faulty spark plug cap
- 4. Ignition coil
  - Cracked or broken ignition coil body
  - Broken or shorted primary or secondary coils
  - Faulty spark plug lead
- 5. Ignition system
  - Faulty ECU (engine control unit)
  - Faulty crankshaft position sensor
  - Broken generator rotor woodruff key
- 6. Switches and wiring
  - Faulty main switch
  - Faulty engine stop switch
  - Broken or shorted wiring
  - Faulty front, rear or both brake light switches
  - Faulty start switch
  - Faulty sidestand switch
  - Improperly grounded circuit
  - Loose connections
- 7. Starting system
  - Faulty starter motor
  - Faulty starter relay
  - · Faulty starting circuit cut-off relay
  - Faulty starter clutch

#### EAS30440

## POOR ENGINE IDLING SPEED PERFOR-MANCE

## Engine

- 1. Cylinder(s) and cylinder head
  - Incorrect valve clearance
  - Damaged valve train components
- 2. Air filter
  - Clogged air filter element

## Fuel system

- 1. Throttle body
  - Damaged or loose throttle body joint
  - Improperly synchronized throttle body
  - Improperly adjusted engine idling speed (idle adjusting screw)
  - Improper throttle grip free play
  - Flooded throttle body

## Electrical system

- 1. Battery
  - Discharged battery
  - Faulty battery
- 2. Spark plug(s)
  - Incorrect spark plug gap
  - Incorrect spark plug heat range
  - Fouled spark plug
  - Worn or damaged electrode
  - Worn or damaged insulator
  - Faulty spark plug cap
- 3. Ignition coil
  - Broken or shorted primary or secondary coils
  - Faulty spark plug lead
  - Cracked or broken ignition coil
- 4. Ignition system
  - Faulty ECU (engine control unit)
  - Faulty crankshaft position sensor
  - Broken generator rotor woodruff key

## EAS30450

## POOR MEDIUM-AND-HIGH-SPEED PER-FORMANCE

Refer to "STARTING FAILURE/HARD START-ING" on page 9-1.

## Engine

- 1. Air filter
  - Clogged air filter element

## Fuel system

- 1. Throttle body
  - Faulty throttle body
- 2. Fuel pump
  - Faulty fuel pump

#### EAS28580 FAULTY CLUTCH

## Engine operates but scooter will not move

- 1. V-belt
  - Bent, damaged or worn V-belt
  - Slipping V-belt

- 2. Primary pulley cam and primary pulley slider
  - Damaged or worn primary pulley cam
  - Damaged or worn primary pulley slider
- 3. Clutch spring(s)
  - Damaged clutch spring
- 4. Transmission gear(s)
  - Damaged transmission gear

## **Clutch slips**

- 1. Clutch
  - Improperly assembled clutch
  - Fatigued clutch spring
  - Worn clutch weight
  - Worn friction plate
  - Worn clutch plate
- 2. Engine oil
  - Incorrect oil level
  - Incorrect oil viscosity (low)
  - Deteriorated oil
- 3. Primary sliding sheave
  - Seized primary sliding sheave

## Poor starting performance

- 1. V-belt
  - V-belt slips
  - Oil or grease on the V-belt
- 2. Primary sliding sheave
  - Faulty operation
  - Worn pin groove
  - Worn pin

## Poor speed performance

- 1. V-belt
  - Oil or grease on the V-belt
- 2. Primary pulley weight(s)
  - Faulty operation
  - Worn primary pulley weight
- 3. Primary fixed sheave
  - Worn primary fixed sheave
- 4. Primary sliding sheaveWorn primary sliding sheave
- 5. Secondary fixed sheave
  - Worn secondary fixed sheave
- 6. Secondary sliding sheave
  - Worn secondary sliding sheave

#### EAS30480 OVERHEATING

## Engine

- 1. Clogged coolant passages
  - Cylinder head and piston(s)
  - Heavy carbon buildup

- 2. Engine oil
  - Incorrect oil level
  - Incorrect oil viscosity
  - Inferior oil quality

## Cooling system

- 1. Coolant
  - Low coolant level
- 2. Radiator
  - Damaged or leaking radiator
  - Faulty radiator cap
  - Bent or damaged radiator fin
- 3. Water pump
  - Damaged or faulty water pump
  - Thermostat
  - Thermostat stays closed
  - Oil cooler
  - Clogged or damaged oil cooler
  - Hose(s) and pipe(s)
  - Damaged hose
  - Improperly connected hose
  - Damaged pipe
  - Improperly connected pipe

## Fuel system

- 1. Throttle body
  - Damaged or loose throttle body joint
- 2. Air filter
  - Clogged air filter element

## Chassis

- 1. Brake(s)
  - Dragging brake

## Electrical system

- 1. Spark plug(s)
  - Incorrect spark plug gap
  - Incorrect spark plug heat range
- 2. Ignition system
  - Faulty ECU

## EAS28610

## OVERCOOLING

## Cooling system

- 1. Thermostat
  - Thermostat stays open

## EAS28620

## POOR BRAKING PERFORMANCE

- Worn brake pad
- Worn brake discAir in hydraulic brake system
- Leaking brake fluid
- Faulty brake caliper kit

- Faulty brake caliper seal
- Loose union bolt
- Damaged brake hose
- Oil or grease on the brake disc
- Oil or grease on the brake pad
- Incorrect brake fluid level

#### EAS28660 FAULTY FRONT FORK LEGS

## Leaking oil

- Bent, damaged or rusty inner tube
- Cracked or damaged outer tube
- Improperly installed oil seal
- Damaged oil seal lip
- Incorrect oil level (high)
- Loose damper rod bolt
- Damaged damper rod bolt copper washer
- Cracked or damaged cap bolt O-ring

## Malfunction

- Bent or damaged inner tube
- Bent or damaged outer tube
- Damaged fork spring
- Worn or damaged outer tube bushing
- Bent or damaged damper rod
- Incorrect oil viscosity
- Incorrect oil level

## EAS28670

## UNSTABLE HANDLING

- 1. Handlebar
  - Bent or improperly installed handlebar
- 2. Steering head components
  - Improperly installed upper bracket
  - Improperly installed lower bracket (improperly tightened ring nut)
  - Bent steering stem
  - Damaged ball bearing or bearing race
- 3. Front fork leg(s)
  - Uneven oil levels (both front fork legs)
  - Unevenly tensioned fork spring (both front fork legs)
  - Broken fork spring
  - Bent or damaged inner tube
  - Bent or damaged outer tube
- 4. Swingarm
  - Worn bearing or bushing
  - Bent or damaged swingarm
- 5. Rear shock absorber assembly
  - Faulty rear shock absorber spring
  - Leaking oil or gas

- 6. Tire(s)
  - Uneven tire pressures (front and rear)
  - Incorrect tire pressure
  - Uneven tire wear
- 7. Wheel(s)
  - Incorrect wheel balance
  - Deformed cast wheel
  - Damaged wheel bearing
  - Bent or loose wheel axle
  - Excessive wheel runout
- 8. Frame
  - Bent frame
  - Damaged steering head pipe
  - Improperly installed bearing race

#### EAS28710 FAULTY LIGHTING OR SIGNALING SYS-TEM

## Headlight does not come on

- Wrong headlight bulb
- Too many electrical accessories
- Hard charging
- Incorrect connection
- Improperly grounded circuit
- Poor contacts (main or dimmer switch)
- Burnt-out headlight bulb

## Headlight bulb burnt out

- Wrong headlight bulb
- Faulty battery
- Faulty rectifier/regulator
- Improperly grounded circuit
- · Faulty main switch
- · Faulty dimmer switch
- Headlight bulb life expired

## Tail/brake light does not come on

- Wrong tail/brake light bulb
- Too many electrical accessories
- Incorrect connection
- Burnt-out tail/brake light bulb

## Tail/brake light bulb burnt out

- Wrong tail/brake light bulb
- Faulty battery
- Tail/brake light bulb life expired

## Turn signal does not come on

- Faulty turn signal switch
- Faulty turn signal/hazard relay
- Burnt-out turn signal bulb
- Incorrect connection
- · Damaged or faulty wire harness
- Improperly grounded circuit

- Faulty battery
- Blown, damaged or incorrect fuse

#### Turn signal blinks slowly

- Faulty turn signal/hazard relay
- Faulty main switch
- Faulty turn signal switch
- Incorrect turn signal bulb

### Turn signal remains lit

- Faulty turn signal/hazard relay
- Burnt-out turn signal bulb

#### Turn signal blinks quickly

- Incorrect turn signal bulb
- Faulty turn signal/hazard relay
- Burnt-out turn signal bulb

## Horn does not sound

- Improperly adjusted horn
- Damaged or faulty horn
- Faulty main switch
- · Faulty horn switch
- Faulty battery
- · Blown, damaged or incorrect fuse
- Faulty wire harness

## EAS59C2901

#### TROUBLESHOOTING AT THE ABS WARN-ING LIGHT

Refer to "BASIC PROCESS FOR TROUBLE-SHOOTING" on page 8-93.

#### EAS59C1001 SELF-DIAGNOSTIC FUNCTION AND DIAGNOSTIC CODE TABLE

## Self-Diagnostic function table

Fault code No.	Item	Reference pages	Fault code No.	Item	Reference pages
12	Crankshaft position sensor	8-37	30	Lean angle sensor (turnover of vehicle)	8-51
13	Intake air pressure sensor (open or short cir- cuit)	8-38	33	Ignition coil (faulty ignition)	8-53
14	Intake air pressure sensor hose line (piping system)	8-41	37	Fast idle plunger (stuck fully open)	8-54
15	Throttle position sensor (open or short cir- cuit)	8-43	41	Lean angle sensor (open or short cir- cuit)	8-56
16	Throttle position sensor (stuck)	8-45	42	Front wheel sensor	8-57
19	Sidestand switch (open circuit wire harness to ECU)	8-46	43	Fuel system voltage (monitor voltage)	8-60
21	Coolant tempera- ture sensor (open or short cir- cuit)	8-47	44	Error in writing the amount of CO adjustment on EEPROM	8-61
22	Intake air tempera- ture sensor (open or short cir- cuit)	8-48	46	Vehicle system power supply	8-63
24	O <sub>2</sub> sensor (Not activated)	8-50	50	ECU internal mal- function (memory check error)	8-63

# SELF-DIAGNOSTIC FUNCTION AND DIAGNOSTIC CODE TABLE

Fault code No.	ltem	Reference pages	Fault code No.	Item	Reference pages
Er-1	ECU internal mal- function (output sig- nal error)	8-64	Er-3	ECU internal mal- function (output sig- nal error)	8-66
Er-2	ECU internal mal- function (output sig- nal error)	8-65	Er-4	ECU internal mal- function (input sig- nal error)	8-67

## Communication error with the meter

## Diagnostic code: sensor operation table

Diag- nostic code No.	Item	Meter display	Checking method
d:01	Throttle position sensor sig- nal		
	<ul> <li>Fully closed position</li> </ul>	14–20	Check with throttle valves fully closed.
	<ul> <li>Fully opened position</li> </ul>	97–107	Check with throttle valves fully open.
d:03	Intake air pressure	Displays the intake air pres- sure.	Set the engine stop switch to " $\bigcirc$ ", and then push the start switch " $\circledast$ ". (If the dis- play value changes, the per- formance is OK.)
d:05	Intake air temperature	When engine is cold: Dis- plays temperature closer to air temperature When engine is hot: Air tem- perature + approx. 20°C (68 °F)	Compare the actually mea- sured intake air temperature with the meter display value.
d:06	Coolant temperature	When engine is cold: Dis- plays temperature closer to air temperature When engine is hot: Displays current coolant temperature	Compare the actually mea- sured coolant temperature with the meter display value.
d:07	Vehicle speed pulse	0–999	Check that the number increases when the front wheel is rotated. The num- ber is cumulative and does not reset each time the wheel is stopped.
d:08	Lean angle sensor • Upright • Overturned	0.4–1.4	Remove the lean angle sen- sor and incline it more than 45 degrees.

# SELF-DIAGNOSTIC FUNCTION AND DIAGNOSTIC CODE TABLE

		1	1
Diag- nostic code No.	ltem	Meter display	Checking method
d:09	Fuel system voltage (battery voltage)	Approximately 12.0	Set the engine stop switch to " $\bigcirc$ ", and then compare with the actually measured battery voltage. (If the bat- tery voltage is lower, per- form recharging.)
d:20	Sidestand switch <ul> <li>Stand retracted</li> <li>Stand extended</li> </ul>	ON OFF	Set on/off the sidestand switch.
d:60	EEPROM fault code display <ul> <li>No history</li> <li>History exists</li> </ul>	<ul> <li>00</li> <li>01 or 02 (Cylinder fault code)</li> <li>(If both cylinders are defective, the display alternates every two seconds.)</li> </ul>	
d:61	Malfunction history code display • No history • History exists	<ul> <li>00</li> <li>Fault code Nos. 12–50</li> <li>(If more than one code number is detected, the display alternates every two seconds to show all the detected code numbers. When all code numbers are shown, the display repeats the same process.)</li> </ul>	
d:62	Malfunction history code erasure • No history • History exists	<ul> <li>00</li> <li>Displays the total number of malfunctions, including the current malfunction, that have occurred since the history was last erased. (For example, if there have been three malfunctions, "03" is displayed.)</li> </ul>	— To erase the history, set the engine stop switch from " $\bowtie$ " to " $\bigcirc$ ".
d:63	Malfunction code reinstate- ment (for fault code No. 24) • No malfunction code • Malfunction code exists	00 Fault code No. 24	— To reinstate, set the engine stop switch from " $\bigotimes$ " to " $\bigcirc$ ".
u.70		0-234 [-]	—

# SELF-DIAGNOSTIC FUNCTION AND DIAGNOSTIC CODE TABLE

Diag- nostic	Item	Actuation	Checking method
No.			
d:30	Ignition coil	Actuates the ignition coil five times at one-second inter- vals. Illuminates the engine trou- ble warning light.	<ul><li>Check the spark five times.</li><li>Connect an ignition checker.</li></ul>
d:36	Fuel injector #1	Actuates the fuel injector #1 five times at one-second intervals. Illuminates the engine trou- ble warning light.	Check the operating sound of the fuel injector #1 five times. ECA59C1801 <b>NOTICE</b> Disconnect the fuel pump coupler.
d:37	Fuel injector #2	Actuates the fuel injector #2 five times at one-second intervals. Illuminates the engine trou- ble warning light.	Check the operating sound of the fuel injector #2 five times. ECA59C1801 <b>NOTICE</b> Disconnect the fuel pump coupler.
d:50	Fuel injection system relay	Actuates the fuel injection system relay five times at one-second intervals. Illuminates the engine trou- ble warning light.	Check the operating sound of the fuel injection system relay five times.
d:51	Radiator fan motor relay	Actuates the radiator fan motor relay for five cycles of five seconds. (ON 2 sec- onds, OFF 3 seconds) Illuminates the engine trou- ble warning light.	Check the operating sound of the radiator fan motor relay five times.
d:52	Headlight relay	Actuates the headlight relay for five cycles of five seconds. (ON 2 seconds, OFF 3 sec- onds) Illuminates the engine trou- ble warning light.	Check the operating sound of the headlight relay five times.
d:57	Grip warmer relay	Actuates the grip warmer relay. Illuminates the engine trou- ble warning light. (The light is off when the relay is off, and the light is on when the relay is on.)	Touch the grip warmer to check the temperature change.

## Diagnostic code: actuator operation table

#### EAS28740 WIRING DIAGRAM

## XP500A 2012

- 1. Crankshaft position sensor 2. AC magneto 3. Rectifier/regulator 4. Frame ground 5. Joint 6. Main switch 7. Immobilizer unit 8. Joint coupler 9. Storage box light switch 10. Storage box light 11. Anti-theft alarm 12. Fuel injection system fuse 13. Backup fuse 14. Signaling system fuse 15. Headlight fuse 16. Ignition fuse 17. Radiator fan fuse 18. Parking lighting fuse 19. Battery 20. Negative lead 21. Main fuse 22. Starter relay 23. Starter motor 24. Starting circuit cut-off relay 2 25. Diode 1 26. Right handlebar switch 27. Engine stop switch 28. Start switch 29. Hazard switch 30. Front brake light switch 31. ABS motor fuse 32. ABS solenoid fuse 33. Diode 2 34. Starting circuit cut-off relay 1 35. Fuel injection system relay 36. Fuel pump 37. Fuel sender 38. Sidestand switch 39. ECU (engine control unit) 40. Ignition coil 41. Spark plug 42. Fuel injector #1 43. Fuel injector #2 44. Coolant temperature sensor 45. Intake air temperature sensor 46. Intake air pressure sensor 47.O<sub>2</sub> sensor 48. Throttle position sensor 49. Lean angle sensor 50. Diagnostic tool coupler 51. Wheel sensor shield ground 52. ABS ECU (electronic control unit)
- 53. Front wheel sensor
- 54. Rear wheel sensor
- 55. ABS test coupler
- 56. Grip warmer relay

91. Meter light
-----------------

- A. OPTION
- B. Wire harness
- C. Headlight sub-wire harness
- D. Throttle position sensor subwire harness
- E. Grip warmer sub-wire harness

#### EAS28750 **COLOR CODE**

В	Black
Br	Brown
Ch	Chocolate
Dg	Dark green
G	Green
Gy	Gray
L	Blue
Lg	Light green
0	Orange
Р	Pink
R	Red

Sb	Sky blue
W	White
Y	Yellow
B/L	Black/Blue
B/W	Black/White
B/Y	Black/Yellow
Br/L	Brown/Blue
Br/R	Brown/Red
Br/W	Brown/White
G/B	Green/Black
G/L	Green/Blue
G/R	Green/Red
G/W	Green/White
G/Y	Green/Yellow
Gy/G	Gray/Green
L/B	Blue/Black
L/G	Blue/Green
L/R	Blue/Red
L/W	Blue/White
L/Y	Blue/Yellow
P/W	Pink/White
R/B	Red/Black
R/G	Red/Green
R/L	Red/Blue
R/W	Red/White
R/Y	Red/Yellow
W/R	White/Red
W/Y	White/Yellow
Y/B	Yellow/Black
Y/G	Yellow/Green
Y/L	Yellow/Blue
Y/R	Yellow/Red



## SCHEMA DE CABLAGE XP500A

SCHALTPLAN XP500A

## SCHEMA ELETTRICO XP500A



## DIAGRAMA DE CONEXIONES DE XP500A

WIRING DIAGRAM XP500A SCHEMA DE CABLAGE XP500A SCHALTPLAN XP500A SCHEMA ELETTRICO XP500A



## DIAGRAMA DE CONEXIONES DE XP500A

